

Super Cruiser G8

Operator's Manual MY17



GA8700771 REV 5
SEP 2018
FROM SERIAL #201874



GOLDACRES

For further information about any of the products shown please visit - www.goldacres.com.au.

© Goldacres Trading 2018

This publication and all designs are copyright.

No part, products or designs may be reproduced by any process except in accordance with the Copyright act 1968.

All information in this operator's manual is based on the latest product information available at the time of printing. The policy of Goldacres is one of continuous improvement and as such, Goldacres reserve the right to alter any specifications and designs without notice and without incurring any obligation regarding such changes.

No part of this manual may be reproduced without written permission from Goldacres. All photographs and technical information remain the property of Goldacres.

Goldacres Trading Pty Ltd
3 Morang Crescent
Mitchell Park Vic 3355

Ph: 03 5342 6399

Fax: 03 5342 6308

Contents

I INTRODUCTION	I	Glossary	53
Welcome.	I		
2 SAFETY	3	5 DRIVETRAIN	55
Safety Information	3	Key Features	55
		Engine	56
3 GENERAL INFORMATION & SPECIFICATIONS	9	Axles	57
Machine Orientation	9	Transmission	58
General.	9	Braking System	59
Wheels & Tyres.	11	Steering System	60
Dimensions.	12	Suspension System	61
Identification & Parts Ordering	13	Transfer Case.	62
4 CABIN	15	6 CALIBRATION	63
Key Features	15	General.	63
Armrest Controls - Raven Controller - 36-42m.	16	Control Valve & Flow Meter Locations	64
Armrest Controls - Raven Controller - 48m	17	Control Valve.	64
Joystick Controls - Raven Controller.	18	Flow Meter Calibration - Raven	64
Operator Seat	19	Nozzle Calibration	65
Steering Column	20	Speed Sensors	66
Multifunction Switch	21	Raven SCS4400 Console Calibration	67
Vehicle Information Unit	21	3TS - Boom Tier Programming	73
Overhead Components	22	7 PRE-OPERATION	77
Air Conditioning	23	Preparing Sprayer For Use.	77
AM/FM Radio	25	Spray Calibration.	78
UHF Two Way Radio.	25	Maintenance	78
Map Light.	25	Starting.	79
Lighting	26	Shut Down.	79
Rear Corner Console	28	8 OPERATION	81
Power Distribution Box	29	Machine Key Features	81
Power Distribution Box - Fuse Box Layouts.	30	EZ Control Station.	82
Autosteer System - Connectors.	31	EZ Control Station - Key Functions	83
Pressure Gauges	32	Suction Filter	84
CANtrak System.	33	Joystick Control	85
CANtrak System - Parameters Monitored	37	Side Console Switches - General	87
CANtrak System - Alarms	40	Side Console Switches - Boom 36-42 m	88
CANtrak System - Engine Fault Codes	41	Side Console Switches - Boom 48 m	89
CANtrak System - Configuration	49	Tank Source Control.	90
GEM Diagnostics.	52	Transmission	91
		Controller - Raven SCS4400 - Standard.	93

Controller - ISOBUS - Optional	94	Air Conditioning System	162
Tank Filling	95	Electrical System	163
Chemical Induction Hopper	97	Maintenance Schedules	164
Agitation	100	First Service - 50 Hours	170
Spray Application.	100		
RapidFire	101	II TROUBLESHOOTING	171
RapidFlow	105	Spray Pump	171
RapidFlow - Pressure Delivery Schematic	106	Flow Meter & Controller.	173
RapidFlow - Rinsing Schematic.	107	Chemical Probe	175
Flushing.	108	Spray Nozzles	175
Pressure Filter Cleaning	109	TriTech Boom	176
Decontamination.	109	Plumbing	177
End of Day	110	Induction Hopper	177
End of Program	110	Brakes	177
		Hydraulic & Pneumatic.	177
9 BOOM	111	Air Conditioning	178
General.	111		
Boom Overview - 36-42 m	112	12 OPTIONAL ACCESSORIES	179
Boom Overview - 48 m	114	General Information	179
Boom Features.	116	Chemical Induction Probe	180
Boom Options	118	Chemical Transfer Pump	182
Boom Adjustment - 36-42 m	120	Flow Meter - FM-I 100.	183
Boom Adjustment - 48 m	132	Flow Meter & Pump - Troubleshooting	186
Three Dimensional Breakaway - 36-48 m	137	Hydraulic Fill Pump.	187
Centre Level Adjustment 36-48m	138	Fill Flow Meter - 70 Series	188
		Groeneveld Auto Greaser	192
10 LUBRICATION & MAINTENANCE	139	Groeneveld Auto Greaser - Overview I.	193
Recommended Lubricants	139	Groeneveld Auto Greaser - Overview II	194
Filters.	140	Groeneveld Auto Greaser - Components.	195
Replacement Globes.	140	Groeneveld Auto Greaser - Pump Unit	202
Headlight Adjustment	140	Groeneveld Auto Greaser - Meter Units	204
Wheels.	141	Groeneveld Auto Greaser - Meter Unit Operation	205
Suspension	142	Groeneveld Auto Greaser - Electronic Timer	207
Steering.	144	Groeneveld Auto Greaser - Maintenance & Testing	208
Pneumatic System	145	Groeneveld Auto Greaser - Warnings Summary	210
Braking System	146	Groeneveld Auto Greaser - Technical Data	211
Transmission	148	Groeneveld Auto Greaser - Troubleshooting	212
Driveline	148	Groeneveld Auto Greaser - Dealer Contacts	213
Transfer Case.	150		
Hydraulics - General	151		
Hydraulics - 36-42m	154		
Hydraulics - 48m.	157		
Engine	159		
Cabin Air Cleaner	161		

Chapter I

INTRODUCTION

Welcome

Congratulations on your purchase of a Goldacres sprayer. For more than a quarter of a century Goldacres has supplied Australian farmers with quality, innovative and technologically advanced spraying solutions - equipment designed in Australia for Australian conditions.

Goldacres not only produce Australia's finest range of spraying equipment - we also keenly value the unique relationship we enjoy with owners of our equipment. We are pleased to welcome you as a Goldacres owner and look forward to making your spray applications as efficient as possible.

Please use this comprehensive resource to gain a full understanding of your equipment, and don't hesitate to contact your Goldacres Dealer or Goldacres for further information.

A handwritten signature in blue ink, appearing to read 'Roger Richards', is positioned above the printed name and title.

Roger Richards
General Manager

GOLDACRES - RESELLER TERMS AND CONDITIONS OF SALE

Goldacres Goods are only available for purchase upon the terms and conditions set out below.

Interpretation

1. In terms and conditions:
 - (1) "Goldacres" means Goldacres Trading Pty. Ltd. A.C.N. 061 306 732 trading as Goldacres Agricultural Equipment (its successors and assigns) which is the seller of the Goods;
 - (2) "Purchaser" means the purchaser of the Goods;
 - (3) "Goods" means the products and, if any, the services sold or provided by Goldacres to the Purchaser;
 - (4) "GST Act" and "GST" are given the meanings referred to in a New Tax System (Goods and Services Tax) Act 1999.
 - (5) "PPSA" means the Personal Property Securities Act 2009 (Cth) (as amended);
 - (6) Nothing in these terms and conditions shall be read or applied so as to exclude, restrict or modify or have the effect of excluding, restricting or modifying, any condition, warranty, guarantee, right or remedy implied by law (including the Competition and Consumer Act 2010) and which by law cannot be excluded, restricted or modified.

General

2. (1) The Goods and all other products or services provided by Goldacres are provided subject to these terms and conditions. These terms and conditions and any terms and conditions incorporated herein by virtue of clause 3 hereto shall prevail over all other terms and conditions of the Purchaser or otherwise to the extent of any inconsistency.
 - (2) These terms and conditions may not be modified or amended without the expressed written consent of Goldacres endorsed by the Managing Director of Goldacres Trading P/L.

Additional Terms and Conditions

3. From time to time Goldacres may provide additional or extended warranties in respect of certain goods and/or services. Where such additional or extended warranties are provided to a Purchaser in writing they will be incorporated into these terms and conditions provided that in the event of any inconsistency between these terms and conditions and the terms of any additional or extended warranty, the provisions of the additional or extended warranty shall prevail.

Goldacres quotations.

4. Unless previously withdrawn, Goldacres quotations are open for acceptance within the period stated therein or, when no period is stated, within 14 days only of the quotation date. Goldacres reserves the right to refuse any order based on any quotation within 7 days of receipt of the order.

Packing

5. The cost of any special packing and packing materials used in relation to the Goods shall be at the Purchaser's expense notwithstanding that such cost may have been omitted from any quotation.

Shortage

6. The Purchaser waives any claim for shortage of any Goods delivered if a claim in respect thereof has not been lodged with Goldacres within (7) seven days from the date of receipt of the Goods by the Purchaser.

Specifications, etc: Catalogues, etc: Quotations

7. All specifications, (including but not limited to: drawings, particulars of weights, volumes, capacities, dimensions, load factors) are approximate only and any deviation shall not be taken to vitiate any contract with Goldacres or form any claim against Goldacres. The descriptions, illustrations, and performances contained in catalogues, price lists and other advertising matter do not form part of the contract of sale of the Goods. Where specifications, drawings or other particulars are supplied by the Purchaser, Goldacres' price is made on estimates of quantities required. Should there be any adjustments in quantities above or below the quantities estimated by Goldacres and set out in a quotation, then any such increase or decrease shall be adjusted on a unit rate basis according to unit prices set out in the quotation.

Performance, Capacities, Chemicals, Liquids, Application Methods, Environmental Effects

8. Any performance, volumes, and/or capacity figures given by Goldacres are estimates only. Goldacres shall be under no liability for damages for failure to obtain such figures unless specifically guaranteed in writing and any such written guarantee shall be subject to the recognised tolerances applicable to such figures. The suitability of chemicals and other liquids for any application and the application methods and the environmental effects shall be the sole decision and responsibility of the Purchaser and the user of the Goods. Goldacres gives no warranty as to the suitability of any chemicals or other liquids for any application, nor the application methods nor the environmental effects, which may result from the use of the Goods. Goldacres shall be under no liability for damages arising out of the use of any chemicals, liquids, or mixtures in the Goods nor for any application, nor for the application methods nor for the environmental effects, which may result from the use of the Goods.

Delivery/Service Times

9. The delivery times and service times made known to the Purchaser are estimates only and Goldacres shall not be liable for late delivery, non-delivery or delay and under no circumstances shall Goldacres be liable for any loss, damage or delay occasioned by the Purchaser or its customers arising from the late or non-delivery or late installation of the Goods.

Loss or damage in transit

10. Goldacres is not responsible for any loss or damage to Goods in transit. Goldacres shall render the Purchaser such assistance as may be necessary to press claims on carriers provided that the Purchaser shall have notified Goldacres and the carriers immediately the loss or damage is discovered on receipt of Goods and shall lodge a claim on the carrier within three days of the date of receipt of the Goods. Insurance of Goods in transit is the responsibility of the Purchaser.

Limit of Liability

11. (1) Goldacres liability for Goods manufactured by it is limited to:
 - (a) where the law implies consumer guarantees into these terms and conditions pursuant to Part 3.2 Division 1 of Schedule 2 to the Competition and Consumer Act 2010 ("Cth") ("consumer guarantees") which cannot be excluded and Goldacres breaches a consumer guarantee, the loss and damage the Purchaser is entitled to at law which cannot be excluded by these terms and conditions; and, in all other cases
 - (i) making good any defects by repairing the same or at Goldacres option by replacement within a period not exceeding either 1000 hours or twelve calendar months, whichever comes first, after the Goods have been dispatched provided that:
 - (i) the defects have arisen solely from faulty materials or workmanship;
 - (ii) the Goods have not received mistreatment, intention or interference;
 - (iii) accessories of any kind used by the Purchaser are manufactured or approved by Goldacres;
 - (iv) where applicable, the seals on the Goods remain unbroken;
 - (v) there has been no improper adjustment, calibration or operation;
 - (vi) the use of accessories including consumables, hardware or software (not manufactured by Goldacres) has been approved in writing by Goldacres;
 - (vii) no contamination or leakage has been caused or induced;
 - (viii) any modification to the Goods have been authorised in writing by Goldacres;
 - (ix) there has been no inadequate or incorrect use, storage, handling or application of the Goods;
 - (x) there has been no use or operation of the Goods outside of the physical, electrical or environmental specifications of the Goods;
 - (xi) there has been no inadequate or incorrect site preparations;
 - (xii) there has been no inadequate or improper maintenance of the Goods;
 - (xiii) it has not been caused by fair wear and tear; and
 - (xiv) firstly the Goods have been thoroughly inspected and any damage (from whatever cause) to the Goods (and in particular – the structure, welding, seams, bolts, booms) has been repaired prior to the Goods being operated, used driven or moved and on each occasion the tanks are filled; and
 - (xv) there has been no failure to comply with the requirements of all present or future laws or regulations relating to the Goods and/or the use and/or the operation of the Goods; and
 - (xvi) there has been no failure to maintain a record of hours of operation (which record shall contain full details of all inspections, repairs and maintenance) and produce same to Goldacres at the time of the claim;
 - (xvii) the defective Goods or any damaged part of the Goods are promptly returned free of cost to Goldacres or a representative of Goldacres;
 - (xviii) all warranty related repairs have been carried out with the prior authorisation of Goldacres;
 - (b) If Goods or any part thereof are not manufactured by Goldacres, in particular engines, engine accessories, transmissions, transfer cases, differentials, tyres, tubes, batteries, radios and UHF's, the guarantee of the manufacturer thereof shall be accepted by the Purchaser and is the only guarantee given to the Purchaser in respect of the Goods or that part provided always that this clause does not seek to exclude the consumer guarantees;
 - (3) In the case of hydraulic systems, Goldacres shall replace defective parts in accordance with clause 11(1) of these conditions, provided that the failure of the part was not related to contamination within the system, Goldacres shall not be liable for labour in the case of repairing hydraulic system defects;
 - (4) Goldacres will not accept liability for damage attributed to fair wear and tear including but not limited to fair wear and tear to nozzles, chains, belts, filters, brake pads, polyethylene bushes and liquid pump valves, valve O-rings, diaphragms and seals;
 - (5) Goldacres shall not be liable for and the Purchaser releases Goldacres from any claims in respect of faulty or defective design of any Goods supplied unless such a design has been wholly prepared by Goldacres and the responsibility for any claim has been specifically accepted by Goldacres in writing and in any event Goldacres liability hereunder shall be strictly limited to the replacement of defective parts in accordance with paragraph 11(1) of these conditions provided always that this clause does not seek to exclude the consumer guarantees;
 - (6) Except as provided herein, all express and implied warranties, guarantees and conditions under statute or general law as to the merchantability, description, quality, suitability or fitness of the Goods for any purpose or as to design, assembly, installation, materials or workmanship or otherwise are hereby expressly excluded and Goldacres shall not be liable for physical or financial injury, loss or damage or for consequential loss or damage of any kind arising out of the supply, layout, assembly, installation or operation of the Goods or arising out of Goldacres negligence or in any other way whatsoever;
 - (7) The benefit of any warranty provided under these terms and conditions shall only be available to the Purchaser and shall not be transferable by the Purchaser;
 - (8) The warranties provided under these terms and conditions do not extend to second hand or used Goods that may be sold by Goldacres.
12. Goldacres liability for breach of a consumer guarantee is hereby limited (in the case of goods and services not used for personal, domestic or household purposes) to:
 - (1) in the case of Goods, any one or more of the following:
 - (a) the replacement of the Goods or the supply of equivalent Goods;
 - (b) the repair of the Goods;
 - (c) the payment of the cost of replacing the Goods or acquiring the equivalent Goods;
 - (d) the payment of having the Goods repaired; or
 - (2) in the case of services;
 - (a) the supplying of the services again; or
 - (b) the payment of the cost of having the services supplied again.

Prices

13. (1) Unless otherwise stated in writing by Goldacres, all prices quoted by Goldacres are inclusive of GST for supplies within Australia and exclusive of GST for exports outside of Australia. Prices quoted are those ruling at the time of quotation or the date the price is given and are based on rates of freight, insurance, customs, duties, taxes, exchange, shipping expenses, sorting and stacking charges, cartage, cost of materials and other charges affecting the cost of production ruling on that date and any alterations thereto either before acceptance of or during currency of the contract shall be to the Purchaser's account.
 - (2) For the purpose of 38-185 of the GST Act, the day upon which the seller gives the invoice for the supply shall be the date of the invoice.

Payment

14. (1) The purchase price in relation to the Goods and the cost of the service shall be payable without deduction and or set off and payment thereof shall be made on or before the thirteenth day of the month following the delivery of the Goods or performance of the

services unless other terms of payment are expressly stated in writing.

- (2) A decreasing or increasing adjustment and or the issuing of an adjustment note, pursuant to Division 21 and Division 29-C of the GST Act, shall not, in any way, constitute a release, waiver, or forgiveness of the debt incurred by the Purchaser.

Interest on overdue payments

15. If Goldacres is not paid for any Goods or services on the due date specified in this agreement without prejudice to any other right or remedy, all outstanding money shall bear interest at the rate set, pursuant to the Penalty Interest Rates Act, Victoria, 1986, as such money, together with interest shall be recoverable forthwith from the Purchaser.

Rights in relation to Goods.

16. (1) Title to the Goods supplied by Goldacres to the Purchaser shall remain with Goldacres until the total amount due in respect of the Goods and all monies owing to Goldacres have been paid in full (the "Debts"). Risk in the Goods shall pass to the Purchaser upon delivery.
 - (2) The Purchaser shall have the right to resell Goods but only as fiduciary agent and trustee for Goldacres by way of bona fide sale at full market value and in the ordinary course of its business.
 - (3) Until all the Debts have been paid in full:
 - (a) the Purchaser shall take custody of the Goods as trustee, fiduciary agent and bailee for Goldacres;
 - (b) the Purchaser shall keep the Goods separate from any other goods and properly marked, stored, protected and insured;
 - (c) the Purchaser must hold all of the money it receives ("Proceeds");
 - (i) from the sale of any property into which Goods supplied have been incorporated; and
 - (ii) from the sale of Goods or provision of services including the Goods supplied by the Goldacres as bailee, fiduciary agent and trustee for Goldacres; but the Purchaser need not hold on trust any money exceeding the amount of the Debts at the time the money is received.
 - (d) The Purchaser expressly acknowledges that it is bound by the fiduciary obligation created in the preceding paragraph and acknowledges that:
 - (i) it must hold the Proceeds on trust for Goldacres;
 - (ii) it must place the whole of the Proceeds in an account separate from its own moneys (the "Proceeds Account");
 - (iii) it must maintain the Proceeds Account separate from its own moneys at all times.
 - (iv) it must maintain proper records for the Proceeds Account.
 - (v) it must not assign or encumber any book debts arising from sales made in circumstances set out in clauses 16(c)(i) and (ii) or do any other act in derogation of Goldacres' legal or beneficial interests; and
 - (vi) it must account to Goldacres on demand for all moneys standing to the credit of such account.
 - (e) For the purposes of identification of different consignments of Goods purchased from Goldacres and receipt of Proceeds, the Purchaser agrees that the principle of "Last In, First Out" shall be applied to any items that cannot be distinguished.
 - (f) Goldacres may trace the Proceeds in equity.
 - (g) Goldacres may at any time, without notice to the Purchaser and without prejudice to any other rights which it may have against the Purchaser, terminate any contract connected with the Goods and the baillment referred to in clause 16(3) and enter upon any premises owned or occupied by the Purchaser where Goldacres reasonably believes the Goods may be stored, and repossess the Goods without liability for any damaged caused, and subsequently dispose of the Goods at Goldacres' discretion if:
 - (a) the Debts are not paid in accordance with these terms and conditions or any other contract or arrangement between Goldacres and the Purchaser; or
 - (b) Goldacres receives notice of or reasonably believes that:
 - (i) a third person may attempt to levy execution against the Goods; or
 - (ii) the Purchaser is insolvent (within the meaning of the Corporations Act 2001) or bankrupt; or
 - (iii) the Purchaser has entered into any arrangement or composition with its creditors, gone into liquidation, or has appointed a receiver, a receiver and manager or administrator.
 - (5) If after repossession under clause 16(4) Goldacres sells the Goods, Goldacres shall account to the Purchaser for any proceeds of sale (less expenses of repossession and sale) that exceeds the amount of the outstanding Debts.
 - (6) If any Goods belonging to Goldacres are disposed of by the Purchaser or an insurance claim is made in respect of them, Goldacres shall be entitled to trace the sale or insurance proceeds, which proceeds shall be held by the Purchaser in a separate bank account on trust for Goldacres.
 - (7) The Purchaser agrees and acknowledges that in the event it sells Goods to a third party on account, it will include in its terms and conditions of sale a provision under which the Purchaser retains title to the Goods until such time that the total amount due in respect of the Goods and all monies owing to the Purchaser have been paid in full by that third party debtor. The Purchaser also agrees and acknowledges that in these instances, it will register its PMSI in accordance with the PPSA in respect of its security interest in the Goods.

PPSA provisions

17. (1) The Purchaser acknowledges that these terms and conditions constitute a security agreement for the purposes of section 20 of the PPSA and that a security interest exists in all Goods (and any associated Proceeds from their sale) previously supplied by Goldacres to the Purchaser (if any) and in all in future Goods (and any associated Proceeds from their sale) that may be supplied to the Purchaser by Goldacres.
 - (2) The Purchaser acknowledges that Goldacres has a first ranking purchase money security interest ("PMSI") (as defined in section 14 of the PPSA) in the Goods and the Purchaser must not jeopardise such ranking (whether by act or omission).
 - (3) The Purchaser acknowledges that it has received value as at the date of first delivery of the Goods and has not agreed to postpone the time for attachment of the security interest (as defined in the PPSA) granted to Goldacres under these terms and conditions.
 - (4) The Purchaser will execute documents and do such further acts as may be required by Goldacres to register the security interest granted to Goldacres under these terms and conditions under the PPSA.
 - (5) Until ownership of the Goods passes, the Purchaser must not give to Goldacres a written demand or allow any other person to give Goldacres a written demand requiring Goldacres to register a financing change statement under the PPSA in respect of Goldacres' interest in the Goods.
 - (6) The Purchaser must indemnify Goldacres and on demand reimburse Goldacres for all costs and expenses incurred by Goldacres in respect of these terms and conditions including but not limited to Goldacres registering its security interest in the Goods, lodging, discharging or amending any financing statement, or financing change statement, or otherwise complying with the PPSA.
 - (7) The Purchaser agrees (other than as provided in these terms and conditions) not to sell, lease, mortgage, deal with, dispose of or create or attempt to create any other security interest in or affecting the Goods unless and until the Purchaser's Debts have been satisfied.
 - (8) The Purchaser waives its rights under the following provisions of Chapter 4 of the PPSA:
 - (a) to receive a notice on enforcement action against liquid assets (section 121(4));
 - (b) to receive a notice to seize collateral (section 123);
 - (c) to receive a notice of disposal of Goods by Goldacres purchasing the Goods (section 129);
 - (d) to receive a notice to dispose of Goods (section 130);
 - (e) to receive a statement of account following disposal of Goods (section 132(2));
 - (f) to receive a statement of account if no disposal of Goods for each 6 month period (section 132(4));
 - (g) to receive notice of any proposal of Goldacres to retain Goods (section 135(2));
 - (h) to object to any proposal of Goldacres to either retain or dispose of Goods (section 137(2));
 - (i) to redeem the Goods (section 142);
 - (j) to reinstate the security agreement (section 143);
 - (k) to receive a notice of any verification statement (section 157(1)) and section 157(3);
 - (9) The rights Goldacres may have under the PPSA are supplementary and in addition to those set out in these terms and conditions and do not derogate from the rights and remedies of Goldacres under these terms and conditions or under any other statute or under general law.
 - (10) The Purchaser must give 10 business days prior written notice of any proposed change in the Purchaser's name or other identifying characteristics and details.

Purchasers property

18. Any property of the Purchaser under Goldacres' custody or control shall be entirely at the Purchaser's risk as regards loss or damage caused to the property or by it.

Storage

19. Goldacres reserves the right to make a reasonable charge for storage if delivery instructions are not provided by the Purchaser within (14) fourteen days of a request by Goldacres for such information.

Returned Goods

20. Goldacres shall not be under any obligation to accept Goods returned by the Purchaser and will do so only on terms to be agreed in writing in each individual case.

Goods sold

21. All Goods to be supplied by Goldacres shall be described on the purchase order agreed by Goldacres and the Purchaser and the description on such purchase order modified as so agreed shall prevail over other descriptions including any Purchaser's specification or enquiry.

Cancellation

22. No order may be cancelled except with the consent in writing and on terms, which will indemnify Goldacres against all losses.

No waiver

23. The failure of any party to enforce the provisions of these terms and conditions or to exercise any rights expressed in these terms and conditions shall not be a waiver of such provisions or rights and shall not affect the enforcement of this agreement. The exercise by any party of any of its rights expressed in this agreement shall not preclude or prejudice such party from exercising the same or any other rights it may have irrespective of any previous action taken by that party.

Force Majeure

24. If by reason of any fact, circumstance, matter or thing beyond the reasonable control of Goldacres is unable to perform in whole or in part any obligation under these terms and conditions then Goldacres shall be relieved of that obligation under these terms and conditions to the extent and for the period that it is so unable to perform and shall not be liable to the Purchaser in respect of such inability.

Passing of risk

25. Risk in the Goods shall pass to the Purchaser upon delivery of the Goods to the Purchaser or collection of the Goods by the Purchaser's agent or carrier as the case may be.

Exclusion of liability

26. To the extent permitted by law Goldacres shall not be liable to the Purchaser in contract or in tort arising out of, or in connection with, or relating to, the performance of the Goods or any breach of these conditions or any fact, matter or thing relating to the Goods or error (whether or not it is negligent or a breach of contract) in information supplied to the Purchaser or a user before or after the date of the Purchaser's or user's use of the Goods and Goldacres shall be under no liability for damages arising out of the use of any chemicals, liquids, or mixtures in the Goods, nor for any application, nor for the application methods nor for the environmental effects, which may result therefrom or from the use of the Goods.

Exclusion of representations and arrangements

27. To the extent permitted by law the terms and conditions supersede and exclude all prior and other discussions, representations (contractual or otherwise) and arrangements relating to the supply of the Goods or any part thereof including, but without limiting the generality of the foregoing, those relating to the performance of the Goods or any part thereof or the results that ought to be expected from using the Goods.

Place of contract

28. The contract for sale of the Goods and the provision of the services is made in the State of Victoria and the Purchaser agrees to submit all disputes arising with Goldacres to the courts of such State and any court competent to hear appeals therefrom.

Chapter 2

SAFETY

Safety Information

General

The following pages outline important safety information. At Goldacres safety is a high priority. These safety and warning instructions **MUST** be followed to ensure the safe operation of your Goldacres equipment.

Explanation of key terms used in this operator's manual are:

DANGER - You will be killed or seriously hurt if you don't follow instructions

WARNING - You can be seriously hurt if you don't follow instructions

CAUTION - You can be hurt if you don't follow instructions

NOTE - Is used to notify people of installation, operation or maintenance information that is important but not hazard related.

The Operator

All operators of this equipment should be adequately trained in the safe operation of this equipment. It is important that all operators have read and fully understand the operator's manual prior to using this equipment.

All new operators should be trained in an area without bystanders or obstructions and become familiar with the sprayer prior to operation.

The machine is fitted with a roll-over protection structure incorporated into the frame of the cabin. To minimize the risk of injury in the event of an accident, the operator and anyone in the training seat must wear seat belts at all times.

Passengers

The machine is equipped with one training seat with a seatbelt. To minimize the risk of injury in the event of an accident, the operator and anyone in the training seat must wear seat belts at all times.

Any further passengers will not be protected by the roll-over protection system and must be kept off the machine.

Do not stand on or carry passengers on the steps or platform when the sprayer is in motion or when the booms are being folded or unfolded.

Warnings

- Always read and understand the operator's manual prior to operation of this equipment.
- It is the responsibility of the operator to ensure that there are no damaged or missing decals on the equipment and that any damaged or missing decals are replaced prior to operation.
- Goldacres equipment either ordered or operated outside the guideline limitations may not be warranted by Goldacres for successful performance. Operators working outside these limitations do so at their own risk, unless specific advice has been sought from, and provided by, Goldacres in writing.
- Inspect the equipment thoroughly for damage and wear before operation.
- Always read and follow the chemical manufacturer's guidelines for safe application as per the chemical label. Particular attention should be given to the recommended target application rate of the chemical being applied as per the chemical label.
- Goldacres equipment uses several materials that may be harmful to the environment. Potentially harmful waste used with Goldacres equipment includes such items as oil, fuel, coolant and batteries. If these items are disposed of incorrectly the waste can threaten the surrounding environment and ecology. The waste products can leech into surrounding water sources and contaminate the area.
- Certain chemicals may be unsuitable for use with Goldacres standard plumbing designs. Consult your Goldacres dealer if in doubt.
- Do not operate the equipment while under the influence of any drugs, alcohol or if excessively tired.
- Lubricate the equipment as per recommended requirements before operating.
- Make sure that the equipment complies with all relevant road regulations when transporting.
- Flush chemicals from equipment immediately after use.

Continued over page

Safety Information

- When draining fluids from the equipment use appropriate, leak proof containers. Do not use food or beverage containers because someone may consume the contents by mistake.
- Any unauthorised modifications to this equipment may affect its function and create a serious safety risk.
- Keep clear of overhead obstructions – especially power lines as contact can be fatal.
- Never attempt to clean parts, or nozzles, by blowing with mouth.
- Never attempt to siphon chemicals, or substances, by sucking.
- It is imperative that the vehicle manufacturer's specifications be checked and all instructions for use when transporting, or towing, be adhered to at all times.
- Care should be taken when transferring liquid into the tank to ensure that the gross weight of the equipment does not exceed the braking and carrying capacity of the vehicle as specified by the vehicle manufacturer.

NOTE: 1 Litre water = 1 Kg.

- Water weighs 1 kg per litre, however conversion factors must be used when spraying liquids that are heavier or lighter than water. Example: liquid nitrogen has a density of 1.28 kg/L and will therefore be significantly heavier than water if the tank is filled completely. The total weight of a tank full of chemical, should not exceed that of a full tank of water. Machine damage can result if the machine is over weight. See filling instructions in Chapter 8 'Operation' for more information.
- Suitable care should be taken when driving the vehicle. Consideration should be given to both the carrying capacity of the vehicle and the gradient of the terrain when determining the speed at which the vehicle can be driven safely.
- Ensure that the maximum speed of the vehicle, when loaded, is within the vehicle manufacturer's limitations.
- Ensure equipment is securely fastened or attached to vehicle at all times.
- Never stand within the radius of the boom wings.
- Never work under any hydraulically raised boom.

Cautions

- When leaving the sprayer always isolate the batteries by turning the isolator key off and removing it.

- A supply of fresh water should be with the equipment at all times.
- Water tanks are not designed for use with diesel fuel or any flammable liquid.
- Do not use this machine in ambient temperatures exceeding 40 degrees Celsius.
- Ensure that all bolts are tightened and secured before operation.
- Always ensure that the boom is securely supported when travelling.
- Where fitted, care should be taken to never overfill the diaphragm pump with oil or operate at speeds exceeding 540 rpm.
- Do not exceed the maximum spraying pressure of 8 Bar.

Dangers

- Check area to be sprayed for overhead powerlines. Contact between the machine and powerlines can result in serious injury or death. If there are powerlines in the spray area, exercise extreme caution when tilting boom wings.
- Do NOT walk on machine platform when near power lines.
- NEVER start the engine when standing on the ground. Only start the engine from the operator's seat, with the transmission in neutral. Possible injury or death can occur by starting the machine through other methods.
- Never exit the cabin while the machine is in motion.
- Diesel engine exhaust fumes are harmful and can cause severe sickness or death. If it is necessary to run the engine in an enclosed area use an exhaust pipe extension. If an exhaust pipe extension is unavailable ensure that all doors are fully open and the room is well ventilated.

Personal Protective Equipment (PPE)

Always wear close fitting clothing and appropriate safety equipment designed for the job at hand.

- Exposure to loud noise over an extended period can cause permanent hearing impairment or loss. Be active in the conservation of your hearing and wear appropriate hearing protection at all times.
- Chemicals can be harmful to humans, appropriate PPE should be used when handling chemicals.

Continued over page

Safety Information

CAUTION: Always refer to the chemical manufacturers label for guidelines on the appropriate PPE to use with the chemical/s you are using.

Goldacres also suggests that you read and understand the following Australian standards:

- Australian Standard for Chemical protective clothing AS3765.
- Australian Standard for Respiratory protection devices AS1715.

Poisons Information Centres - Call 131 126 (AU)

Cuts, Stabs & Punctures

When Servicing machine, be mindful of sharp edges on parts such as trimmed cable ties, hose clamps, cut reinforced hose and the edges of plates and brackets as they could cause cut, stab or puncture injuries.

Crush Hazard

Never attempt to maintain axles, wheels or components within the vicinity of the wheels with the engine running.

Pinch Hazard

When operating moving components such as the boom, access ladder, bonnet or other components, keep fingers and hands away from potential pinch points.

Burn Hazard

- Avoid contact around the entire exhaust system of the sprayer when at operating temperature
- Avoid contact around the hydraulic tank and all hydraulic lines when at operating temperature

Entanglement Hazard

Rotating drives can cause serious injury or even death when entanglement occurs. Keep hands, feet, hair and clothing away from all moving parts to prevent injury. Never operate this machine with covers, shrouds, or guards removed.

Stored Energy Hazard

Even when the machine is not running, energy can be stored in components such as hydraulic accumulators, air tanks, tyres, A/C hoses, springs and boom cables. Hydraulically supported components such as the boom center are also a source of stored energy. Before working on the machine, ensure that these parts are relieved of their energy in a safe manner.

Overhead Hazard

BOOM LIFT OR TILT AND RADIO ANTENNA COULD STRIKE POWER LINES. Keep clear of overhead obstructions – especially power lines as contact can be fatal.

Do NOT walk on machine platform when near power lines.

Airborne Particles

- Always stand well clear of equipment during operation.
- Any spray drift is dangerous and may be hazardous to humans and other animals.
- When heating and welding components, ensure that all paint and other such materials are removed. Often hazardous airborne particles and fumes are generated from welding and heating.

Fluids Under Pressure

Fluids escaping from high pressure lines can cause serious injury to skin. Hydraulic oil can easily penetrate human skin. This hazard can be avoided by relieving the pressure in the system.

Do not disconnect any hoses, nozzles or filters while equipment is operating. Disconnecting these components while under pressure may result in uncontrolled fluid discharge which may be hazardous.

Be mindful of the location of pressurised lines in the vicinity of the work area when using equipment such as grinders, oxy torches and welders. The two main risks are that this equipment may easily cut through the lines or the local heat generated near the lines may cause them to rupture.

Ensure that all fittings and lines are fully/tightly secured before re-pressurizing after repairs.

Norac System

If Norac height control system is fitted, keep clear of the boom as it could potentially move without notice.

Cooling System

- At operating temperature the fluids in the cooling system are under pressure. Only remove the radiator cap when the engine is turned off and has cooled down.
- Loosen the radiator cap slowly to relieve the pressure before removing the cap completely.
- Coolant can be added when the engine is cool and turned off.

Batteries

The machine is supplied with sealed, non-serviceable batteries. The battery electrolyte contains sulfuric acid; this is a highly dangerous liquid and should be handled with the greatest degree of care.

Continued over page

Safety Information

The acid can cause blindness, burn skin and dissolve clothing. Batteries also produce flammable hydrogen gas (especially when charging), so keep them separated from any sources of sparks and flames.

A vigilant operator can avoid these hazards by:

1. Wearing the correct personal protective equipment.
2. Avoid spilling or dripping electrolyte.
3. Place into a plastic collection tray ready for disposal if the case is found to be damaged.

EMERGENCY MEASURES

- If the electrolyte gets in your eyes, flush your eyes with clean water for at least 15 minutes, then get immediate medical assistance.
- Also thoroughly wash all other affected areas on your body with water and remove all clothing.
- If you swallow any electrolyte seek medical attention immediately.

Lifting Machine

Before raising the machine off the ground:

- ✓ Ensure that the boom is in its closed position.
- ✓ Park on a flat level, firm area and engage the park brake.
- ✓ Empty the spray tank where possible.
- ✓ Chock all wheels that remain on the ground.
- ✓ Securely lift the machine using a jack and support the machine on work stands.
- ✗ Do not work under the machine when supported solely by a jack.
- ✗ Do not support the sprayer using materials that may crumble.

Changing Wheels & Tyres

An experienced person with the correct equipment should mount the wheels on the sprayer.

When changing a wheel on the sprayer ensure that the sprayer is on firm level ground and the wheels are chocked.

Tyre Maintenance

Maintain correct tyre pressure at all times. Inflation of tyres above or below the recommended pressure exerts additional pressure on the tyre, which may result in tyre damage.

Extreme caution is required during the inflation of tyres. If the tyre is inflated at a rapid rate separation and/or explosion of the rim can occur. This event can inflict serious or fatal injuries to the operator.

- ✓ Always use a tyre inflation gauge.
- ✓ Be proactive and continually check the condition of your tyres.

- ✗ Do not weld, heat or modify the rim.

Machine Operation

- High speed turning places severe stresses on the wheels and axles and should be avoided. It is essential to observe the effects of turning on the open spray boom. Excessive turning speeds transmit great stresses to the spray boom and WILL CAUSE boom damage.
- Modification of the machine to increase maximum speed is STRICTLY PROHIBITED. This machine is designed for a maximum speed of 50 km/h. This speed must only be used on suitable terrain conditions. All components i.e. tyres, brakes, suspension, steering and chassis are designed and built to this maximum speed.
- MAXIMUM SPEED WHEN CORNERING, TURNING AT AN ANGLE GREATER THAN 45° OR DRIVING ON A SLOPE OR UNEVEN TERRAIN IS 5KM/H. When fitted with narrow wheel track and with high centre of gravity, the self-propelled sprayer may become unstable when turning at excessive speed or when operating on excessively steep terrain.
- Before leaving the sprayer the engine must be shut off, the transmission placed in neutral and the park brake engaged. NEVER ENGAGE THE PARK BRAKE WHILE THE SPRAYER IS MOVING. DAMAGE TO THE TRANSMISSION MAY RESULT.

Refuelling

- Handle fuel with extreme caution. Do not refuel the machine while smoking or near open flames or sparks.
- Always stop the engine before refueling the machine.
- To prevent fires always keep the machine clean of grease, debris and dirt.
- Do not use current emitting devices when refuelling.

Collision Prevention & Warning Lights

- Before operating the machine check with the relevant road management authorities for information regarding safe and legal transport on public roads in the state where the machine is being operated.
- To assist in the prevention of collisions with other road users the Goldacres sprayers are fitted with warning lights and signs in accordance with national road regulations.

Continued over page

Safety Information

- The machine is fitted with a reverse warning beeper when the machine is put into reverse.
- The machine can only be driven on public roads during daylight hours.
- Keep lighting and signs in good order and replace any damaged or faulty fixtures.

Working at Heights

Please contact your local government on the restrictions and safety requirements needed to operate at heights.

- There is a risk a falling if a person has “climbed” onto the machine.
- Do not “climb” on machine to get access.
- Use ladder or work platform to get access to parts or areas of the machine above local government restrictions.

Slippery Surfaces

- The surface of the platform has raised portions to stop slipping.
- The platform surface needs to be kept clean of mud and other material to help stop slipping.

Main Tank

- Danger - Confined space do not enter.
- Do not enter the tank for any purpose.

Safe Chemical Usage

The safe use of Agricultural (Ag) chemicals with this equipment is the responsibility of the owner/operators. All operators should be trained in the safe use of Ag chemicals. Goldacres suggest that a relevant course is completed by owners/operators prior to operation of this equipment as a spray unit.

Safety Decals

Understanding safety decals and their purpose assists in the safe operation of your sprayer. Safety decals are there for your protection and it is the responsibility of the owner operator to replace damaged and/or missing safety decals.

Regularly review safety decals with operators. It is very important to ensure that all new machine components and replacement parts include current hazard identification decals.

Replacement safety decals can be ordered from your Goldacres dealer. Part numbers and descriptions of the decals on this machine can be found in the parts manual supplied.

First Aid Kit

It is recommended that a first aid kit be added to your machine.

Fire Extinguisher

A fire extinguisher is fitted under the training seat in the cabin of your machine.

It is a dry chemical ABE type fire extinguisher approved for wood, paper, flammable liquid and live electrical equipment fires.

Machine Recovery

- The mechanical drive system delivers efficient, positive power to the ground for superior traction. However, should your machine become bogged and the wheels subsequently locked, do not engage first gear and maximise engine revs. With the wheel 'locked' in a bog situation, transmitting full power WILL DAMAGE the driveline.
- Goldacres recommends that bog situations are addressed prudently by using the assistance of a tow vehicle. Doing otherwise can cause significant driveline damage and VOID WARRANTY.


Towing & Transporting Sprayer

- A disabled sprayer is best transported on a drop deck trailer. Use chains to secure the sprayer via the tie down attachment point located under the front and rear axles.
- The machine must not be towed unless the engine is running (as the steering and brakes require engine power to operate). Before towing, the front & rear tail shaft should be disconnected due to the risk of damage to the transmission. While towing do not travel at a speed greater than 10 Km/h.
- An operator must steer and brake the sprayer under tow.
- The park brake needs to be manually released if engine is not able to run.
- Check the wheel nut tension on a regular basis. The torque and inspection frequency is outlined in the maintenance section.
- Brake performance should be checked regularly. The inspection frequency is outlined in the maintenance section.

Chapter 3

GENERAL INFORMATION & SPECIFICATIONS

Machine Orientation



General

Chassis

The chassis is an all steel construction, that is fully welded for superior strength. The chassis is grit blasted, primed and then protected by the Goldacres paint process for excellent chemical resistance and durability.

Paint Codes

Wheels: N23 Neutral Grey
Steel work: G13 Dark Green
Steel work: N61 Black
Australian Standards AS2700

Tank

All tanks are constructed from UV resistant polyethylene. Polyethylene tanks have a very high chemical resistance. Due to the rotational moulding process, there can be variance in the overall dimensions of the tank which in turn results in 5-10% variation in the tank capacity. For this reason, calibration markings should be used as a guide only.

Cabin

The cabin features panoramic views surrounding the sprayer and is customised to suit spraying applications. The rate controller and all key spraying functions are within easy reach of the operator. Further information on the cabin can be found in Chapter 4 'Cabin'.

Agitation

The Supermix agitator is located at the back of the tank and is used to generate increased agitation within the tank. The pressure line to the Supermix agitator from the control manifold passes through a nozzle and then through the barrel into the tank. This causes extra agitation as flow around the agitator is sucked into the barrel and is then passed back into the tank. To increase this venturi effect, the bypass flow from the electric regulating valve also passes through the barrel, multiplying the agitation effect. The Supermix agitator has an approximate capacity of 300 - 1300 L/min depending of the pump size and operating pressure. For further information refer to Chapter 10 'Lubrication & Maintenance'.

Boom Nozzle Control

Motorised boom valves for control of boom section on/off function are fitted as standard. These are mounted on the boom centre section at the rear of the sprayer. The number fitted is dependent on the number of boom sections and number of boom lines.

Controller

These sprayers are supplied with either a Raven SCS4400 automatic rate controller or an ISOBUS connector.

Continued over page

General

Automatic rate controllers will maintain a user defined application rate automatically as the vehicle speed changes. In order to function, the automatic rate controller relies on a flow meter, speed sensor and control valve. For specific information on the Raven controller please refer to Raven operator's manual supplied and Chapter 6 'Calibration' of this manual.

Filtration

Filtration is a critical part of the sprayer's performance.

As standard, these sprayers are fitted with:

- 1 x Suction filter (30 mesh)
- 2 x Pressure filters (1 x 80 & 1 x 100 mesh)
- Nozzle strainers (50 mesh)

Spray Pump

Fitted as standard on Goldacres equipment are Udor positive displacement and oil backed diaphragm pumps. The normal operating range is from 1 - 8 bar which is sufficient for efficient nozzle performance.

- Each individual boom section has a maximum delivery of 35 litres per minute with clean filters fitted.
- The maximum combined flow of all boom sections is limited to 140 litres per minute, or 50% of the pump flow, whichever is the lesser amount with clean filters.
- Where fitted, care should be taken to never overfill the diaphragm pump with oil or operate at speeds exceeding 540 rpm.
- Do not exceed the maximum spraying pressure of 8 Bar.

Chemical Induction

The method of chemical induction into your sprayer is dependent on the optional chemical induction equipment fitted to your sprayer.

Goldacres chemical induction equipment available includes:

- Chemical Probe
- Chemical Induction Hopper
- 12V Chemical Transfer Pumps

Booms

The machine can be fitted with a variety of boom sizes up to 48 metres in width. TriTech booms (24 - 48 m) feature hydraulic lift, fold and individual wing tilt controllable from the cabin.

Goldacres TriTech booms feature pitch, roll and yaw suspension in order to provide a superior boom ride

and assist in the efficient application of chemical to your target.

Nozzles

As information regarding nozzles is specific to those being used in your application, no specific reference is made to nozzle application rates or nozzle types in this operator's manual. Goldacres suggest the use of a current TeeJet or Lechler nozzle selection catalogue for reference to nozzle sizes, outputs, spray patterns and general spraying information. For more technical information on the function of spray nozzles and factors affecting their performance you can also use the TeeJet 'User's guide to spray nozzles'.

The TeeJet & Lechler nozzle selection catalogue and Users guides to spray nozzles are available from your Goldacres dealer, or as a free download from the TeeJet web site: www.teejet.com

Lechler web site: www.lechler.de

Machine Limitations

All Goldacres equipment is subject to operating limitations, it is the operator's responsibility to ensure that this equipment is being operated within these limitations and appropriately to the operating conditions at hand.

Goldacres do not endorse use of this machine for spraying at speeds greater than 20 km/hr and should not be used in ambient temperatures exceeding 40 degrees Celsius or below 5 degrees Celsius.

Do not travel at excessive speeds over rough terrain. The superior ride characteristics of this machine can disguise the impact of rough terrain on the driveline and suspension system of the machine. Stop the machine and inspect for damage after impact with gutters, sinkholes, rocks etc.

Violent speed change WILL CAUSE boom damage. The high power to weight ratio and braking capacity (especially when empty) enables very high acceleration and decelerations of the machine. It is important during accelerating and braking that the effect on the spray boom in the open position is taken into account.

The mechanical drive system delivers efficient, positive power to the ground for superior traction. However, should your machine become bogged and the wheels subsequently locked, do not engage first gear and maximise engine revs.

With the wheel 'locked' in a bog situation, transmitting full power WILL DAMAGE the driveline.

Continued over page

General

Goldacres recommends that bog situations are addressed prudently by using the assistance of a tow vehicle. Doing otherwise can cause significant driveline damage and VOID WARRANTY.

Custom Built Equipment

Where the owner of this sprayer has requested that custom built equipment or options be fitted to this sprayer it is necessary to understand that custom fabrication and engineering is subject to many variables. Goldacres cannot fully field test all custom built options prior to despatch, and owners of new sprayers fitted with custom built equipment or options need to understand that the functionality of these items may require refining in order to operate as desired.

Suspension

The machine is fitted with 5 link airbag axle suspension to provide excellent ride and comfort. Further information on the suspension can be found in Chapter 10 'Lubrication & Maintenance'.

Air Conditioning

The cabin is climate controlled and a carbon filter is installed to ensure operator safety.

Further information can be found in Chapter 4 'Cabin'.

Wheels & Tyres

Tyre pressures need to be checked regularly - check every 8 to 12 hours of operation.

There are many factors concerning the appropriate tyre pressure for a particular tyre and load. For example, the tyre size, rim type, tyre status (driven or free rolling), load, speed, haul length and ply rating all need to be considered when determining the tyre pressure.

Hydraulics

Electric over hydraulic valves are standard on these machines. The hydraulic functions are then controlled from electric switches in the cabin. The valve block is mounted on the boom centre section which is located at the rear of the sprayer.

Hand Wash Tank

A fresh water hand wash tank is located on the left hand side of the machine under the left hand access ladder. It has a bottle with a hand pump that can be filled with a liquid hand cleaner. The main tank can be filled with fresh water for operator use.

Ladder

The Ladder is to be used to access to the platform and cabin by the operator. Always face the ladder and retain three points of contact with the ladder at all times when ascending and descending. The ladder is only lifted to the raised position when the key is turned on and the handbrake is released. The operator must take care when operating the handbrake to ensure that no person is standing on or near the ladder at the time. In an emergency, the ladder can be lowered by either applying the park brake or turning off the ignition, or removing the air supply hose from the air cylinder.

NOTE: If a tyre is replaced with a different brand or size, please contact the supplier for correct air pressures to suit the load carrying capacity of this machine.

For further information on wheels and tyres please refer to Chapter 10 'Lubrication & Maintenance'.

GA8700354 MAX SPEED FULLY LOADED IS 25 KM/H		RECOMMENDED TYRE PRESSURE	
TYRE BRAND	TYRE SIZE	KPA	PSI
HARVEST	520/85R46 173A8/169D	240	35
AGRIMAX	520/85R46 158A8 (20.8 R46)	262	38

NOTE: PSI = Kpa x 0.145


EXAMPLE: 240 Kpa x 0.145 = 34.8 PSI

Dimensions

The following information is provided as a guide only. Variations in dimensions may occur without notification. To ensure that the dimensions are accurate for your sprayer it is recommended that you measure your sprayer individually.


NOTE: This sprayer is approximately 4.3 metres in height and with aerials on the roof, can be much

higher. Check the regulations in your state for maximum vehicle height restrictions. When driving on roads it may be necessary to remove aerials to meet the required height restrictions. Aerials on the roof may also need to be removed to meet clearance requirements for over head power lines, while on the road and also in some paddocks.



BOOM SIZE	A FRONT HEIGHT	B WIDTH	C TOTAL LENGTH	D WHEEL-BASE
36 m	4.30 m	3.50 m	9.85 m	4.45 m
42 m	4.30 m	3.50 m	10.40 m	4.45 m
48m	4.30 m	4.20 m	9.35 m	4.45 m

NOTE: Sprayer height is based on 520/85 R46 tyres fitted and with air bags deflated.



Identification & Parts Ordering

When ordering parts or requesting service information for your sprayer it is important to quote the serial number of your machine, and the purchase date, in order to receive accurate information. The location of the serial number plate on your machine is shown in the picture.

NOTE: To identify the exact options fitted to your particular machine, refer to the original quotation and/or build sheet. If needed, a copy of the build sheet may be obtained by contacting your dealer and quoting your machine serial number as described above.


When ordering parts from your Goldacres dealer, please quote:

- Machine serial number
- Part number required
- Part description
- Quantity required

The parts manual supplied with this machine includes all the relevant information that you need when ordering parts from your dealer. When returning parts to a Goldacres dealer for service or repair, all parts **MUST** be cleaned thoroughly before sending them. Dealers cannot expose technicians to the many potentially hazardous pesticides and substances that are in use.

NOTE: Please ensure that all parts are clearly labelled with the owner's details, and a brief description of the fault. Dealers are not liable for the return of any goods to a Goldacres Dealer. The goods must be returned to the point of sale.

Genuine Goldacres parts only should be used on Goldacres equipment.



ID plate located on the left hand chassis rail near steps.


Chapter 4

CABIN

Key Features



NO.	FEATURE
1.	Over Head Console
2.	Side Arm Rest Console
3.	Rear Corner Console
4.	Operators Seat
5.	Steering Wheel & Controls
6.	Training Seat
7.	Fire Extinguisher (Under Training Seat)
8.	Storage Area/Fridge - when optioned (Under Training Seat)
9.	Power Distribution Box
10.	Engine Monitor CAN
11.	Spray pressure gauge - other positions not used
12.	Storage Area (Under Operator's Seat)
13.	Operator Seat Belt
14.	Fridge Switch (When Fridge Optioned)
15.	Fold Out Cup Holder
16.	Fuel Gauge



NOTE: Training seat shown folded up.

Armrest Controls - Raven Controller - 36-42m




NO.	FEATURE
1.	Joystick control
2.	Rate controller
3.	Engine monitor CAN
4.	Transmission shifter
5.	Boom rest IN/OUT
6.	Boom fold IN/OUT
7.	Boom bi-fold IN/OUT
8.	Rinse tank/Main tank
9.	Cruise ON/OFF - RPM Raise ON
10.	Boom recirculation ON/OFF
11.	Spray pump ON/OFF
12.	GPS ON/OFF (if wired in)
13.	Diff lock - Centre ON/OFF
14.	Diff lock - Rear ON/OFF
15.	Park brake
16.	Fence line jet indicator

Armrest Controls - Raven Controller - 48m



NO.	FEATURE
1.	Joystick control
2.	Rate controller
3.	Engine monitor CAN
4.	Transmission shifter
5.	Boom fold 3 IN/OUT
6.	Boom fold 2 IN/OUT
7.	Boom fold 1 IN/OUT
8.	Boom catch CLOSE/OPEN
9.	Cruise ON/OFF - RPM Raise ON
10.	Boom recirculation ON/OFF
11.	Spray pump ON/OFF
12.	GPS ON/OFF (if wired in)
13.	Diff lock - Centre ON/OFF
14.	Diff lock - Rear ON/OFF
15.	Park brake
16.	Fence line jet indicator

Joystick Controls - Raven Controller



NO.	FEATURE
1.	Boom lift/lower - Fenceline Nozzle Left/Right
2.	GPS - Autosteer
3.	Boom tilt left/right
4.	Cruise cancel
5.	Cruise resume/increase
6.	Cruise set/decrease
7.	Dual tilt UP/DOWN (On reverse side, not shown)
8.	Spray master

Operator Seat



NO.	FEATURE	INSTRUCTIONS
1.	Fore / Aft Adjustment	By lifting this lever the seat can be slid backwards or forward to the desired position.
2.	Fore / Aft Locking lever	Release this lever to enable the Fore & Aft adjustment of the seat, and engage to lock the seat to the desired position.
3.	Seat Depth Adjustment	To adjust the depth of the seat cushion, pull the handle upwards. By moving the seat cushion backwards the desired seating position can be reached.
4.	Seat Pan Angle Adjustment	To adjust the angle of the seat pan, pull the handle upwards. By exerting pressure on or off the front or rear part of the seat pan it can be moved to the desired position.
5.	Height Adjustment	By lifting this lever air will be pumped in to the airbag suspension. By lowering this lever air is exhausted from the air bag.
6.	Tilt	The lever on the right hand side of the seat allows the back rest to be tilted forward or rearward. Pulling the lever forward releases the back rest so it can be repositioned.
7.	Arm Rest Adjust	By turning this knob the arm rest can be lowered or raised to suit.
8.	Lumbar	By turning this handle the lumbar in the back of the seat will increase or decrease the pressure on the operators back.
9.	Seat Belt	Operator lap seat belt must be fitted when ever the operator is seated in the cabin.


Steering Column



NO.	FEATURE	POSITION SETTING INSTRUCTIONS
1.	Steering Column Adjust	1. Hold the steering wheel with your hand 2. Press the lever at the rear end with your foot. With the lever pressed down, set the steering column to the desired position with your hand 3. Release lever The desired position is now locked.
2.	Tilting the Steering Column	1. Hold the steering wheel with your hand 2. Push lever to the top 3. With the lever pushed up, tilt the steering column to the desired position with your hand 4. Release lever The desired position is now locked.
3.	Steering Wheel Height Adjust	1. Hold the steering wheel with your hand 2. Turn lid a quarter of a turn anti-clockwise 3. Set the steering wheel to the desired position by hand 4. Turn lid a quarter of a turn clockwise The desired position is now locked.

Multifunction Switch


The multifunction switch is located on the left hand side of the steering column.



NO.	FEATURE
1.	Horn
2.	Windscreen wiper • 0 = Off • J = Intermittent • I = Constant
3.	Windscreen washer
4.	Right turn signal indicator
5.	Left turn signal indicator
6.	High beam/ Low beam/ Headlight flasher

Vehicle Information Unit

The vehicle information unit is located on the rear of the steering column, although other icons may be visible, only blinkers and high beam are used.




NO.	FEATURE
1.	Headlights high beam
2.	Left/right turn signal indicator

Overhead Components



NO.	FEATURE
1.	Air-conditioning
2.	Mirror Adjuster
3.	Lights
4.	AM/FM Radio/CD player
5.	UHF 2 Way Radio
6.	Hazard Lights
7.	Rotating Beacons

Air Conditioning



The automatic air conditioner regulates the temperature and humidity of the air in the cabin.

The following operating modes are available:

- Fully automatic

Ideal for high outside temperatures.

- Manual ventilation system

Automatic mode with manual fan speed setting.

- ECON

Automatic mode without cooling function.

- Drying the cab windows

Continuous compressor operation at maximum fan speed

Activating Automatic Air Conditioner

Switch the ignition on and start the engine.

After switching the ignition on, the software version appears in the display (1) for 3 seconds.

After that, the unit carries out a self-test which takes 20 seconds max. The keys are now enabled for operation.

The operating mode and the display will remember the same settings from the last time the machine was running.

In fully automatic mode the air conditioner compressor, heater and the ventilation are automatically controlled so that the pre-set cab temperature is achieved as quickly as possible and then kept constant.

This operating mode is ideal at high outside temperatures.

Activating fully automatic operation:

- Switch off cab windows drying (3), manual ventilation (8) and ECON (9) operating modes

The indicator lights (3), (8) and (9) are OFF.

Indicator light (2) lights up. Fully automatic mode is active.

At outside temperatures below 10°C, the automatic system shuts down the air conditioner compressor.

Activating Manual Fan

In manual fan operation, the heater and depending on the setting, the air conditioner compressor are automatically regulated to the pre-set set point. The fan speed can be set manually.

This offers the opportunity of setting a lower fan speed and slower temperature adaptation in case of large deviations between cab and outside temperature.

Activating the manual fan:

- Press button (8)

Indicator light (8) lights up. Manual venting is active.

Current fan speed is shown on the display (5). One bar represents a 10% speed increment between 0 and 100 %.

To reduce the fan speed:

- Press button (6) once per 10% speed decrease

To increase the fan speed:

- Press button (7) once per 10% speed increase

The changed setting is activated after 5 seconds.

Continued over page

Air Conditioning

Activating ECON Mode

In ECON mode, the air conditioner compressor is shut down. The heater and – depending on the setting – the ventilation are controlled automatically.

- Use this mode when cooling is not required

Activating the ECON mode

- Press button (9)

Indicator light (9) lights up. Indicator light (2) goes out. The ECON mode is active.

Drying Cab Windows

For drying the cab windows, the compressor is on constantly at maximum fan speed. The heater is set to the pre-set set value.

Drying the cab windows:

- Press button (3)

Indicator light (3) lights up. The drying mode is active. The fan is set to maximum speed.

To change the fan speed, see 'Activating Manual Fan'.

Setting Cab Temperature

The display (1) shows the currently set temperature. To decrease temperature:

- Press button (6)

To increase temperature:

- Press button (7)

Temperature may be adjusted in 1°C or 2°F increments depending on units selected (See 'Changing the temperature unit') per press of button.

The automatic air conditioner adjusts the cab temperature to the set value. During this process, the fan speed may rise quickly so that the cab temperature reaches the pre-set set point more quickly. Such as on a very hot day. When the cab temperature approaches the set value, the fan speed will be reduced again.

Switching Temperature Display

The temperature display can be switched between degrees Celcius and degrees Farenheit.

- Press buttons (4) and (6) simultaneously for up to 3 seconds to switch between unit modes

Repeating the above step will cycle between the two unit modes.

Displaying Outside Temperature

Press button (4). Indicator light (4) lights up. The display (1) shows the outside temperature.

Adjusting Air Conditioner Air Flow

The air flow is distributed inside the cab by fully adjustable nozzles. Each nozzle can be adjusted directionally or turned on/off to suit the individual needs of the user; e.g. to heat the leg area, close all upper vents and direct air flow from the lower vents to the floor.

AM/FM Radio

The entertainment radio is fitted to the panel in front of the operator on the roof. It consists of a radio tuner as well as single CD player. A Bluetooth compatible phone system is installed in the unit.

Operational instructions can be found in the entertainment radio manual supplied with this manual.

UHF Two Way Radio

There is a UHF two way radio mounted on the roof cavity near the entertainment radio. This radio is powered up through the electrical panel and has a fused circuit.

Operational instructions can be found in the UHF Two Way Radio manual supplied with this manual.

Map Light


The map light has two separate lights that can be operated together or individually.

The switch on the left turns the front map light on and off. This light is fixed and cannot be aimed.

The switch on the right operates the rear map light. This light is directional and can be aimed as desired.

NOTE: The map lights only operate when the ignition key is in the 'accessories' or 'run' position.

Lighting



ITEM	FEATURE	POSITION	FUNCTION
A	Headlights	0	Off
		1	Cab interior lights,Tail Lights, Outer Boom Marker lights.
		2 & 3	Headlights + All of the above ON
B	Front Work Lights Inner	0	OFF
		1,2 & 3	Inner front work lights ON
C	Front Work Lights Outer	0	OFF
		1,2 & 3	Outer front work lights ON
D	Rear Work Lights	0	OFF
		1,2 & 3	Rear work lights & Night Pro LED boom lights ON

NOTE: To cycle between high and low beam the steering column multi function stick is used.The headlights must be turned on overhead first.

NOTE: Front and rear work lights will not function unless the headlight switch is in position 1, 2 or 3.

Continued over page


Lighting

Egress Lighting

These machines are fitted with egress lighting to assist with safely exiting the machine when parking in dark conditions. There is a timed relay that will keep the outside work lights on for 30 seconds after the machine has been shut down and the key removed. The amount of time that the relay keeps the lights on for can be adjusted. It is found inside the main cabin fuse box area.



Above: Egress lighting timer relay location in main fuse box area.




Above: Timer relay potentiometer and dip switches.

By default, the timer potentiometer is set to 30 seconds (A). It has a range between 0 and 60 seconds. Turning it clockwise increases the timer. Turning it anti-clockwise decreases the timer.

The two dimples in the white adjuster indicate the direction it is pointing in.

The two dip switches are set to the OFF position by default (B). If a lighting time longer than 60 seconds (1 minute) is required, then dip switch 2 can be set to the ON position. On this setting, each increment on the potentiometer represents 1 minute, for a maximum of range of 1 to 60 minutes.

Rear Corner Console




NO.	FEATURE
1.	Ignition Key
2.	12V Sockets
3.	Aux USB Power Supply
4.	Park Brake/Low Air Warning Light with Audible Alarm
5.	Cigarette Lighter
6.	Carbon Filter Fan Switch
7.	Glass Breaking Hammer (Emergency use only)
8.	Engine/Transmission Diagnostic Connector
9.	Rinse tank / Main tank switch (48m only - Switch located on side console for other models)

Power Distribution Box

The power distribution box is located on the floor to the right of the operators seat. The box contains fuses and relays, to gain access to these the top cover needs to be removed. To do this, turn the




knobs on the top of the cover to undo the clips and then slide the cover forwards. The location of the fuses and relays are shown below.



Configuration of the main fuse box will depend on options selected.

If a Raven controller has been selected then all three cabin fuse boxes will be installed.

Power Distribution Box - Fuse Box Layouts



Autosteer System - Connectors

Inside the power distribution box are electrical connectors that have been provided for the connection of optional Autosteer equipment.

GPS REMOTE SWITCH MOMENTARY +12V

For the connection of the G-Motion GPS momentary switch from the joystick mounted on the side dash. When this single pin connector is connected to the ISOBUS based cabin harness it will be able to communicate directly with the John Deere Autosteer node. To make use of this button circuit for Trimble based Autosteer systems, it should be connected independently on the cabin harness and directly to the Trimble harness instead.


GPS REMOTE SWITCH

For the connection to an auto steer system. The cable has a 3 pin male weather pack plug for the customer to connect their Auto steer system. The switch is labelled Road mode/spray mode and is located on the side dash. When this 3 pin connector is connected to the ISOBUS based cabin harness it will be able to communicate directly with the John Deere Autosteer node. To make use of this button circuit for Trimble based Autosteer systems, it should be connected independently on the cabin harness and directly to the Trimble harness instead.


SEAT SAFETY SWITCH

The seat safety switch or operator presence switch causes the Autosteer system to turn off when the operator leaves their seat as a safety measure.


The harness part numbered GA3000147 incorporates a connector for the seat safety switch. This connector is able to communicate directly with the John Deere Autosteer node. This connector (male) on harness GA3000147 will be joined to the CLAAS cabin seat harness safety switch connector (female) when John Deere Autosteer is fitted. The seat safety switch can be optionally connected for Trimble based Autosteer systems. To do so, the seat connector should be joined directly to the Trimble harness and independently of harness GA3000147. This way the trimble node will be able to receive the signal from the seat safety switch.



Above: GPS resume - remote switch momentary +12V circuit.



Above: GPS master - remote switch circuit.



Above: Safety switch harness from back of CLAAS seat.

Continued over page

Autosteer System - Connectors



GPS RECEIVER CONNECTION POINTS

Inside the cabin roof on the left hand side, is one 12 pin connector and 2 coaxial connection points provided for roof mounted GPS receivers and antennas.



Above: GPS receiver connection points inside the cabin roof on the left hand side.

Pressure Gauges



NO.	FEATURE
1.	Not used
2.	Not used
3.	Spray Pressure
4.	Not used

CANtrak System



Understanding GEM

Generic Engine Monitor (GEM) software runs on a CANtrak display with five soft keys, providing a flexible and intuitive Human-Machine Interface (HMI). The 5 soft keys access a graphical menu structure that uses standard and easily-understood icons to indicate the key's current function. This enables the operator to select the required engine and transmission data and display it in the following formats:

- Analogue gauges
- Digital values
- Multi-gauge/data (a combination of above)
- Historical trend graphs
- Current or stored alarm messages

Additionally, various diagnostic screens are available, allowing detailed investigation of the engine and transmission data stream. By accessing the Configuration menu, users can customise some of the displayed data to show, for example, metric or imperial units, and various parameters such as the full-scale reading of gauges.

Pressing any of the first 4 keys (GEM keys are numbered 1 to 5, from left to right) brings up the top level 'button bar' (navigation menu).

Continued over page

CANtrak System



GEM presents a context dependent 'button bar' above the push buttons if any key from 1 to 4 is pressed - it disappears after 5 seconds of inactivity. This 'top level' button bar shows the basic structure of GEM:

NO.	FEATURE	FUNCTION
1.	Tri Display, or Main Engine Display	Repeat presses cycle the fuel computer through various modes.
2.	Quad Display	(User configurable). Repeat presses cycle the display around 3 different quad view options..
3.	Uni Display	Showing data history (configurable). Repeat presses cycle display through available parameters.
4.	Active alarm display	Holding the button brings up stored alarms..
5.	Contrast and Lighting Adjustment	Or - if held for 3 seconds - the configuration menu..

Left to right: Key 1-5, examples of screen images after keys are pushed.



Getting Started

When power is applied to the display, a start-up screen displays for approximately 7 seconds while the unit performs a self test . If the unit makes a long 'beeping' sound, self-test has failed. Users can attempt to rectify the fault by restoring factory defaults (see Configuration section); if the fault persists, contact your supplier for guidance.

The 'Splash Screen' is displayed on boot up.


After the start up screen disappears, GEM starts displaying readings on its virtual gauges if it is connected to an active source of data. GEM displays the 'main engine display' or tri-screen on initial start up, but note that after use this changes to the screen that was last displayed (see Preferred Screen Store section for details). GEM display modes are detailed in the following sections.

GEM Soft Keys

GEM's soft keys simplify the operator interface. In use, GEM displays a 'button bar' directly above the soft keys when any of the first 4 keys (keys 1 to 4, starting from the left) are pressed - with icons representing the current function of each key. The picture at the top of the page shows the main button bar, with icons 1 to 4 representing the gauges and alarms available, and icon 5 an 'exit door'. Repeat presses of these buttons toggles around the display options available. The button bar will disappear after approximately 5 seconds if no further keys are pressed.

Continued over page

CANtrak System



Key 1: Pages icon indicating that further presses cycle through options for the screen being viewed (in this instance fuel computer modes for the main engine display)

Key 2: Quad display mode

Key 3: Uni display mode

Key 4: Alarm display mode

Key 5: Exit door

The Tri Display or Main Engine Display - Key 1



Tri-display or main engine display, accessed via key 1.

NOTE: Metric units are shown by default but others may be selected via the configuration menu.

This GEM display mode provides three independent windows, and is intended to show the most frequently-accessed vehicle data (RPM, speed, temperature and fuel).

To select Tri Display, press any of the first 4 keys to show the top-level button bar, and then key 1 (the left-hand key). The parameters displayed on this page cannot be changed, apart from the fuel computer window which is explained below. However, attributes such as units and scales may be changed - see the Configuration menu section for details (note that user-defined views of vehicle data are available in the next GEM mode: Quad Display).

Tri Display - Fuel Computer Modes



Left: An example of a fuel computer mode

- Instantaneous Fuel Rate: (volume/hour)
- Average Trip Fuel Rate: If Total Fuel and Engine Hours are available it is calculated since last trip fuel/hours reset using: trip fuel/trip hours [volume/hour]
- Average Distance Per Volume: If Vehicle Speed or Vehicle Distance and the Total Fuel is available then it is calculated since last trip fuel/distance reset using: distance/volume
- Total Engine Hours: If Total Engine Hours is available
- Trip Engine Hours: Since last trip hours reset
- Trip Fuel: Since last trip fuel reset
- Total Distance: If Total Distance is available
- Trip Distance: If Total Distance is available then it is calculated since last trip distance reset. If Total Distance is not available, but Trip Distance is, then this is displayed.
- Fuel Remaining: If Tank Capacity is entered, Tank Full is reset, and Total Fuel Used is available, then Fuel Remaining is calculated using: Tank Capacity – (Total Fuel Used – Trip Fuel). Evaluation assumes Engine Fuel Used is cumulative and not zeroed on power up.

Continued over page


CANtrak System

Distance Remaining: If the data required for Fuel Remaining and Average Distance Per Volume is available, it is calculated using: Average Distance Per Volume x Fuel Remaining


NOTE: Reset - which affects all resettable fuel computer parameters - is performed by allowing the button bar to disappear and pressing and holding key 1 for at least 3 seconds. If the button bar is visible then the display will move to the next parameter before the Reset. Setting Fuel Tank Reset and Total Fuel Tank Data is performed via the Configuration menu.

The Quad Display - Key 2

Quad display mode provides 4 gauges. To select it, press any of the keys 1 to 4 to show the top-level button bar and then key 2. Repeat presses of key 2 cycle the display around 3 separate quad screens: as a default these screens show 4 digital gauges (RPM, temperature, battery voltage, oil pressure), 4 analogue gauges (same as digital), and 4 alternative analogue gauges. All 12 gauges may be selected and configured by users, providing a simple means of creating application-specific views of engine data. Gauges are selected via quad display's 'adjust mode', by pressing key 5 (noted by an arrow icon) when GEM is running quad display and the button bar is visible. In adjust mode, corresponding key presses cycle the display through available parameters. The selected configuration is stored even when power is removed; adjust mode is exited by pressing key 5.




Above: Three default display setups available in quad-display mode.



Above: Adjust mode; allows users to select the individual gauge types displayed.

The Uni Display - Key 3

GEM's Uni display mode plots data history in one large window - in an X-Y graph format similar to a pen plotter. This mode is selected by pressing any of the first 4 keys to show the top-level button bar and then key 3. Data is shown in graph form, with the most recent data scrolling from right to left. The viewed time range may be adjusted in the Configuration menu from 2 minutes to 8 hours in six steps. Maximum and minimum values of the Y axis (the reading span) are adjusted automatically to give an optimum view of data. The parameter displayed is selectable by repeatedly pressing key 3 while in the graph display mode. The parameters that may be displayed are listed in the next section.



Above: Example graph display plotting battery voltage.



CANtrak System - Parameters Monitored

Engine & Transmission Parameters Monitored

This table lists the engine and transmission parameters that can be displayed by GEM and which may be shown in user-configurable Quad Display and Uni Display modes (a tick indicates the parameter may be selected). DB is an abbreviation for GEM's internal database, which stores all data transmitted from the engine/transmission. It can be accessed via the Configuration menu. (Note that this list is current at the time of going to press, new parameters are continually being added - the latest list may be found in the latest GEM data sheet available at <<http://www.cantrak-int.com>>).

Abbreviations: The units 'MPG' and 'Gal' denote US gallons. For non-US Imperial gallons (UK, Canada, etc) units, these units are denoted as IMPG or IGal. N = nautical. KTS = Knots.

NOTE: If a parameter is not available, it will not be possible to select it. If the parameter becomes unavailable while in view, '- -' is displayed.

Icon	Parameter	Tri	Quad	Uni	DB
	MISCELLANEOUS				
None	Torque converter lock-up				✓
	Current gear		✓		✓
	Selected gear		✓		✓
	Accelerator position (%)		✓		✓
None	Transmission output shaft speed (RPM)				✓
None	Transmission input shaft speed (RPM)				✓
	Engine speed (RPM)	✓	✓	✓	✓
	Engine torque (%)		✓		✓
	Engine oil level (%)		✓		✓
	Coolant level (%)		✓		✓
	Fan speed (%)		✓		✓
	Vehicle speed (km/h, MPH or KTS)	✓			✓
	Engine hours (h)	✓			✓
	Trip engine hours (h)	✓			✓

Continued over page

CANtrak System - Parameters Monitored

Icon	Parameter	Tri	Quad	Uni	DB
FUEL & DISTANCE					
	Trip distance (km, Miles, NMiles)	✓			✓
	Distance remaining (km, Miles, NMiles)	✓			✓
	Total distance (km, Miles, NMiles)	✓			✓
	Fuel rate (L/h, Gal/h or lGal/h)	✓		✓	✓
	Average trip fuel rate (L/h, Gal/h or lGal/h)	✓			✓
	Fuel level (%)	✓			✓
	Fuel remaining (L, Gal or lGal)	✓			✓
	Trip fuel (L, Gal, lGal)	✓			✓
None	Total fuel used (L, Gal, lGal)				✓
	Instantaneous fuel economy (Km/L, MPG or IMPG)	✓			✓
	Average fuel economy (Km/L, MPG or IMPG)	✓			✓
Icon	Parameter	Tri	Quad	Uni	DB
PRESSURE (can be kPa, PSI or bar)					
	Fuel pressure		✓	✓	✓
	Barometric pressure		✓		✓
	Auxiliary pressure		✓		✓
	Turbo pressure		✓	✓	✓
	Air inlet pressure		✓	✓	✓
	Air filter differential pressure		✓		✓
None	Injector metering rail 1 pressure				✓
None	Injector metering rail 2 pressure				✓
	Coolant pressure		✓	✓	✓
	Engine oil pressure	✓	✓	✓	✓
	Transmission oil pressure		✓	✓	✓

Continued over page

CANtrak System - Parameters Monitored

Icon	Parameter	Tri	Quad	Uni	DB
ELECTRICAL					
	Internal voltage (V)		✓	✓	✓
	Battery voltage (V)		✓	✓	✓
	Battery current (A)		✓		✓
	Alternator current (A)		✓		✓
TEMPERATURE (can be °C or °F)					
	Coolant temperature	✓	✓	✓	✓
	Engine intercooler temperature		✓		✓
	Engine oil temperature		✓	✓	✓
	Transmission oil temperature		✓	✓	✓
	Turbo oil temperature		✓		✓
	Fuel temperature		✓		✓
	Inlet manifold temperature		✓	✓	✓
	Air inlet temperature		✓		✓
	Exhaust temperature		✓	✓	✓
	Auxiliary temperature		✓		✓

CANtrak System - Alarms

Active & Stored Alarm Lists

Active alarms. When an active/current alarm is received, a flashing pop-up window appears overlaid on the current screen in use, showing details of the current alarm. If the alarm is 'red/stop' category (this is J1939 terminology for a serious problem, e.g. low oil pressure), GEM activates its internal sounder (beeping noise), and the External Alarm Output or Pin 11 (if available on the CANtrak you have chosen)


The alarm list is accessed by pressing any key while an alarm pop-up is displayed, or by pressing any of the first 4 keys to show the button bar, and then key 4. This screen displays all current active alarms; when entered, Pin 11 External Alarm Output is deactivated (if the function is available). Alarms not yet acknowledged are shown in grey on black. Alarms already acknowledged are shown in black on grey. If engine Hours data is available, the list indicates when the alarm was initiated. When first entering the screen, the list automatically displays the most recent alarm. The list can be scrolled using keys 1 and 2. This screen cannot be exited until all alarms have been acknowledged by pressing key 3. Alarm messages are automatically cleared from the list when no longer received by GEM.

Stored alarms. Alarms stored by engine/transmission ECU's (i.e. not active or current but old/historical alarms) may be viewed by pressing and holding key 4 while the active alarm list screen is visible. On entry to this page, GEM sends a data request to the engine/transmission. The engine/transmission sends the stored alarm data to GEM, which is decoded and displayed in a similar fashion to active alarms. GEM displays an error message if there is no response from the engine/transmission. If the engine/transmission supports the erasure of stored alarms, they may now be erased by holding key 3.



Above: Example alarm message plus alarm list screens showing unacknowledged conditions (black background) and acknowledged alarms (grey background). After acknowledgement the return key becomes active ('exit door' icon). J1939 - standard abbreviations are used wherever possible.

NOTE: 'MS' = Most Severe, "MOD"= Moderately Severe and "LS" = Least Severe.



Above: Example of stored alarms list.

CANtrak System - Engine Fault Codes

Fault Code	J1939 SPN	J1939 FMI	Lamp Colour	J1939 SPN Description	Cummins Description
111	629	12	Red	Controller #1	Engine Control Module Critical internal failure - Bad intelligent Device or Component
115	612	2	Red	System Diagnostic Code # 2	Engine Speed/Position Sensor Circuit lost both of two signals from the magnetic pickup sensor - Data Erratic, Intermittent, or incorrect
122	102	3	Amber	Boost Pressure	Intake Manifold Pressure Sensor Circuit – Voltage Above Normal, or Shorted to High Source
123	102	4	Amber	Boost Pressure	Intake Manifold Pressure Sensor Circuit – Voltage Below Normal, or Shorted to Low Source
124	102	16	Amber	Boost Pressure	Intake Manifold 1 Pressure - Data Valid but Above Normal Operational Range - Moderately Severe Level
131	91	3	Red	Accelerator Pedal Position	Accelerator Pedal or Lever Position Sensor Circuit - Voltage Above Normal, or Shorted to High Source
132	91	4	Red	Accelerator Pedal Position	Accelerator Pedal or Lever Position Sensor Circuit - Voltage Below Normal, or Shorted to Low Source
133	974	3	Red	Remote Accelerator	Remote Accelerator Pedal or Lever Position Sensor Circuit – Voltage Above Normal, or Shorted to High Source
134	974	4	Red	Remote Accelerator	Remote Accelerator Pedal or Lever Position Sensor Circuit – Voltage Below Normal, or Shorted to Low Source
135	100	3	Amber	Engine Oil Pressure	Oil Pressure Sensor Circuit - Voltage Above Normal, or Shorted to High Source
141	100	4	Amber	Engine Oil Pressure	Oil Pressure Sensor Circuit - Voltage Below Normal, or Shorted to Low Source
143	100	18	Amber	Engine Oil Pressure	Oil Pressure Low – Data Valid but Below Normal Operational Range - Moderately Severe Level
144	110	3	Amber	Engine Coolant Temperature	Coolant Temperature Sensor Circuit – Voltage Above Normal, or Shorted to High Source
145	110	4	Amber	Engine Coolant Temperature	Coolant Temperature Sensor Circuit – Voltage Below Normal, or Shorted to Low Source
146	110	16	Amber	Engine Coolant Temperature	Coolant Temperature High - Data Valid but Above Normal Operational Range - Moderately Severe Level
147	91	1	Red	Accelerator Pedal Position	Accelerator Pedal or Lever Position Sensor Circuit – Abnormal Frequency, Pulse Width, or Period
148	91	0	Red	Accelerator Pedal Position	Accelerator Pedal or Lever Position Sensor Circuit – Abnormal Frequency, Pulse Width, or Period
151	110	0	Red	Engine Coolant Temperature	Coolant Temperature Low - Data Valid but Above Normal Operational Range - Most Severe Level
153	105	3	Amber	Intake Manifold #1 Temp	Intake Manifold Air Temperature Sensor Circuit - Voltage Above Normal, or Shorted to High Source
154	105	4	Amber	Intake Manifold #1 Temp	Intake Manifold Air Temperature Sensor Circuit - Voltage Below Normal, or Shorted to Low Source
155	105	0	Red	Intake Manifold #1 Temp	Intake Manifold Air Temperature High – Data Valid but Above Normal Operational Range - Most Severe Level
187	3510	4	Amber	5 Volts DC Supply	Sensor Supply Voltage #2 Circuit – Voltage Below Normal, or Shorted to Low Source

Continued over page

CANtrak System - Engine Fault Codes

Fault Code	J1939 SPN	J1939 FMI	Lamp Colour	J1939 SPN Description	Cummins Description
193	520199	3	Amber	Cruise Control	Cruise Control (Resistive) Signal Circuit - Voltage Above Normal, or Shorted to High Source
194	520199	4	Amber	Cruise Control	Cruise Control (Resistive) Signal Circuit - Voltage Below Normal, or Shorted to Low Source
195	111	3	Amber	Coolant Level	Coolant Level Sensor Circuit - Voltage Above Normal, or Shorted to High Source
196	111	4	Amber	Coolant Level	Coolant Level Sensor Circuit - Voltage Below Normal, or Shorted to Low Source
197	111	18	Amber	Coolant Level	Coolant Level - Data Valid but Below Normal Operational Range - Moderately Severe Level
199	1661	4	Amber	Engine Automatic Start Lamp	Engine Automatic Start Lamp Driver Circuit - Voltage Above Normal, or Shorted to High Source
211	1484	31	None	J1939 Error	Additional Auxiliary Diagnostic Codes logged - Condition Exists
212	175	3	Amber	Oil Temperature	Engine Oil Temperature Sensor 1 Circuit - Voltage Above Normal, or Shorted to High Source
213	175	4	Amber	Oil Temperature	Engine Oil Temperature Sensor 1 Circuit - Voltage Below Normal, or Shorted to Low Source
214	175	0	Red	Oil Temperature	Engine Oil Temperature - Data Valid but Above Normal Operational Range - Most Severe Level
221	108	3	Amber	Barometric Pressure	Barometric Pressure Sensor Circuit - Voltage Above Normal, or Shorted to High Source
222	108	4	Amber	Barometric Pressure	Barometric Pressure Sensor Circuit - Voltage Below Normal, or Shorted to Low Source
227	3510	3	Amber	5 Volts DC Supply	Sensor Supply Voltage #2 Circuit - Voltage Above Normal, or Shorted to High Source
231	109	3	Amber	Coolant Pressure	Coolant Pressure Sensor Circuit - Voltage Above Normal, or Shorted to High Source
232	109	4	Amber	Coolant Pressure	Coolant Pressure Sensor Circuit - Voltage Below Normal, or Shorted to Low Source
233	109	18	Amber	Coolant Pressure	Coolant Pressure - Data Valid but Below Normal Operational Range - Moderately Severe Level
234	190	0	Red	Engine Speed	Engine Speed High - Data Valid but Above Normal Operational Range - Most Severe Level
235	111	1	Red	Coolant Level	Coolant Level Low - Data Valid but Below Normal Operational Range - Most Severe Level
237	644	2	Amber	External Speed Input	External Speed Input (Multiple Unit Synchronization) - Data Erratic, Intermittent, or Incorrect
238	3511	4	Amber	System Diagnostic code # 1	Sensor Supply Voltage #3 Circuit - Voltage Below Normal, or Shorted to Low Source
239	3511	3	Amber	System Diagnostic code #2	Sensor Supply Voltage #3 Circuit - Voltage Above Normal, or Shorted to High Source
241	84	2	Amber	Wheel-based Vehicle Speed	Vehicle Speed Sensor Circuit - Data Erratic, Intermittent, or Incorrect
242	84	10	Amber	Wheel-based Vehicle Speed	Vehicle Speed Sensor Circuit tampering has been detected - Abnormal Rate of Change
244	623	4	Amber	Red Stop Lamp	Red Stop Lamp Driver Circuit - Voltage Below Normal, or Shorted to Low Source
245	647	4	Amber	Fan Clutch Output Device Driver	Fan Control Circuit - Voltage Below Normal, or Shorted to Low Source
249	171	3	Amber	Ambient Air Temperature	Ambient Air Temperature Sensor Circuit - Voltage Above Normal, or Shorted to High Source
256	171	4	Amber	Ambient Air Temperature	Ambient Air Temperature Sensor Circuit - Voltage Below Normal, or Shorted to Low Source
261	174	16	Amber	Fuel Temperature	Engine Fuel Temperature - Data Valid but Above Normal Operational Range - Moderately Severe Level

Continued over page

CANtrak System - Engine Fault Codes

Fault Code	J1939 SPN	J1939 FMI	Lamp Colour	J1939 SPN Description	Cummins Description
263	174	3	Amber	Fuel Temperature	Engine Fuel Temperature Sensor 1 Circuit - Voltage Above Normal, or Shorted to High Source
265	174	4	Amber	Fuel Temperature	Engine Fuel Temperature Sensor 1 Circuit - Voltage Below Normal, or Shorted to Low Source
268	94	2	Amber	Fuel Delivery Pressure	Fuel Pressure Sensor Circuit - Data Erratic, Intermittent, or Incorrect
271	1347	4	Amber	Fuel Pump Pressurizing Assembly #1	High Fuel Pressure Solenoid Valve Circuit - Voltage Below Normal, or Shorted to Low Source
272	1347	3	Amber	Fuel Pump Pressurizing Assembly #1	High Fuel Pressure Solenoid Valve Circuit - Voltage Above Normal, or Shorted to High Source
281	1347	7	Amber	Fuel Pump Pressurizing Assembly #1	High Fuel Pressure Solenoid Valve #1 - Mechanical System Not Responding Properly or Out of Adjustment
284	1043	4	Amber	Internal Sensor Voltage Supply	Engine Speed/Position Sensor (Crankshaft) Supply Voltage Circuit - Voltage Below Normal, or Shorted to Low Source
285	639	9	Amber	SAE J1939 Datalink	SAE J1939 Multiplexing PGN Timeout Error - Abnormal Update Rate
286	639	13	Amber	SAE J1939 Datalink	SAE J1939 Multiplexing Configuration Error - Out of Calibration
287	91	19	Red	Accelerator Pedal Position	SAE J1939 Multiplexing Accelerator Pedal or Lever Sensor System Error - Received Network Data In Error
288	974	19	Red	Remote Accelerator	SAE J1939 Multiplexing Remote Accelerator Pedal or Lever Data Error - Received Network Data In Error
292	441	14	Red	Auxiliary Temperature 1	Auxiliary Temperature Sensor Input 1 - Special Instructions
293	441	3	Amber	OEM Temperature	Auxiliary Temperature Sensor Input # 1 Circuit - Voltage Above Normal, or Shorted to High Source
294	441	4	Amber	OEM Temperature	Auxiliary Temperature Sensor Input # 1 Circuit - Voltage Below Normal, or Shorted to Low Source
295	108	2	Amber	Barometric Pressure	Barometric Pressure Sensor Circuit - Data Erratic, Intermittent, or Incorrect
296	1388	14	Red	Auxiliary Pressure	Auxiliary Pressure Sensor Input 1 - Special Instructions
297	1388	3	Amber	Auxiliary Pressure	Auxiliary Pressure Sensor Input # 2 Circuit - Voltage Above Normal, or Shorted to High Source
298	1388	4	Amber	Auxiliary Pressure	Auxiliary Pressure Sensor Input # 2 Circuit - Voltage Below Normal, or Shorted to Low Source
319	251	2	Maint	Real Time Clock Power	Real Time Clock Power Interrupt - Data Erratic, Intermittent, or Incorrect
322	651	5	Amber	Injector Cylinder #01	Injector Solenoid Cylinder #1 Circuit - Current Below Normal, or Open Circuit
323	655	5	Amber	Injector Cylinder #05	Injector Solenoid Cylinder #5 Circuit - Current Below Normal, or Open Circuit
324	653	5	Amber	Injector Cylinder #03	Injector Solenoid Cylinder #3 Circuit - Current Below Normal, or Open Circuit
325	656	5	Amber	Injector Cylinder #06	Injector Solenoid Cylinder #6 Circuit - Current Below Normal, or Open Circuit
331	652	5	Amber	Injector Cylinder #02	Injector Solenoid Cylinder #2 Circuit - Current Below Normal, or Open Circuit
332	654	5	Amber	Injector Cylinder #04	Injector Solenoid Cylinder #4 Circuit - Current Below Normal, or Open Circuit
334	110	2	Amber	Engine Coolant Temperature	Coolant Temperature Sensor Circuit - Data Erratic, Intermittent, or Incorrect

Continued over page

CANtrak System - Engine Fault Codes

Fault Code	J1939 SPN	J1939 FMI	Lamp Colour	J1939 SPN Description	Cummins Description
338	1267	3	Amber	Vehicle Accessories Relay Driver	Idle Shutdown Vehicle Accessories Relay Driver Circuit - Voltage Above Normal, or Shorted to High Source
339	1267	4	Amber	Vehicle Accessories Relay Driver	Idle Shutdown Vehicle Accessories Relay Driver Circuit - Voltage Below Normal, or Shorted to Low Source
341	630	2	Amber	Calibration Memory	Engine Control Module data lost - Data Erratic, Intermittent, or Incorrect
342	630	13	Red	Calibration Memory	Electronic Calibration Code Incompatibility - Out of Calibration
343	629	12	Amber	Controller #1	Engine Control Module Warning internal hardware failure - Bad Intelligent Device or Component
349	191	16	Amber	Transmission Output Shaft Speed	Transmission Output Shaft Speed - Data Valid but Above Normal Operational Range - Moderately Severe Level
351	627	12	Amber	Controller #1	Injector Power Supply - Bad Intelligent Device or Component
352	3509	4	Amber	5 Volts DC Supply	Sensor Supply Voltage #1 Circuit - Voltage Below Normal, or Shorted to Low Source
386	3509	3	Amber	5 Volts DC Supply	Sensor Supply Voltage #1 Circuit - Voltage Above Normal, or Shorted to High Source
415	100	1	Red	Engine Oil Pressure	Oil Pressure Low - Data Valid but Below Normal Operational Range - Most Severe Level
418	97	15	Maint.	Water in Fuel Indicator	Water in Fuel Indicator High - Data Valid but Above Normal Operational Range - Least Severe Level
422	111	2	Amber	Coolant Level	Coolant Level - Data Erratic, Intermittent, or Incorrect
425	175	2	Amber	Oil Temperature	Engine Oil Temperature - Data Erratic, Intermittent, or Incorrect
428	97	3	Amber	Water in Fuel Indicator	Water in Fuel Sensor Circuit - Voltage Above Normal, or Shorted to High Source
429	97	4	Amber	Water in Fuel Indicator	Water in Fuel Sensor Circuit - Voltage Below Normal, or Shorted to Low Source
431	558	2	Amber	Accelerator Pedal Low Idle Switch	Accelerator Pedal or Lever Idle Validation Circuit - Data Erratic, Intermittent, or Incorrect
432	558	13	Red	Accelerator Pedal Low Idle Switch	Accelerator Pedal or Lever Idle Validation Circuit - Out of Calibration
435	100	2	Amber	Engine Oil Pressure	Oil Pressure Sensor Circuit - Data Erratic, Intermittent, or Incorrect
441	168	18	Amber	Electrical Potential (Voltage)	Battery #1 Voltage Low - Data Valid but Below Normal Operational Range - Moderately Severe Level
442	168	16	Amber	Electrical Potential (Voltage)	Battery #1 Voltage High - Data Valid but Above Normal Operational Range - Moderately Severe Level
449	157	0	Red	Injector Metering Rail 1 Pressure	Fuel Pressure High - Data Valid but Above Normal Operational Range - Moderately Severe Level
451	157	3	Amber	Injector Metering Rail 1 Pressure	Injector Metering Rail #1 Pressure Sensor Circuit - Voltage Above Normal, or Shorted to High Source
452	157	4	Amber	Injector Metering Rail 1 Pressure	Injector Metering Rail #1 Pressure Sensor Circuit - Voltage Below Normal, or Shorted to Low Source
488	105	16	Amber	Intake Manifold	Intake Manifold 1 Temperature - Data Valid but Above Normal Operational Range - Moderately Severe Level
489	191	18	Amber	Transmission Output Shaft Speed	Transmission Output Shaft Speed - Data Valid but Below Normal Operational Range - Moderately Severe Level

Continued over page

CANtrak System - Engine Fault Codes

Fault Code	J1939 SPN	J1939 FMI	Lamp Colour	J1939 SPN Description	Cummins Description
497	1377	2	Amber	Switch Circuit	Multiple Unit Synchronization Switch Circuit - Data Erratic, Intermittent, or Incorrect
523	611	2	Amber	System Diagnostic code # 1	OEM Intermediate (PTO) Speed switch Validation - Data Erratic, Intermittent, or Incorrect
527	702	3	Amber	Circuit - Voltage	Auxiliary Input/Output 2 Circuit - Voltage Above Normal, or Shorted to High Source
528	93	2	Amber	Switch - Data	Auxiliary Alternate Torque Validation Switch - Data Erratic, Intermittent, or Incorrect
529	703	3	Amber	Circuit - Voltage	Auxiliary Input/Output 3 Circuit - Voltage Above Normal, or Shorted to High Source
546	94	3	Amber	Fuel Delivery Pressure	Fuel Delivery Pressure Sensor Circuit - Voltage Above Normal, or Shorted to High Source
547	94	4	Amber	Fuel Delivery Pressure	Fuel Delivery Pressure Sensor Circuit - Voltage Below Normal, or Shorted to Low Source
551	558	4	Amber	Accelerator Pedal Low Idle Switch	Accelerator Pedal or Lever Idle Validation Circuit - Voltage Below Normal, or Shorted to Low Source
553	157	16	Amber	Injector Metering Rail 1 Pressure	Injector Metering Rail #1 Pressure High – Data Valid but Above Normal Operational Range - Moderately Severe Level
554	157	2	Amber	Injector Metering Rail 1 Pressure	Fuel Pressure Sensor Error - Data Erratic, Intermittent, or Incorrect
559	157	18	Amber	Injector Metering Rail 1 Pressure	Injector Metering Rail #1 Pressure Low – Data Valid but Below Normal Operational Range - Moderately Severe Level
584	677	3	Amber	Starter Solenoid Lockout Relay Driver Circuit	Starter Relay Circuit - Voltage Above Normal, or Shorted to High Source
585	677	4	Amber	Starter Solenoid Lockout Relay Driver Circuit	Starter Relay Circuit - Voltage Below Normal, or Shorted to Low Source
595	103	16	Amber	Turbocharger 1 Speed	Turbocharger #1 Speed High - Data Valid but Above Normal Operational Range – Moderately Severe Level
596	167	16	Amber	Alternate Potential (voltage)	Electrical Charging System Voltage High – Data Valid but Above Normal Operational Range - Moderately Severe Level
597	167	18	Amber	Alternate Potential (voltage)	Electrical Charging System Voltage Low – Data Valid but Below Normal Operational Range - Moderately Severe Level
598	167	1	Red	Alternate Potential (voltage)	Electrical Charging System Voltage Low – Data Valid but Below Normal Operational Range - Most Severe Level
599	640	14	Red	Engine External Protection Input	Auxiliary Commanded Dual Output Shutdown - Special Instructions
649	1378	31	Maint	Engine Oil Change Interval	Change Lubricating Oil and Filter – Condition Exists
687	103	18	Amber	Turbocharger 1 Speed	Turbocharger #1 Speed Low - Data Valid but Below Normal Operational Range – Moderately Severe Level
689	190	2	Amber	Engine Speed	Primary Engine Speed Sensor Error – Data Erratic, Intermittent, or Incorrect
691	1172	3	Amber	Turbocharger #1 Compressor Inlet Temperature	Turbocharger #1 Compressor Inlet Temperature Sensor Circuit – Voltage Above Normal, or Shorted to High Source
692	1172	4	Amber	Turbocharger #1 Compressor Inlet Temperature	Turbocharger #1 Compressor Inlet Temperature Sensor Circuit – Voltage Below Normal, or Shorted to Low Source
697	1136	3	Amber	Sensor Circuit - Voltage	ECM Internal Temperature Sensor Circuit - Voltage Above Normal, or Shorted to High Source
698	1136	4	Amber	Sensor Circuit - Voltage	ECM Internal Temperature Sensor Circuit - Voltage Below Normal, or Shorted to Low Source

Continued over page

CANtrak System - Engine Fault Codes

Fault Code	J1939 SPN	J1939 FMI	Lamp Colour	J1939 SPN Description	Cummins Description
719	22	3	Amber	Crankcase Pressure	Extended Crankcase Blow-by Pressure Circuit - Voltage Above Normal, or Shorted to High Source
729	22	4	Amber	Crankcase Pressure	Extended Crankcase Blow-by Pressure Circuit - Voltage Below Normal, or Shorted to Low Source
731	723	7	Amber	Engine Speed Sensor #2	Engine Speed/Position #2 mechanical misalignment between camshaft and crankshaft sensors - Mechanical System Not Responding Properly or Out of Adjustment
753	723	2	Amber	Engine Speed Sensor #2	Engine Speed/Position #2 Camshaft sync error - Data Erratic, Intermittent, or Incorrect
757	2802	31	Amber	Electronic Control Module	Electronic Control Module data lost - Condition Exists
778	723	2	Amber	Engine Speed Sensor #2	Engine Speed Sensor (Camshaft) Error – Data Erratic, Intermittent, or Incorrect
779	703	11	Amber	Auxiliary Equipment Sensor Input	Warning Auxiliary Equipment Sensor Input # 3 (OEM Switch) - Root Cause Not Known
951	166	2	None	Cylinder Power	Cylinder Power Imbalance Between Cylinders - Data Erratic, Intermittent, or Incorrect
1117	627	2	None	Power Supply	Power Lost With Ignition On - Data Erratic, Intermittent, or Incorrect
1139	651	7	Amber	Injector Cylinder # 01	Injector Cylinder #1 - Mechanical System Not Responding Properly or Out of Adjustment
1141	652	7	Amber	Injector Cylinder # 02	Injector Cylinder #2 - Mechanical System Not Responding Properly or Out of Adjustment
1142	653	7	Amber	Injector Cylinder # 03	Injector Cylinder #3 - Mechanical System Not Responding Properly or Out of Adjustment
1143	654	7	Amber	Injector Cylinder # 04	Injector Cylinder #4 - Mechanical System Not Responding Properly or Out of Adjustment
1144	655	7	Amber	Injector Cylinder # 05	Injector Cylinder #5 - Mechanical System Not Responding Properly or Out of Adjustment
1145	656	7	Amber	Injector Cylinder # 06	Injector Cylinder #6 - Mechanical System Not Responding Properly or Out of Adjustment
1239	2623	3	Amber	Accelerator Pedal Position	Accelerator Pedal or Lever Position Sensor 2 Circuit - Voltage Above Normal, or Shorted to High Source
1241	2623	4	Amber	Accelerator Pedal Position	Accelerator Pedal or Lever Position Sensor 2 Circuit - Voltage Below Normal, or Shorted to Low Source
1242	91	2	Red	Accelerator Pedal Position	Accelerator Pedal or Lever Position Sensor 1 and 2 - Data Erratic, Intermittent, or Incorrect
1256	1563	2	Amber	Control Module Identification Input State	Control Module Identification Input State Error - Data Erratic, Intermittent, or Incorrect
1257	1563	2	Red	Control Module Identification Input State	Control Module Identification Input State Error - Data Erratic, Intermittent, or Incorrect
1852	97	16	Amber	Water in Fuel Indicator	Water in Fuel Indicator - Data Valid but Above Normal Operational Range - Moderately Severe Level
1911	157	0	Amber	Injector Metering Rail	Injector Metering Rail 1 Pressure - Data Valid but Above Normal Operational Range - Most Severe Level
2111	52	3	Amber	Coolant Temperature	Coolant Temperature 2 Sensor Circuit - Voltage Above Normal, or Shorted to High Source
2112	52	4	Amber	Coolant Temperature	Coolant Temperature 2 Sensor Circuit - Voltage Below Normal, or Shorted to Low Source
2113	52	16	Amber	Coolant Temperature	Coolant Temperature 2 - Data Valid but Above Normal Operational Range - Moderately Severe Level
2114	52	0	Red	Coolant Temperature	Coolant Temperature 2 - Data Valid but Above Normal Operational Range - Most Severe Level

Continued over page

CANtrak System - Engine Fault Codes

Fault Code	J1939 SPN	J1939 FMI	Lamp Colour	J1939 SPN Description	Cummins Description
2115	2981	3	Amber	Coolant Pressure	Coolant Pressure 2 Circuit - Voltage Above Normal, or Shorted to High Source
2116	2981	4	Amber	Coolant Pressure	Coolant Pressure 2 Circuit - Voltage Below Normal, or Shorted to Low Source
2117	2981	18	Amber	Coolant Pressure	Coolant Pressure 2 - Data Valid but Below Normal Operational Range - Moderately Severe Level
2182	1072	3	Amber	Engine Brake Output # 1	Engine Brake Actuator Driver 1 Circuit - Voltage Above Normal, or Shorted to High Source
2183	1072	4	Amber	Engine Brake Output # 1	Engine Brake Actuator Driver 1 Circuit - Voltage Below Normal, or Shorted to Low Source
2185	3512	3	Amber	System Diagnostic code # 1	Sensor Supply Voltage #4 Circuit - Voltage Above Normal, or Shorted to High Source
2186	3512	4	Amber	System Diagnostic code # 1	Sensor Supply Voltage #4 Circuit - Voltage Below Normal, or Shorted to Low Source
2195	703	14	Red	Auxiliary Equipment Sensor	Auxiliary Equipment Sensor Input 3 Engine Protection Critical - Special Instructions
2215	94	18	Amber	Fuel Delivery Pressure	Fuel Pump Delivery Pressure - Data Valid but Below Normal Operational Range - Moderately Severe Level
2216	94	1	Amber	Fuel Delivery Pressure	Fuel Pump Delivery Pressure - Data Valid but Above Normal Operational Range - Moderately Severe Level
2217	630	31	Amber	Calibration Memory	ECM Program Memory (RAM) Corruption - Condition Exists
2249	157	1	Amber	Injector Metering Rail 1 Pressure	Injector Metering Rail 1 Pressure - Data Valid but Below Normal Operational Range - Most Severe Level
2261	94	15	Maint	Fuel Delivery Pressure	Fuel Pump Delivery Pressure - Data Valid but Above Normal Operational Range - Least Severe Level
2262	94	17	Maint	Fuel Delivery Pressure	Fuel Pump Delivery Pressure - Data Valid but Below Normal Operational Range - Least Severe Level
2263	1800	16	Amber	Battery Temperature	Battery Temperature - Data Valid but Above Normal Operational Range - Moderately Severe Level
2264	1800	18	Amber	Battery Temperature	Battery Temperature - Data Valid but Below Normal Operational Range - Moderately Severe Level
2265	1075	3	Amber	Electric Lift Pump for Engine Fuel	Fuel Priming Pump Control Signal Circuit - Voltage Above Normal, or Shorted to High Source
2266	1075	4	Amber	Electric Lift Pump for Engine Fuel	Fuel Priming Pump Control Signal Circuit - Voltage Below Normal, or Shorted to Low Source
2292	611	16	Amber	Fuel Inlet Meter Device	Fuel Inlet Meter Device - Data Valid but Above Normal Operational Range - Moderately Severe Level
2293	611	18	Amber	Fuel Inlet Meter Device	Fuel Inlet Meter Device flow demand lower than expected - Data Valid but Below Normal Operational Range - Moderately Severe Level
2311	633	31	Amber	Fuel Control Valve #1	Fueling Actuator #1 Circuit Error - Condition Exists
2321	190	2	None	Engine Speed	Engine Speed / Position Sensor #1 - Data Erratic, Intermittent, or Incorrect
2322	723	2	None	Engine Speed Sensor #2	Engine Speed / Position Sensor #2 - Data Erratic, Intermittent, or Incorrect
2345	103	10	Amber	Turbocharger 1 Speed	Turbocharger speed invalid rate of change detected - Abnormal Rate of Change
2346	2789	15	None	System Diagnostic Code #1	Turbocharger Turbine Inlet Temperature (Calculated) - Data Valid but Above Normal Operational Range - Least Severe Level

Continued over page

CANtrak System - Engine Fault Codes


Fault Code	J1939 SPN	J1939 FMI	Lamp Colour	J1939 SPN Description	Cummins Description
2347	2790	15	None	System Diagnostic Code #1	Turbocharger Compressor Outlet Temperature (Calculated) - Data Valid but Above Normal Operational Range – Least Severe Level
2363	1073	4	Amber	Engine Compression Brake Output # 2	Engine Brake Actuator Circuit #2 – Voltage Below Normal, or Shorted to Low Source
2365	1112	4	Amber	Engine Brake Output # 3	Engine Brake Actuator Driver Output 3 Circuit - Voltage Below Normal, or Shorted to Low Source
2367	1073	3	Amber	Engine Compression Brake Output # 2	Engine Brake Actuator Circuit #2 – Voltage Above Normal, or Shorted to High Source
2368	1112	3	Amber	Engine Brake Output # 3	Engine Brake Actuator Driver 3 Circuit - Voltage Above Normal, or Shorted to High Source
2372	95	16	Amber	Engine Fuel Filter Differential Pressure	Fuel Filter Differential Pressure - Data Valid but Above Normal Operational Range - Moderately Severe Level
2373	1209	3	Amber	Exhaust Gas Pressure	Exhaust Gas Pressure Sensor Circuit - Voltage Above Normal, or Shorted to High Source
2374	1209	4	Amber	Exhaust Gas Pressure	Exhaust Gas Pressure Sensor Circuit - Voltage Below Normal, or Shorted to Low Source
2375	412	3	Amber	Exhaust Gas Recirculation Temperature	Exhaust Gas Recirculation Temperature Sensor Circuit - Voltage Above Normal, or Shorted to High Source
2376	412	4	Amber	Exhaust Gas Recirculation Temperature	Exhaust Gas Recirculation Temperature Sensor Circuit - Voltage Below Normal, or Shorted to Low Source
2377	647	3	Amber	Fan Clutch Output Device Driver	Fan Control Circuit - Voltage Above Normal, or Shorted to High Source
2425	730	4		Intake Air Heater # 2	Intake Air Heater 2 Circuit - Voltage Below Normal, or Shorted to Low Source
2426	730	3		Intake Air Heater # 2	Intake Air Heater 2 Circuit - Voltage Above Normal, or Shorted to High Source
2555	729	3	Amber	Inlet Air Heater Driver #1	Intake Air Heater #1 Circuit - Voltage Above Normal, or Shorted to High Source
2556	729	4	Amber	Inlet Air Heater Driver #1	Intake Air Heater #1 Circuit - Voltage Below Normal, or Shorted to Low Source
2557	697	3	Amber	Auxiliary PWM Driver #1	Auxiliary PWM Driver #1 - Voltage Above Normal, or Shorted to High Source
2558	697	4	Amber	Auxiliary PWM Driver #1	Auxiliary PWM Driver #1 - Voltage Below Normal, or Shorted to Low Source
2963	110	15	None	Engine Coolant Temperature	Engine Coolant Temperature High - Data Valid but Above Normal Operational Range - Least Severe Level
2973	102	2	Amber	Boost Pressure	Intake Manifold Pressure Sensor Circuit - Data Erratic, Intermittent, or Incorrect

CANtrak System - Configuration

Configuration Menu

This mode allows users to set various GEM operating parameters such as imperial or metric units, scale limits for the speedometer, engine service interval, etc. The configuration menu is entered by pressing and holding key 5 ('Exit door' icon) for at least 3 seconds while GEM is in normal operating mode. The top-level configuration menu will be displayed as shown below. Use Keys 1 and 2 (up and down arrows) to point to either SETTINGS

or SYSTEM sub-menus. Press key 4 to enter the selected sub-menu. User preferences are set in SETTINGS sub-menu. SYSTEM sub-menu accesses maintenance and low-level system configuration settings. These sub-menus are detailed below. Key 5 ('Exit door' icon) exits the current menu/sub menu. Settings are automatically stored on exit.



Above: The top-level Configuration menu showing two choices of SETTINGS and SYSTEM sub-menus. Pressing Key 4 enters the menu highlighted. Key 5 showing the 'exit door' icon returns you to the previous menu.

Settings Sub-Menu

The settings sub-menu allows the user to configure or view the following items:

UNITS: Speed, distance, pressure, volume, etc.


LANGUAGE: Choose from various language options.

BEEP: Keys "beep" when pressed (toggles on or off); note that an audible beep still sounds if an alarm occurs.

DISPLAY: Select ranges for max. RPM, max. speed, and graph X axis.

SERVICE: Set service interval in hours, and reset interval counter.

FUEL CAPACITY: Adjust tank capacity and reset tank level to full.



Continued over page

CANtrak System - Configuration

System Sub-Menu

The system sub-menu allows the user to configure or view the following items:



DEMO: Switches between GEM's demonstration mode and the normal mode of displaying live engine/transmission data. Demo allows GEM to operate without live data and provides 3 levels of simulated data: 1 = Speed On; 2 = Speed Off; 3 = Alarms On. Demo is automatically set to OFF if live data is received. DEMO mode can be selected, allowing you to evaluate GEM without connecting an engine/transmission (it is accessed via the Configuration menu described above). If the unit is in DEMO mode and live data from the engine/ transmission becomes active, DEMO mode will automatically be switched off.

RESTORE DEFAULTS: Allows you to reset all configuration information to default metric or imperial values. The default settings are:

Setting	Metric	Imperial
Language	ENGLISH	
Max. RPM	4000	
Max. speed	110 KM/H	70 MPH
Graph range	2 minutes	
Speed	KM/H	MPH
Distance	KM	MILES
Pressure	kPa	PSI
Volume	L	Gallon (US)
Temperature	°C	°F

COM VIEWER: Displays last messages received on J1939 (CAN) and NMEA 0183 (GPS - derived speed over ground data) ports. You can also view GEM's database (DB) which stores all data transmitted from the engine/transmission.

NOTE: this is a diagnostic feature that may be helpful for OEMs/users diagnosing faults.

J1939 SETTINGS: J1939 configuration screen for engine and transmission source: 1 = engine 1 (port), 2 = engine 2 (Starboard); alarm filter (GLB (Global) = all alarm sources, SRC = selected engine/ transmission only); SPN version (4 is default but older engines will need to be set to 1, 2 or 3 as appropriate). Note. Consult your engine or vehicle supplier to establish which SPN version is appropriate if you have problems reading alarm data.

ABOUT: Displays the following product information:


- ID NO: Unique number of the display.
- EEPROM: Number of write cycles.
- PART No: Software part number.
- VERS: Software version number.
- CHK: Flash memory checksum.
- SOURCE: The source of received data.
- LIB1: Low level system library version.
- LIB2: Low-level graphical display interface library version (if used).

Continued over page

CANtrak System - Configuration

Pop Up Messages & Warnings

- Engine service warning. In the Configuration menu, users can set the engine service interval in hours. When GEM determines an engine service is due, it displays SERVICE REQUIRED on the splash screen that appears at power-up.
- Data communications failure. If GEM cannot detect engine/ transmission data broadcasts , a pop-up window with a data communications failure warning icon will appear and flash. Once engine/transmission data is detected the warning disappears and normal data display resumes.
- CANTX disable. If CANTX (transmission) is disabled, then the status will be displayed, with a pop-up window flashing with a period of approximately 1 second on, 10 seconds off. Note that this function is a requirement of the J1939 specification and is not normally of importance for GEM applications.
- Data not supported. If the required data parameter is not available, the gauge will display " - - - " near the units and parameter icon (see centre picture for example)




Above, top to bottom: Pop up warnings - Engine service required, a data communications failure and CANTX is disabled.

Setting LCD Lighting & Contrast

Pressing key 5 (the right-hand key) when the menu icons are not being displayed brings up the lighting and contrast menu. The LCD has a number of back-lighting levels that allow the display to be read in the dark. The appropriate level is selected by pressing keys 1 or 2 to decrease or increase illumination. Contrast is adjusted in the same manner, using keys 3 and 4 (Figure 12.1). Note that GEM monitors the temperature of the LCD and automatically adjusts display contrast as required, therefore it is not likely that a user will need to make a manual contrast adjustment unless extreme climate changes occur. The menu is exited by pressing key 5. The lighting and contrast settings are retained after the unit is switched off.

NOTE: resetting contrast. If the contrast has been adjusted poorly, you may restore the factory setting (a central value) by pressing keys 1 to 4 simultaneously. This action does not change other user-configured settings.

NOTE: The backlight can be set to Auto or ON.



Above: Contrast level adjustment on the lighting and adjust screen.

Continued over page

CANtrak System - Configuration

Preferred Screen Storage

GEM automatically stores the current screen as a user's preferred page, after a delay of approximately 15 seconds (if no buttons are pushed). On next power-up the display will start with the splash screen, and then go to the last stored screen.

NOTE: selecting Restore Defaults on the Systems sub-menu of Configuration will set the main engine screen as the default display.

Key Pad Lock

GEM's five keys can be locked, such that an operator cannot change any settings or access any other display mode - in a similar manner to the key lock functions on a mobile phone. This is achieved by pressing and holding keys 1 and 5 simultaneously for four seconds. Repeating this operation resets GEM/CANtrak back to normal operation.

Maintenance & Troubleshooting

No regular maintenance is required, except for cleaning the GEM lens as required using a soft, damp cloth. Do not use abrasive materials or solvents. Should any further attention be necessary, please contact your supplier.

GEM Diagnostics

Problem	Possible solution
Unit does not power up	Ensure connections to unit are correct. Ensure power source is present.
Display is blank or black	Adjust/ reset lighting and contrast settings. Ensure temperature is within operating range of the unit.
Unit fails self-test	Perform Restore Factory Defaults procedure.
Unit fails to display any data	Ensure connections to unit are correct. Ensure data source supports J1939 message protocol.
Unit fails to display certain parameter(s)/unable to select certain parameter(s)	Ensure GEM supports required parameter(s). Ensure data source provides required parameter(s).
Active alarm messages are not displayed	Ensure data source provides alarm message data in the following format: J1939 Active Diagnostic Trouble Codes- Diagnostic Message 1 (DM1).
Stored alarm messages are not displayed	Ensure data source provides alarm message data in the following format: J1939 Active Diagnostic Trouble Codes- Diagnostic Message 2 (DM2).

Glossary


- CAN: Controller Area Network (also referred to as CANbus); serial communications protocol for automotive use.
- CANtrak: Intelligent CAN-compatible LCD display module
- GEM: Generic Engine Monitor
- GPS: Global Positioning System
- HMI: Human-Machine Interface
- ISO: International Standard Organisation
- J1939: SAE engine data protocol using CAN 2.0B
- LCD: Liquid Crystal Display
- NMEA: National Marine Electronics Association; serial communications protocol for marine use.
- PID: Parameter Identifier
- RS-232: Standard electrical interface for serial communications
- RS-485: Standard differential electrical interface for serial communications
- SAE: Society of Automotive Engineers Inc.
- SID: Subsystem Identifier
- Soft keys: Push-button keys whose function changes according to use
- SPN: Suspect Parameter Number: J1939-specific fault code ID number

NOTE: The messages, icons, error codes etc displayed by GEM conform to J1939 standards wherever possible.

Chapter 5

DRIVETRAIN

Key Features




NO.	FEATURE
1.	Engine
2.	Transmission
3.	Axle
4.	Steering
5.	Differential
6.	Drive Shafts
7.	Suspension
8.	Transfer Case

Engine


The Super Cruiser is fitted with a 193kw (260 hp) QSB 6.7 litre Cummins engine, some of its components are shown below.

NOTE: More information can be found in Chapter 10 'Lubrication & Maintenance'.



NO.	FEATURE
1.	Air cleaner
2.	Turbo
3.	Alternator
4.	Fuel Filter (Secondary)
5.	Oil Filter
6.	Starter Motor
7.	Engine Mounts
8.	Hydraulic Pump - Fan & Brakes
9.	Dip Stick
10.	Oil Filler (A second fill point is located near the dipstick - No. 9.)


Axles



Rear Axle

NO.	FEATURE
1.	Input Flange
2.	Planet Hub - Left

NO.	FEATURE
3.	Planet Hub - Right
4.	Differential



Front Axle

The axles are driven by a spiral bevel gear and pinion located in the centre of the axle. Inside the rear differential centre is a slide ring for locking the centre and driving torque to both drive shafts out to the planetary wheel hubs, giving direct drive through the axles.


The rear differential locking engagement is pneumatic driven and equipped with a switch that detects the engagement and disengagement position of the slide ring. When engaged, the switch in the cabin will light up and when disengaged the light will turn off. To help with engagement and disengagement, it may be necessary to rock the Super Cruiser forward or backward to help the slide ring engage or disengage.

The front axle is an open centre and drive is transmitted through the steering knuckles and into the outer planetary hubs. The steering ram is a 50mm shaft with adjustable rod ends to adjust toe in. Camber is factory set.


Transmission

The Super Cruiser uses an Allison 3000-series transmission. Refer to the Allison Transmission operation and codes manual (supplied) for any information on operation or trouble shooting the Allison transmission.

See also Chapter 8 'Operation' for information on using the Allison transmission.



Braking System



The braking system for the Super Cruiser is hydraulically driven. The hydraulic pump mounted on the engine supplies oil to the braking circuit and gives priority to the brakes once the accumulators are fully charged. Hydraulic pressure goes from the accumulators to the foot pedal and then to the wet brake system in the front and rear axles.


If one accumulator fails, a check valve will prevent the other accumulator from losing pressure and keep enough pressure to operate the braking system.

The Park Brake in the axle, is also hydraulically driven and is actuated by a solenoid valve, with a manual override. The park brake also uses an accumulator and then a pressure reducing valve to keep the pressure from going over 35 bar.

NOTE: The Park Brake will apply at any time that there is no hydraulic pressure going into the park brake control cylinder.

NOTE: More information can be found in Chapter 10 'Lubrication & Maintenance'.

Steering System



Camber


The wheel camber is a factory set parameter. At the time of manufacture the wheel camber is set to $+0.5^\circ$.

Steering Toe-in

The wheels of the sprayer should toe-in by 0-5 mm.

Note: Information on checking camber and toe can be found in Chapter 10 'Lubrication & Maintenance'.

Suspension System



NO.	FEATURE
1.	Parallel link
2.	Shock absorber
3.	Panhard rod
4.	Sway bar (rear only)
5.	Air bag

The Five Point Suspension system used on the Super Cruiser sprayer consists of four parallel links, one Panhard rod, and 2 air bags on each axle. The rear axle of the machine is also fitted with an anti-roll sway bar.


Parallelogram links hold the axle in place under the chassis. Panhard rods hold the axle centred in the chassis. The parallelogram arms allow the drop legs to distort or twist forward and backwards when the wheels come in contact with an obstruction such as a pot hole, log or embankment. This oscillation is absorbed by polyurethane bushes on each end of the links. The life time of these bushes is subject to the conditions the sprayer operates in and the style of operation that it receives.

The polyurethane bushes should be checked at regular service intervals as advised in Chapter 10 'Lubrication & Maintenance'.

Air bags mounted on each side of the axle allow the axle to oscillate and dampen the ride.

NOTE: More information can be found in Chapter 10 'Lubrication & Maintenance'.

Transfer Case



NO.	FEATURE
1.	Input flange (From transmission)
2.	Output flange (To front diff)
3.	Drive split 50/50 - Engage/disengage - Shift cylinder air line 6 mm
4.	Output flange (To rear diff)
5.	Oil fill plug
6.	Oil drain plug
7.	Oil level plug
8.	Lock ring signal plug

The transfer case is a constant 4WD type. It is a single speed transfer case that directs drive from the transmission, to the front and rear axles. The transfer case has a centre differential lock that will split the drive 50/50 front to rear.

The differential lock is engaged from a switch located in the arm rest console in the cab. The switch activates a solenoid which sends air through a 6 mm line, to the transfer case shift cylinder (see no. 3 above). The shift cylinder is pushed in by the air and the differential lock is engaged. A light will illuminate on the differential lock switch when it is actually engaged and not just when the switch is activated.

When centre diff lock is turned off, air is released from the 6 mm line and a spring pushes the shift cylinder in the transfer case back out.

The air solenoid that switches the centre diff lock on and off is located on the chassis rail on the right hand side of the machine.

For more information on the transfer case and solenoid, see Chapter 10 'Lubrication & Maintenance'.

Chapter 6

CALIBRATION

General

Spraying is a complex task, that is affected by many variables. It is the responsibility of the operator to be familiar with spraying variables and to understand the spraying process prior to operation.

In general, the operator should know:

- The target application rate
- The required operating (spray) pressure
- The speed of travel
- The desired droplet size

To make the spray application as accurate as possible, it is critical that your spray equipment is regularly calibrated.

The Raven automatic controller is designed to improve the uniformity of spray applications. Raven controllers will monitor and control the determined application volume, but prior calculations will be required to ensure spraying pressures do not exceed operating parameters.

The Raven system comprises a console, flow meter, speed sensor and liquid flow control valve.

As the sprayer is moving, the console records ground speed and then calculates the amount of flow required to maintain the respective application rate at that speed. The console monitors the amount of flow being used via the flow meter and then determines if the flow is correct for that speed. Flow adjustments are made by the control valve which varies the amount (volume) of bypass and thus the volume being applied via the boom is controlled.

When the console is in the automatic mode, as the ground speed increases, the flow to the booms required to maintain the application volume will be increased. This will result in the pressure (as displayed on the gauge) increasing. Conversely, as the ground speed decreases, the required flow to the booms, as well as the pressure, decreases.

When the console is in the manual mode, as the ground speed increases, the pressure and flow will remain constant and the application volume will decrease. Similarly, as the ground speed decreases, again the pressure and flow will remain constant and the application rate will increase.

Record your console calibration information in the table below for future reference:


PARAMETER	VALUE	UNIT
Boom Cal 1		cm
Boom Cal 2		cm
Boom Cal 3		cm
Boom Cal 4		cm
Boom Cal 5		cm
Boom Cal 6		cm
Boom Cal 7		cm
Speed Cal		-
Meter Cal		-
Valve Cal		-
Rate 1		L/Ha
Rate 2		L/Ha
Tier 1		L/min
Tier 2		L/min
Pump Cal (1)		RPM

$$\text{L/min (per nozzle)} = \frac{\text{L/ha} \times \text{km/hr} \times \text{W}}{60,000}$$

$$\text{L/ha} = \frac{60000 \times \text{L/min (per nozzle)}}{\text{Km/hr} \times \text{W (metres)}}$$

$$\text{Km/hr} = \frac{\text{Metres} \times 3.6}{\text{Time (seconds)}}$$

Control Valve & Flow Meter Locations



Control Valve

The flow control valve regulates the flow going to the boom sections directed via the console. It controls the flow to the boom by regulating the amount of liquid that bypasses back to tank.

The flow control valve is a positive ball valve which means it can control flow infinitely to the boom.

from 0 L/min to the maximum pump output, dependant on system pressure.

The flow control valve can be operated in manual mode from the console for boom priming, flushing and also troubleshooting.

Flow Meter Calibration - Raven

If the sprayed volume from the controller does not match the tank volume that was sprayed out, then the flow meter will need to be checked and a new updated figure input into the 'Meter Cal' in the Raven controller:

- On the flow meter on the sprayer, there will be a calibration number attached to it on a white sticker. The number that is applicable is the one in square brackets, i.e. [185]. Note this number down as this is the number that should be entered as the 'Meter Cal' number.

- The flow meter should be checked at the start of every spraying season and periodically during the season.
- The simplest way to check the accuracy of the flow meter is to fill the tank to a previously determined volume mark (usually top fill marking), while making sure the tank is level.
- On the Raven controller, make sure the 'Total Volume' reads '0'.

Continued over page

Flow Meter Calibration - Raven

- Perform a self test, choose a high speed and high rate so that the tank will empty relatively quickly but make sure the pressure does not exceed 60 PSI.
- When the tank is empty, on the Raven controller press 'Total Volume' to read what the Raven flow meter has output to the boom. Record the reading.
- Check the volume of the tank to see what has been sprayed out to the boom. Record the reading.
- Compare the reading from the controller with the known volume from the tank. If there is a relatively large discrepancy (i.e. more than 50 litres out of a 3000 litre tank), the flow meter should be removed from the sprayer, disassembled and the condition of the turbine checked and cleaned. It should be able to spin freely.
- The flow meter should then be reassembled and replaced on the sprayer. Perform the volume check again and if there is still a discrepancy, the 'Meter Cal' value can be changed
 - i.e. If volume from the controller reads 3100 litres instead of 3000 litres and the original Meter Cal value is 185, then:

$$\text{New 'Meter Cal' value} = (185 \times 3100) / 3000 = 191$$

Every sprayer should be calibrated regularly to ensure minimal error in the application rate. A nozzle selection chart indicates what application rates are to be expected. Variations due to nozzle wear, ground speed error and pressure irregularities can all add up to result in large application rate errors.

Nozzle Calibration

As part of your daily sprayer calibration, Goldacres recommends you carry out a simple "jug test" to ensure the spray nozzles you are using are delivering the correct amount of chemical, as stated in your nozzle supplier's rate chart.

Jug Test

The method of carrying out the "jug test" is described below.

You will need:

- A calibrated measuring container that can measure the medium in litres, in 10 ml increments. e.g. 0.45 L.
 - A timing device that counts seconds.
 - A pressure gauge mounted at the nozzle tip to verify the system pressure being delivered at the nozzle. Goldacres part number GA5077983 will enable mounting of a suitable gauge to the nozzle body bayonet fitting (not including gauge).
1. Check the plumbing system for kinked or obstructed hoses and repair or replace any hoses that might restrict the normal flow of the liquid.
 2. Start your sprayer and initiate a 'self test' procedure on your rate controller console. Set the application rate and speed to the values given in your rate chart that match your desired spray output.
 3. Then place the jug under one of the nozzles, for exactly 1 minute and record the volume of liquid collected.
 4. Repeat the test over a representative sample of the jets in each boom section.
 5. Compare the volume collected from each nozzle to the stated volume in your nozzle supplier rate chart. Variation should be no more than plus or minus 10 %.

Continued over page

Nozzle Calibration

In the event that any of your nozzles do not deliver the required volume, a further investigation is required. This may include, but not be limited to;

- Cleaning the nozzles using the method recommended by the nozzle supplier
- Replacing the nozzles
- Teejet advise that nozzles that flow greater than +10% of their stated volume are 'worn out' and should be replaced
- Cleaning nozzle filters

NOTE: Uneven volumes from individual nozzles will result in variations in the application rate across the width of the boom. Spray efficiency will be reduced. **Crop damage may result.**

Speed Sensors

Raven automatic rate controllers can utilise a speed reading from the:

- Transmission Output
- GPS receiver

Transmission Output

When the transmission output is used for speed the system must be set as if it were reading a radar sensor (SP2).

GPS receiver

If a GPS unit is fitted, GPS ground speed can be obtained and used in place of the transmission output.

To receive a speed reading from the GPS unit a **pulsed niema** string must be connected to the speed cable of the console. The console must then be set up to accept GPS speed. This is called radar in the console calibration settings. When using GPS the console speed cal figure is 200 initially and then can be fine tuned from this figure. See 'Calibration' chapter for further information on console setup.

If you have any further questions, Goldacres recommends that you contact your nozzle supplier or your Goldacres dealer for additional information.

Download your free copy of 'A user's guide to spray nozzles' from the Teejet website. Also Lechler nozzle selection catalogue and Users guides to spray nozzles are available from your Goldacres dealer; or as a free download from the Teejet web site: www.teejet.com or Lechler web site: www.lechler.de

Raven SCS4400 Console Calibration

The following information is a condensed version of the Raven installation and service manual. It is designed to provide sufficient basic information to enable the new unit to be calibrated before spraying is commenced. For more detailed information about console features, consult the Raven installation and operational manual.

It is imperative that the Raven console is correctly programmed, as the system will only work as accurately as the programmed information entered. The Raven 4000 series consoles are very similar however there may be slight differences during calibration - for specific information please refer to the Raven operator's manual supplied with the machine.

NOTE: While proceeding through the initial console programming write down all relevant calibration values for future reference.

The following steps are very important because the system will appear to function properly but be very inaccurate if values are incorrectly entered.

STEP 1 - TURNING THE CONSOLE ON

1. Turn the console 'ON' by momentarily depressing the [POWER] key.
2. Instruction for adjusting the contrast should now be displayed

NOTE: If this is not displayed or if an incorrect entry is made during programming turn the console power switch 'OFF' depress and hold the [CE] key while turning the power switch back "ON". This procedure resets the console.

3. Adjust the screen contrast as directed by depressing and holding the or keys.
4. When the desired contrast is achieved depress the [ENTER] key.
5. The display should now flash the word "CAL" and prompt for a "UNIT OF MEASURE" to be selected.

STEP 2 - UNITS OF MEASURE

1. Momentarily depressing the [CE] key repeatable at this stage toggles the console through the "UNITS OF MEASURE" selection.
2. To operate in litres/hectare ensure "UNITS SI METRIC HECTARES" is display.

3. Then depress the [ENTER] key to lock it in.
4. The console will now prompt for a "PRODUCT TYPE" to be selected.

STEP 3 - PRODUCT TYPE

1. Momentarily depressing the [CE] key repeatedly at this stage toggles the console between "LIQUID" and "GRANULAR" control selections.
2. Sprayers require the selection of "LIQUID CONTROL" to function correctly. (Granular control would be selected when using a fertilizer spreader or air seeders).
3. Ensure "LIQUID CONTROL" is displayed then depress the [ENTER] key to lock it in.
4. The console will now prompt for a "VALVE TYPE" to be selected.

STEP 4 - VALVE TYPE

To select the correct valve type:
Labelling on the side of the flow control valves provides information on the "VALVE TYPE" ("VALVE CAL" information is also on the label and will be required in step 6 below).

Momentarily depressing the [CE] key repeatedly at this stage toggles the console through the various valve types. "FCV" is for SCS4400 (fast close valve).

1. Ensure correct "VALVE TYPE" is displayed as labelled on the valve then depress the [ENTER] key to lock it in.
2. The console will now prompt for a "METER CAL" value to be entered.

STEP 5 - METER CAL

All Raven flow meters are pre-calibrated. The calibration tag is attached to the transducer wire directly adjacent to the flow meter. The metric calibration number is the number in [square brackets] i.e. [185].

To enter the meter calibration figure first:

1. Depress the [ENTER] key.
2. The console will now display "E" enter symbol on the bottom right hand side of the calibration screen.
3. Key in the correct calibration number (i.e. 185).
4. Depress the [ENTER] key again to lock it in.

Continued over page

Raven SCS4400 Console Calibration

5. The console will now prompt for a "VALVE CAL" value to be entered.

NOTE: When entering any calibration figures during the calibration process the [ENTER] key must first be depressed momentarily to display the "E" enter symbol. The "E" indicates the console is ready to accept a calibration figure. After keying in a figure the [ENTER] key must be depressed again to lock the new value in before moving on to the next step.

STEP 6 - VALVE CAL

The [VALVE CAL] value is located on the side of the flow control valve together with the "VALVE TYPE" "FAST CLOSE VALVES" have a value of [743].

To enter the value calibration figure:

1. Depress the [ENTER] key to display the "E" enter symbol.
2. Key in the appropriate [VALVE CAL] calibration number as printed on the side of the flow control valve.
3. After keying in the appropriate valve calibration number depress the [ENTER] key again to lock it in.
4. The console will now prompt for a [RATE CAL] number to be entered.

STEP 7 - APPLICATION RATE

[RATE CAL] is the rate (litres/hectare) desired for the particular application

NOTE: Before entering an application rate consult the nozzle application chart (in the operators manual or the Tee Jet catalogue) to ensure the rate is within the speed and pressure capabilities of the nozzles fitted to the boom.

To enter a [RATE CAL]:

1. Depress the [ENTER] key to display the "E" enter symbol.
2. Key in the desired application rate (i.e. 50 L/ha).
3. Depress [ENTER] again to lock it in.
4. The console will now prompt for a "SPEED SENSOR TYPE" to be entered

NOTE: If the console detects the presence of a 2nd product it will automatically interrupt the programming procedure at this point and request values be entered for PRODUCT TYPE, VALVE

TYPE, METER CAL, VALVE CAL, and RATE for this 2nd product. The console will then revert back to STEP 8 if a 3rd product is not detected. If a 3rd is detected the console will automatically request the information be entered for this product before continuing on to STEP 8 below.

For SCS 4400 console connected to a chemical injection pump(s) see separate section on SCS 4400 chemical injection pump programming, in the "DCI" chapter for further details.

STEP 8 - SPEED SENSOR TYPE

Before proceeding in this step first identify which type of speed sensor the console is connected to.

Transmission output or Raven GPS:

1. Momentarily depress the [CE] key repeatedly to toggle through the selection of "SPEED SENSOR TYPES" until "SPEED SENSOR RADAR SP-2" is displayed.
2. Depress the [ENTER] key to lock it in and the console will now prompt for a "SPEED CAL" number to be entered.

STEP 9 - SPEED CAL

Before a [SPEED CAL] figure can be entered a speed calibration value must first be ascertained. The method for calculating a speed calibration figure varies depending on the type of speed sensor the console is connected to

For consoles connected to a transmission output:

Use an arbitrary [SPEED CAL] value of [200]

To enter this value:

1. Depress the [ENTER] key to display the "E" enter symbol.
2. Key in the appropriate [SPEED CAL] number.
3. Depress the [ENTER] key again to lock it in.
4. The console will now prompt for a "BOOM CAL I" number to be entered.

NOTE: This is an arbitrary value only and will require correcting; using the following procedure, once the remainder of the programming procedure is completed.

To recalibrate a [SPEED CAL] value once initial console programming is complete:

1. Accurately mark and measure 100 metres.

Continued over page

Raven SCS4400 Console Calibration

2. With the power switch "on" and all other switches "Off"
3. Depress the [DISTANCE] key.
4. Depress the [ENTER] key to display the "E" enter symbol.
5. Key in a "0" value.
6. Then depress the [ENTER] key again to lock it in.
7. Drive the 100 metres, being careful not to accelerate or decelerate too suddenly.
8. Record the distance that the console displays once the 100 metres has been travelled.
9. The distance should read 100. If it reads between 99 or 101 this calibration value will be correct. If the distance reads any other value perform the following procedure.

NEW [SPEED CAL] VALUE = OLD [SPEED CAL] VALUE X 100

RECORDED DISTANCE

NOTE: Redo the distance check again to confirm the new [SPEED CAL] value is correct.

For consoles connected to a Raven GPS:

Use a Speed Cal figure of [785] (standard speed cal figure for all Raven GPS units).

To enter this value:

1. Depress the [ENTER] key to display the "E" enter symbol.
2. Key in the appropriate [SPEED CAL] number.
3. Depress [ENTER] again to lock it in.
4. The console will now prompt of a "BOOM CAL 1" value to be entered.

This value can be checked once initial console programming is complete by using the same procedure for recalibrating a [SPEED CAL] value for a radar speed sensor above.

STEP 10 - BOOM SECTIONS

The console needs to know the width of each section so it can calculate;

1. The total flow rate required.
2. The area applied.

As boom sections are turned on or off the console

increases or decreases the theoretical width of the boom accordingly in order to calculate the correct flow rate (total L/min to the boom) and the total area sprayed.

To measure the width for each boom section, count the number of nozzles in each section and multiply by the nozzle spacing. i.e. 12 nozzles in one section at 50cm (½ metre) spacings = 12 x 0.5m = 6m

All Boom Sections must be entered in Centimetres (for example 6m = 600cm) so the correct Boom Cal in this example would be 600.

To enter a [BOOM CAL] figure for boom 1:

1. Ensure boom 1 is displayed.
2. Depress the [ENTER] key to display the "E" enter symbol.
3. Key in the boom width in centimetres for boom 1.
4. Depress the [ENTER] key to lock it in.

NOTE: At this point the console does not proceed automatically to boom 2.

5. To proceed to Boom 2 depress the [UP] key momentarily.
6. Depress [ENTER] and key in the calibration figure for boom 2.
7. Depress the [ENTER] key again to lock it in.

Depress the key and continue entering the [BOOM CAL]'s in the remaining boom sections. If a boom section is not utilised ensure "0" is entered in that section or the console will fail to function correctly.

INITIAL PROGRAMMING IS NOW COMPLETE.

If the sprayer is fitted with the 3TS option see the separate section on Raven SCS 4400 3TS dual boom operation and programming.

NOTE: Each time the console power switch is turned "on" the products automatically default to the "OFF" mode. Before commencing spraying the product must be changed to the "AUTO" mode.

To change to the "AUTO" mode:

1. Momentarily depress the [PRODUCT ON/OFF] key to turn the product "ON". At this point the console should read "AUTO NOBM" (auto no boom).
2. If it reads "MAN NOBM" (manual no boom)

Continued over page

Raven SCS4400 Console Calibration

momentarily depress the [AUTO/MANUAL] key to switch to the product to the auto mode.

The "NOBM" (no boom) component automatically disappears when the console senses the switching "on" of a boom section.

If you wish to change a calibration figure for Boom Cal, Speed Cal, Meter Cal, Valve Cal or Rate Cal (application rate) at any time simply depress the appropriate key i.e. [BOOM CAL], then the [ENTER] key to display the "E" enter symbol, key in the new calibration number and depress the [ENTER] key again to lock it in.

If you wish to view the Units of Measure, Product Type, Valve Type or Speed Sensor Type depress and hold down the [SELF TEST] key and the console will flash through the various values entered.

If you wish to change the Units of Measure, Product Type, Valve Type or Speed Sensor Type continue holding down the [SELF TEST] key for 20 seconds until the console stops on "UNITS OF MEASURE" and flashes "CAL". Once "CAL" is displayed release the [SELF TEST] key.

At this point repeatedly depressing the [CE] key momentarily will toggle the console through the various options in each step and depressing the [ENTER] key will lock it in and/or move on to the next step. To exit this function at any time continue momentarily depressing the [ENTER] key until the console reverts back to "SELF TEST" and discontinues flashing "CAL".

STEP 11 - PUMP RPM - REQUIRED WHEN PUMP IS HYDRAULICALLY DRIVEN

For RPM to be displayed on the console screen the sprayer must be fitted with a pump RPM sensor.

To activate the pump RPM display on the console screen:

1. Depress the [DATA MENU] key to display the data sub menu at the bottom of the screen. The word "SERIAL" will be highlighted.
2. Depress [DATA MENU] key again and the highlight will move down to "PRODUCT".
3. Momentarily depress the [DOWN] key repeatedly to move the cursor down until page 2 is displayed.
4. Continue momentarily depressing the [DOWN]

key repeatedly until the cursor is adjacent to "PUMP CAL".

5. Depress the [ENTER] key to display the "E" (enter symbol).
6. Key in a value of pulses per revolution (normally one)
7. RPM should now be displayed in the top right hand corner of the screen.
8. Depress a volume or area key to exit the data sub menu and return to the operational screen.

STEP 12 - LOW FLOW LIMIT

This feature, when activated, stops the console controlling the flow rate below an assigned limit to prevent boom line pressure falling too low resulting in fan angle collapse or nozzle check valve closure.

This feature is particularly useful in row crop situations to prevent 'under- application' at the start and end of a row.

In this mode the console effectively defaults to an 'over-application' mode during periods when the sprayer is unable to maintain the minimum speed required for a particular application rate.

NOTE: This feature must not be used with chemicals that have poor crop selectivity and will cause damage to the crop if 'over-applied'. Check with your chemical supplier for more details on chemical/crop selectivity before using this feature.

The SCS 4400 also has the added ability to control to this minimum flow rate value. To activate this feature a minimum flow rate value must be calculated and entered into the console.

To calculate a minimum flow rate refer to the relevant nozzle chart for the nozzle type/size fitted to the sprayer. Nozzle charts can be found in the operator's manual or the TeeJet catalogue.

From the nozzle chart determine the flow rate of the nozzle used at the minimum recommended operating pressure. Multiply this figure by the total number of nozzles fitted to the entire boom line to obtain the "LOW FLOW LIMIT" value.

NOTE: This minimum flow rate value is automatically proportioned as boom sections are turned on and off. Thus a minimum pressure will be maintained regardless of boom section status.

Continued over page

Raven SCS4400 Console Calibration

ENTERING A LOW FLOW LIMIT VALUE:

1. Depress the [DATA] key to bring up the data submenu at the bottom of the screen. The word "SERIAL" will be highlighted.
2. Depress the [DATA] key again to highlight "PRODUCT".
3. Momentarily depress the key repeatedly to move the cursor adjacent to "LOW LIMIT".
4. Depress the [ENTER] key to display the "E" (enter symbol).
5. Enter the "LOW FLOW LIMIT" value calculated.
6. Depress the [ENTER] key again to lock it in.
7. Depress a volume or area key to exit the data submenu and return to the operational screen.

STEP 13 - TO ZERO INFORMATION WHEN STARTING A NEW LOAD

When starting a new load, the previous Area and Volume data in the console can be reset using the following procedure;

"TANK VOLUME" gives the operator a reference as to the number of litres left in the tank as the load is progressively applied to the field. For this feature to function correctly the estimated volume in the tank must be entered before application of the new load is commenced. A Raven Fill-flow meter can be used to more accurately determine tank volume particularly if using partial tank loads.

1. Depress the [VOLUME TANK] key.
2. Depress the [ENTER] key to display the "E" enter symbol.
3. Enter the volume of liquid actually in the tank at the start of the load.
4. Depress [ENTER] again to lock it in.

NOTE: The console will subtract the litres used (count down) from this value as the load is applied to the field giving the operator a reference as to the number of litres left in the tank.

TO ZERO OUT DATA IN AREA AND VOLUME:

NOTE: Before resetting the Area and Volume functions record any previous data in the console that maybe applicable for future use.

To reset an Area or Volume value:

1. Depress the relevant key relating to the value to be reset. For example [TOTAL AREA], [TOTAL VOLUME], [FIELD AREA] or [FIELD VOLUME].
2. Depress the [ENTER] key to display the "E" enter symbol.
3. Enter a value of "0" to reset the particular function.
4. Depress the [ENTER] key again to lock it in.

The Area and Volume will now count up from zero for the new field.

[FIELD AREA] and [FIELD VOLUME] are generally use as sub-totals for [TOTAL AREA] and [TOTAL VOLUME].

For example if applying several tank loads to the one area [FIELD AREA] and [FIELD VOLUME] can be use to record data for the current tank load while the [TOTAL AREA] and [TOTAL VOLUME] can be used to record accumulative data for the whole area. If [TOTAL AREA] and [TOTAL VOLUME] are used to accumulate data do not reset them until starting a new area.

WARNING: The [self test] feature should never be used with chemical in the tank.

WARNING: Do not use the self test function with the booms in the transport position.

TO SIMULATE A SPEED:

1. Depress the [SELF TEST] key momentarily.
2. Depress [ENTER] key to display the "E" enter symbol.
3. Key in a desired test speed. Note this feature has a decimal point so a "0" needs to be added when entering a whole figure. For example 1, 6 and 0 for 16 Kph.
4. Depress the [ENTER] key again to lock it in.

A desired test speed should now be displayed in the speed window at the lower left corner of the display

Spraying can now be simulated by simply turning on the boom switches.

The [SELF TEST] feature will automatically clear itself when motion is detected from the speed sensor.

NOTE: Some radar and GPS units may sense motion when the sprayer is stationary thus continually clear this function. To counteract this simply unplug the

Continued over page

Raven SCS4400 Console Calibration

speed sensor connection in the fuse box area whilst using this function.

USING THE FLOW METER TO CALIBRATE THE TANK:

1. Enter in the Meter Cal value as given on the white Calibration sticker on the Flow meter.
2. Enter all the other calibration information needed to enable the console to work.
3. Fill the tank to the top mark with water (i.e. 2500 or 3000 etc.). Make sure the tank is level.
4. Make sure the Total Volume reads "0"

Press [TOTAL VOLUME] then [ENTER] Enter "0" then [ENTER]

5. Perform a self-test. (Choose a relatively high speed and high rate so that the tank will empty relatively quickly but make sure the pressure does not exceed 60 psi).
6. When the tank is empty press [TOTAL VOLUME] to read what the Raven Flow meter has output to the booms.
7. If there is a large discrepancy (i.e. the difference between theoretical tank volume and Flow meter volume is greater than 100 litres), alter the Meter Cal value accordingly. For example: If volume reads 3100 litres instead of 3000 litres and the original Meter Cal value is 185.

New 'Meter Cal' value = $(185 \times 3100) / 3000 = 191$

8. Enter in new Meter Cal value and repeat procedure (Step 3 to Step 6). Continue to re-iterate the Meter Cal value until the desired volume accuracy is achieved
9. Write down the appropriate Speed Cal value for future reference.
10. Re-fill the tank to the top mark and perform the self test again. Stop the self test after every 200 litres has been pumped out (read by pressing [TOTAL VOLUME] and check how the water level compares with the appropriate tank calibration mark.

(i.e. After 200 litres has been pumped out there is 2800 left in a 3000 litre tank).

There may need to be extra marks put on tank to indicate where the actual tank calibration levels are.

3TS - Boom Tier Programming

NOTE: 3TS boom tier programming can only be carried out if initial console programming has been completed (see Raven SCS4400 Console Calibration section).

For boom tiering to operate, flow rate values (L/min) have to be entered into the console. The console automatically starts on the first tier when the boom master switch is turned "on" but it needs reference points entered to be able to determine when it should change to the second and third tiers. Thus to achieve the three tiers two flow rate values have to be entered.

Before these figures can be entered the maximum flow rate (L/min in total to the boom) for each tier must be calculated.

Using a nozzle chart determine the flow rates (for a single nozzle) at which point you wish the console to change tiers. These points are best determined by ascertaining the minimum pressure and thus the corresponding flow rates at which point you wish the next nozzle to cut in. Care must be taken to ensure these minimum pressure/flow rate settings do not exceed the maximum recommended operating pressure of the preceding nozzle.

For example: If you had XRI 10015 and XRI 10025 nozzles fitted to the sprayer the minimum pressure that the XRI 10025's can cut in at is 1.0 bar. The flow rate for an XRI 10025 nozzle at 1.0 bar is 0.57 L/min. The maximum operating pressure for an XRI 10015 is 4.0 bar, at which point the flow rate is 0.68 L/min, so this combination of nozzles overlap nicely. In actual fact the XRI 10025 would cut in at slightly less than 3 bars if the first set point was programmed at the 0.57 L/min.

To determine the second set point of the 3rd tier, first ascertain the minimum pressure you wish the combination of the two nozzles to operate at. Then add the corresponding flow rates at this pressure for the two nozzles together to form the second set point.

For example: If you wanted the 3rd tier to cut in at one bar you would add the flow rates for the XRI 10015 and XRI 10025 at one bar together ($0.34 + 0.57 = 0.91$ L/min). Again care must be taken to ensure this minimum pressure/flow rate setting does not exceed the maximum recommended operating

pressure/flow rate of the preceding nozzle. At 0.91 L/min the preceding XRI 10025 nozzle would be operating at slightly over 2.5 bars before the 3rd tier would cut in. Again a nice overlap.

NOTE: The flow rate values entered into the console for the tier interchange points must be the sum total of all the nozzles on one entire boom line.

For example: A 30 metre boom with 50 cm nozzle spacings has 60 nozzles on one boom line, therefore $60 \text{ nozzles} \times 0.57 \text{ L/min} = 34.2 \text{ L/min}$ which would be the tier 1 max rate value for the example above.

The tier 2 max rate would be $60 \times 0.91 \text{ L/min} = 54.6 \text{ L/min}$.

NOTE: The above example is based on a 30 metre broad acre boom. Some booms may have different nozzle spacings or layout (i.e. row crop) so it's important to count the total number of nozzles on the first line to ensure the correct Tier Value is calculated and entered.

The pressure figure of one bar is an example only. Other trigger point pressures may be selected.

NOTE: Care must be taken to ensure there is sufficient pressure overlap between the tiers otherwise spray drift or poor efficacy may result.

NOTE: The consoles won't accept tier values containing decimal points so values calculated with decimal points require rounding off to the nearest whole figure before entering.

TO ENTER THE TIER VALUES:

1. Depress and hold down the [BOOM CAL] key for 5 seconds until "TIER 1 HIGH VOL PER MIN" is displayed.
2. Depress the [ENTER] key to display the "E" (enter symbol).
3. Key in the first tier interchange value and depress [ENTER] again to lock it in.
4. To enter the second tier interchange point depress the key and "TIER 2 HIGH VOL PER MIN" will be displayed.
5. Depress the [ENTER] key again to display the "E" (enter symbol).

Continued over page

3TS - Boom Tier Programming

6. Key in the second tier interchange value and depress [ENTER] again to lock it in.
7. Depress the key again and "PERCENTAGE TIER DISABLE" will be displayed.

The default setting for this function is "10" which means the tiers will overlap 10% above the entered tier values on the 'up-change' and 10% below on the 'down-change'.

This function is useful if the sprayer is operated at a speed and/or rate that coincides with a tier change point. If this scenario occurs the console will tend to hunt between tiers unless a percentage overlap figure is entered. Maintaining the 10% tier disable value at this point will reduce this 'hunting' tendency.

Keep in mind that the pressures will rise over and fall under the set tier value by the percentage entered. For example if a value of 10% is entered the pressure will rise 10% above the set tier interchange point before a tier 'up-change' will occur and correspondingly fall 10% below the value before 'down- changing'. If using this function ensure the tier interchange points are calculated with this expanded pressure range in mind otherwise the sprayer may operate outside the recommended operating pressure range of the nozzle.

If the nozzles or tier values selected allow for very little or no pressure overlap a "PERCENT TIER DISABLE" value of "0" must be selected:

1. To enter a "PERCENT TIER DISABLE" value depress the [ENTER] key to display the "E" (enter symbol).
2. Key in the desired percentage overlap and depress the [ENTER] again to lock it in.
3. Press a volume or area key to exit this function and return to the operational screen.

SCS4400 & 2TS

The SCS 4400 3TS system can be set up to operate in a 2TS mode if the operator wishes to use the same size nozzles in both boom lines.

In the 2TS mode the console will start the sprayer on one line then turn the second line on in conjunction with the first at a predetermined point. It effectively does away with the first tier interchange

point of the 3TS system where one boom line is turned "on" whilst the other is turned "off" (obviously this step is superfluous if the same size nozzles are fitted to both boom lines).

TO SET THE CONSOLE UP IN THE 2TS MODE:

1. Depress and hold down the [BOOM CAL] key for 5 seconds until "TIER 1 HIGH VOL PER MIN" is displayed.
2. Depress the [ENTER] key to display the "E" (enter symbol).
3. Key in a value of "1".
4. Depress the [ENTER] key again to lock it in.

By entering a value of "1" the console will automatically proceed and start on the second tier.

To calculate the second tier interchange value: From the nozzle chart in the operator's manual or the TeeJet catalogue locate the minimum recommended operating pressure and corresponding flow rate (L/min) for the nozzle size and type fitted to the sprayer.

NOTE: If operating the sprayer in the 2TS mode the same size and type of nozzles should be fitted to both boom lines.

Multiply this value by 2 then by the total number nozzle on one entire boom line.

For example: Using a 30 m broad acre boom fitted with XRI 1002 nozzles.

The minimum recommended pressure for an XR nozzle is 1 bar. The flow rate for an XRI 1002 nozzle at 1 bar is 0.46 L/min. Thus the second tier interchange value will be $0.46 \times 2 \times 60$ (2 nozzles/meter) = 55.2.

NOTE: The console will not except tier values containing decimal points so round any values calculated with decimal points off to the nearest whole number before entering.

So the value entered in this example would be 55.

Continued over page

3TS - Boom Tier Programming

Continuing on from above to enter the second tier interchange point:

1. Depress the key and "TIER 2 HIGH VOL PER MIN" will be displayed.
2. Depress the [ENTER] key again to display the "E" (enter symbol).
3. Key in the second tier interchange value and depress [ENTER] again to lock it in.
4. Depressing the again will display "PERCENT TIER DISABLE" (see instruction above on setting this value).
5. Depress and volume or area key to exit this function and return to the operational screen

NOTE: That if either tier value is set to zero then the boom valves will not open.

Chapter 7

PRE-OPERATION

Preparing Sprayer For Use

WARNING

If spraying is to be done at night, ensure that adequate lighting is available around the sprayer and the area to be sprayed.

- The amount of lighting around the sprayer needs to be sufficient for all labels and warnings on the sprayer to be clearly visible to the operator.
- The amount of lighting in the area to be sprayed needs to be sufficient for obstacles in the path of the sprayer to be clearly visible to the operator.

Before Starting Sprayer in Cold Conditions

- If the sprayer has been in a cold environment, always check components to make sure that they have not been damaged and that there is no ice in the system before starting spraying. If the water has frozen in the pump and/or in the lines, wait until it has completely thawed before use.
- Inspect the sprayer to ensure there is no damage or wear which could lead to injury, further damage or reduced performance.
- Check all hoses and fittings for leaks or damage. Check the sprayer to ensure frosts and/or vermin have not damaged the machine, and that the tyres are correctly inflated.
- Check the engine oil, water and fuel.
- Check that all of the lights are working correctly.
- Check all bolts and nuts to make sure they are tight and secure.
- Complete the scheduled lubrication.

NOTE: Proper grease is essential for the sprayer to operate with maximum effectiveness and life-expectancy. It is important to keep the lubricant and lubricant applicator clean. Wipe all dirt from the fittings before use.

Goldacres recommends that multi-purpose grease should be used for all lubrications. Make sure all open-end bearings are lubricated their full length by forcing lubricant into them until it begins to appear at the sides. Protect all surfaces with corrosion inhibitor G15.

- Be sure to adequately clean and flush all chemical handling equipment.
- All spray equipment should be cleaned at the start and end of each spray season including all filters and nozzles.
- Test the pump with clean water. Switch on the pump at the lowest revs possible and then gradually increase revs until the pump reaches its operating speed. Do not exceed 540 RPM.
- Check nozzle patterns for irregularities. If there are irregularities, clean the nozzles and refit. If the problem persists they could be worn so remove and replace.
- Make sure there is a sufficient quantity of clean water in the rinse water tank in case of a chemical accident.
- Arrange communication with someone who can come to your aid if need be.

Sprayer in Transit

The machine is approximately 4.3 m in height and with aerials on the roof, can be much higher. Check the regulations in your state for maximum vehicle height restrictions. When driving the Super Cruiser on roads it may be necessary to remove aerials to meet the required height restrictions.

Aerials on the roof may also need to be removed to meet clearance requirements for over head power lines, while on the road and also in some paddocks.

Continued over page

Preparing Sprayer For Use

Overhead Power Lines

Check any areas to be sprayed for overhead power lines. If there are any in the area, contact the relevant energy provider for information on safe use of machinery near live lines.

DANGER: Check area to be sprayed for over head power lines. Contact between the machine and power lines can result in serious injury or death. If there are power lines in the spray area, exercise extreme caution when tilting boom wings.

DANGER: Do NOT walk on machine platform when near power lines.

Spray Calibration

Flow meter and spray nozzle calibration should be checked regularly to ensure that correct application rates are maintained. Refer to Chapter 6 'Calibration' for procedures to check and alter calibration if required.

Maintenance

Correct servicing and maintenance of the Goldacres Super Cruiser Sprayer will ensure the efficient safe operation of the sprayer. Servicing and maintenance should be carried out according to the schedule in Chapter 10 'Lubrication & Maintenance'.

During The First 8 Hours Of Operation - Checks

Torque Settings

- Check the torque on retaining nuts frequently.
- The wheel nuts should be checked to ensure that 350 ft/lb is maintained.

Engine

- If the engine has been running, take extra care around hot engine parts such as the exhaust.
- Check the engine oil level frequently. Due to the "bedding in" of the engine components and additional friction between connecting parts, expect the oil usage to be higher than normal.
- Avoid excess engine idling.
- Inspect the air intake system and check for leaks.

Lubrication & Hydraulic Fluids

- Maintain correct hydraulic oil levels and monitor the oil temperature on a regular basis.
- Check the transmission oil level and ensure that grease points are lubricated effectively. Crush Hazard Warning (refer to Chapter 2 'Safety').
- Inspect for leaks in the hydraulic system

Tank Retaining Strap Bolts

- The tank retaining strap bolts should be checked to ensure that they have not become loose.

Pump Mounting Bolts

- The pump mounting bolts should be checked to ensure that they are not loose.

Suspension Bolts

- There are numerous suspension bolts located at each end of the parallel links and at each end of the pan hard rods and sway bars. These bolts should be checked to ensure that they have not become loose.

Lights

- Check each light around the vehicle for correct operation.

Starting

Before operating the machine all fluid levels must be checked in accordance with this manual.

The battery isolator switch must be engaged to provide power to the machine systems.

To start the engine, the transmission must be in neutral.


Insert the ignition key and turn clockwise. The ignition key is located on the rear right console.

Key Positions

The key has 4 positions, however only the first 3 are used on this machine.

1. Off, vertical position.
2. On/accessories, in this position all cabin components will be energised.
3. Not Used.
4. Start, this is a momentary position which can only be achieved by holding the key hard in this position, the engine will be cranking if the transmission is in neutral. Once released the key will return to the On/accessories position.

To shut down the engine rotate the ignition key counter clockwise until in the vertical 'Off' position.




Shut Down

1. Bring the machine to a complete stop.
2. Place the gear selector in NEUTRAL.
3. Activate the park brake switch. The ladder will go down.
4. Turn the key to the OFF position.
5. Wait for a minimum of 30 seconds before turning the isolator switch to OFF. This allows time for the engine data to be saved back to the ECM.

Chapter 8


OPERATION

Machine Key Features



NO.	FEATURE	NO.	FEATURE
1.	Diaphragm pump	11.	Pressure gauges (view from inside cab)
2.	EZ control	12.	Boom paralift
3.	Fill point	13.	Boom rest
4.	Hand wash tank (under ladder)	14.	Boom inner wing
5.	Induction hopper	15.	Boom hinge
6.	Main tank lid	16.	Boom outer wing
7.	Flow meter	17.	Boom tip
8.	Access ladder	18.	3-D breakaway
9.	Fresh water tank (on right side, mid)	19.	Suction filter & tap
10.	Main tank		

EZ Control Station



NO.	FEATURE	NO.	FEATURE
1.	Main tank rinse (external water)	10.	RPM raise switch
2.	Main tank rinse (recirculate)	11.	Pod light switch
3.	Main tank agitation	12.	Main tank fill ball valve
4.	Rinse tank fill (external water)	13.	Rinse tank drain
5.	Three way ball valve handle	14.	Chemical probe venturi
6.	Spray pump switch	15.	Main tank 3" fill point (direct to tank)
7.	Rinse tank switch	16.	Main tank 3" fill point (hydraulic pump)
8.	Hydraulic fill pump switch (optional)	17.	Micromatic rinse socket (optional)
9.	Wash down gun switch	18.	Chemical probe pump

EZ Control Station - Key Functions

EXTERNAL WATER DELIVERY	USE
Main tank rinse (external water source)	Turning on this function allows the use of the tank rinse nozzles with larger quantities of fresh water making it useful for a more thorough flushing/decontamination.
Rinse tank fill	Used to fill the rinse water tank.

NOTE: These functions are only available when external water is being pumped into the system.

PRESSURE DELIVERY	USE
Vortex induction hopper	Turn ON to use vortex induction hopper
Chemical Probe Venturi	Turn ON to use chemical probe
Main tank agitator	Turn ON to activate agitator
Bypass	Turn ON bypass when in spray mode
Main tank rinse (recirculate)	Turning ON allows flow to recirculate through system for a more thorough flushing/decontamination.

NOTE: These functions only available when the main spray pump is operating - pressuring the system.

Suction Filter

The suction filter tap is plumbed before the filter housing. The suction filter receives fluid from either the rinse water tank or the main spray tank. Therefore, all fluid to be sprayed or flushed through the system passes through this filter. Fluid supply to the suction filter is controlled by an electronically operated valve. The valve can be activated either from inside the cabin or a switch on the right hand side Pod (EZ control station).

NOTE: Running the main spray pump dry will damage it. The main spray pump must be OFF when switching from main spray tank to rinse water tank and vice versa.

Filter Removal


For information specific to your circumstances, the spraying equipment being used and the chemicals being applied, consult your agronomist or chemical supplier.

WARNING: Always wear the recommended personal protective equipment and use caution while working with chemicals.

To remove the suction filter bowl, follow the steps below.


NOTE: A quantity of fresh water will need to be in the rinse tank.

1. Set the tap handle in the CLOSED position.
2. Loosen the nut holding the filter bowl slowly. Take care as some chemical may dribble out.
3. Suction on the filter bowl can be relieved by briefly OPENING the tap for about 2 seconds and then off again. This will cause the filter bowl to drop and become loose. Stand clear of bowl and be sure to catch any chemical coming out in a suitable container.
4. Once chemical has stopped coming out of the filter, unscrew the nut fully to remove the filter bowl. Be careful when removing the bowl as there may still be some chemical in it.
5. Clean the screen and the O-rings, then refit and ensure that O-rings are in place.




Above: The electric suction filter valve switches between suction from the main tank and rinse tank. It is located to the left of the spray pump on the chassis rails.

Suction filter ball valve tap isolates the suction filter



Joystick Control



Boom Controls

BOOM LIFT

Press the black oval button upward the boom raise circuit is activated. Releasing the button will return the switch to the neutral, centre position.

BOOM LOWER

Press down on the black oval button, the boom lower function is activated. The boom will lower until the boom lower height switch, which is mounted on the parallelogram, is tripped. When the switch is released it returns to neutral, centre position.

TILT RIGHT UP

Press the black circular button up and to the right the boom tilt right up circuit is energised. This lifts the right hand side boom only, when the tilt function is fitted to the sprayer. When the switch is released it returns to neutral centre. When ultra glide is connected to the sprayer the right side will be disabled from automatic mode if this switch is activated in this direction.

TILT RIGHT DOWN

Press the black circular button back and to the right the boom tilt right down circuit is energised. This lowers the right hand side boom only, when the tilt function is fitted to the sprayer. When the switch is released it returns to neutral centre. When ultra glide is connected to the sprayer the right side will be enabled automatic mode when this switch is activated in this direction.

TILT LEFT UP

Press the black circular button forward the boom tilt left up circuit is energised. This lifts the left hand side boom only, when the tilt function is fitted to the sprayer. When the switch is released it returns to



neutral centre. When ultra glide is connected to the sprayer the left side will be disabled from automatic mode when this switch is activated in this direction.

TILT LEFT DOWN

Press the black circular button down the boom tilt left down circuit is energised. This lowers the left hand side boom only, when the tilt function is fitted to the sprayer. When the switch is released it returns to neutral centre. When ultra glide is connected to the sprayer the left side will be enabled into automatic mode when this switch is activated in this direction.

DUAL TILT UP/DOWN

This raises and lowers both of the boom wings, when the tilt function is fitted to the sprayer. When the switch is released it returns to neutral centre. If the switch is pushed forward and held, both left and right wings will tilt UP to the maximum. When the switch is pulled back and held, both the left and right wings will tilt DOWN to a level horizontal setting. Small movements of the switch will bring the tilts up or down in smaller increments.

BOOM MASTER ON/OFF

The large yellow button cycles the Boom Master ON/OFF and has the same function as flicking the Master ON/OFF switch on the SCS4400 console. This button eliminates the need for the ISOBUS foot pedal.

Continued over page

Joystick Control

Plumbing Controls

LEFT FENCE LINE JETS

Press the black oval button forward once and the left fence line nozzle on the left hand end of the boom is activated. When activated, a red LED on the console and red LED on the boom tip will be illuminated. To switch off the fence line nozzle, press the button once more.

RIGHT FENCE LINE JETS

Press the black oval button forward once, the right fence line nozzle on the right hand end of the boom are activated. When activated, a red LED on the console and red LED on the boom tip will be illuminated. To switch off the fence line nozzle, press the button once more.

Auto Steer & Cruise Control

AUTO STEER ON/OFF

Press to cycle customer fitted auto steer ON/OFF.

CRUISE SET/DECREASE

When the top black rocker button is depressed the current ground speed will be set as the cruise control speed. The cruise switch on the console must be in the ON position for this to engage and the foot brake must be released. Once cruise control is engaged, depressing the top rocker button down will decrease ground speed. To disable cruise control the Cruise OFF switch can be cycled to the off position or the foot brake can be engaged.

CRUISE RESUME/INCREASE

When the bottom black rocker button is depressed, the cruise control will resume the ground speed that was previously set before the system was disabled by the foot brake or the cruise off switch. The cruise switch on the console must be in the ON position for this to engage and the foot brake must be released. Once cruise control is engaged, depressing the bottom rocker button down will increase ground speed. If the engine ignition has been cycled a new cruise speed will have to be set. To disable cruise control the Cruise OFF switch can be cycled to the off position or the foot brake can be engaged.

CRUISE CANCEL

Pressing the yellow button will cancel the currently active cruise control. Simulates pressing the brake pedal.

NOTE: Cruise control should not be engaged when RPM Raise is switched on.

NOTE: The transmission will not engage any gear from neutral if the engine is running over 1000 RPM.

Side Console Switches - General



CRUISE CONTROL / RPM RAISE

Press switch forward to turn ON Cruise Control function. Press this switch forward again will turn the function OFF.

Press the bottom of this switch will turn ON the RPM Raise, which will increase the engine RPM to 1500 RPM. Press the bottom of the switch again will turn this function OFF.

BOOM RECIRC

By pressing this switch forward, will turn ON the recirculation function. The spray pump must be on and the suction from tank open. Pressing the bottom of the switch will this function OFF.

SPRAY PUMP ON/OFF

Press switch forward to activate the spray pump. When the pump is on the light on the arm rest will be illuminated. The pump will remain operating until the switch is returned to the SPRAY PUMP OFF location. If dual product pumps are installed this switch must be first turned on to activate the pump circuit required.

PARK BRAKE ON/OFF

This switch must be in the ON (forward) position before starting the engine. If not, pull the orange slide lock and then press forward to turn the function 'ON'. Once the engine has started and the foot service brake has been applied, pull the orange slide lock back and press the bottom of the switch to disengage the park brake. A drive gear can now be selected. When stopping the machine, the foot service brake needs to be applied to bring

the machine to a complete stop, and then the transmission needs to be placed in 'N' before the park brake switch can be put in the 'ON' position.

AUTOSTEER

By pressing switch down, the GPS resume wires are activated. If a GPS steering unit is fitted, 12 volts will be supplied to the GPS auxiliary connector pin 'C' each time this momentary switch is triggered. This switch returns immediately to the centre OFF position once the operator releases it.

CENTRE DIFF LOCK ON/OFF

This switch will engage the differential lock in the transfer case and split the drive 50/50 to the front & rear axles. When the differential lock is fully engaged, the light in the switch will illuminate.

DIFF LOCK REAR ON/OFF

This switch will engage the differential lock in the rear differential and give full drive to both rear wheels. When engaged, the light in the switch will illuminate.

Side Console Switches - Boom 36-42 m

Complete Folding Operation

FOLDING PROCEDURE:

- To make the boom fold cylinders extend or compress equally and fully on both sides, continue holding the switches for a few extra seconds.
- Starting with the boom in the working (unfolded) position, use the switch to tilt the wings level.
 - Use the 'Boom Lift' switch to raise the boom fully.
 - Use the 'Boom Fold' IN switch to fold the boom completely in.
 - Use the 'Boom Lower' switch to lower the boom onto the boom rests until they are just supported on them. It is important not to lower the boom too much as the booms can contact the rear wheels and become damaged.
 - Use the 'Boom Rest' IN switch to fold the boom rest in.
NOTE: This function only effects the left hand side boom rest. The right hand side boom rest is fixed.
 - Finally, press the boom fold switch momentarily to fold the booms tight on the rest.

UNFOLDING PROCEDURE:

- To make the boom fold cylinders extend or compress equally and fully on both sides, continue holding the switches for a few extra seconds.
- Use the 'Boom Rest' OUT switch to fold boom rest completely out.
NOTE: This function only effects the left hand side boom rest. The right hand side boom rest is fixed.
 - Use the 'Boom Lift' switch to raise the boom fully to clear the boom rests.
 - Use the 'Boom Fold' OUT switch to fold the boom completely out so that the boom is parallel with the centre section.
 - Use the 'Boom Lower' switch to lower the boom to the desired height above the target.

Bi-folding Operation

FOLDING PROCEDURE:

- To make the boom fold cylinders extend or compress equally and fully on both sides, continue holding the switches for a few extra seconds.
- Starting with the boom in the working (unfolded) position, use the 'Boom Bi-fold' IN switch to fold just the outer wings in.

NOTE: When the booms are all the way out hold the button depressed until the bi-fold pressure gauges read 1700-1900 PSI. This pressure maintains boom alignment while moving.


UNFOLDING PROCEDURE:

- To make the boom fold cylinders extend or compress equally and fully on both sides, continue holding the switches for a few extra seconds.
- Starting with the boom in the working (unfolded) position but with the outer wings folded in, use the 'Boom Bi-fold' OUT switch to fold just the outer wings back out.

DANGER: Always check for power lines while folding and unfolding the boom, as contact with lines can be fatal.

NOTE: Booms must not be folded, or unfolded, while the sprayer is moving. When the boom is between fully open and fully closed, there can be large stresses placed on many boom components. If the sprayer is moving and hits a bump, severe damage to the boom can occur.

NOTE: The booms must be folded continuously without stopping and starting during the sequence. Take care not to fold/unfold booms too fast, as damage can be caused.



Above: Boom fold controls located on side console.

Side Console Switches - Boom 48 m

Folding Operation

FOLDING PROCEDURE:

- To make the boom fold cylinders extend or compress equally and fully on both sides, continue holding the switches for a few extra seconds.
1. Use the 'Boom Lift' switch to raise the boom to it's maximum height.
 2. Press 'Fold Stage 3' IN to fold the third stage completely in.
 3. Press 'Fold Stage 2' IN to fold the second stage completely in. The catch mechanism should automatically unlock.
 4. Press 'Boom Catch' CLOSE to capture the second stage against the third stage.
 5. Press 'Fold Stage 1' IN to fold the first stage in to touch the boom rests.

NOTE: If the tilt sensors are calibrated and working correctly then the boom will automatically level as it folds in. If not, then it is possible to manually override the levelling function. In cases where the tilt sensor is out of adjustment, faulty or disconnected, press 'Fold Stage 1' IN and 'Boom Catch' CLOSE at the same time.

6. Use the 'Boom Lower' switch to lower the boom onto the boom rests until they are just supported on them.

NOTE: It is important not to lower the boom too much as the booms can contact the rear wheels and become damaged.

UNFOLDING PROCEDURE:


- To make the boom fold cylinders extend or compress equally and fully on both sides, continue holding the switches for a few extra seconds.
1. Use the 'Boom Lift' switch to raise the boom to clear the boom rests.
 2. Press 'Fold Stage 1' OUT to fold the first stage completely out so that the boom is parallel with the centre section.
 3. Press 'Boom Catch' OPEN to release the second stage.
 4. Press 'Fold Stage 2' OUT to fold the second stage completely out. Visually confirm that the catches have locked between the second and third stages.

5. Press 'Fold Stage 3' OUT to fold the third stage completely out.
6. Use the 'Boom Lower' switch to lower the boom to the desired height above the target.

DANGER: Always check for power lines while folding and unfolding the boom, as contact with lines can be fatal.

NOTE: Booms must not be folded, or unfolded, while the sprayer is moving. When the boom is between fully open and fully closed, there can be large stresses placed on many boom components. If the sprayer is moving and hits a bump, severe damage to the boom can occur.

NOTE: The booms must be folded continuously without stopping and starting during the sequence. Take care not to fold/unfold booms too fast, as damage can be caused.



Above: Boom fold controls located on side console.


Tank Source Control

Rinse Tank/Main Tank Switch

The tank source is electronically controllable from inside the cabin. This switch alternates between sucking fluid from either the rinse tank or the main tank through the suction filter. This function can also be controlled via a switch on the right hand side pod (EZ control station). A buzzer will sound in the cabin and at the EZ control station when in rinse tank mode to help avoid accidental spraying from rinse tank rather than main tank.

- Tilt the switch forward to select the rinse tank as the fluid source.
- Tilt the switch backward to select the main tank as the fluid source.

NOTE: The spray pump must be off when switching this function to avoid damaging it.



Above: The rinse tank/main tank switch is located on side console for 36-42m boom variants.



Above: The rinse tank/main tank switch is located on the rear corner console for 48m boom variant.

Transmission

The operator must wear the operator safety belt at all times when seated in the cabin or when the machine is in motion. To engage a gear from neutral, first apply the foot service brake located to the right of the steering column, then release the park brake and press the 'D' button on the gear selector to drive forward or 'R' to reverse.



SELECT DISPLAY

This LED Character shows which gear has been selected by the operator. It will display D, R, or N or a number reflecting the specific gear.

MONITOR DISPLAY

This LED character shows which transmission gear is currently engaged. This includes P, R, N, and numerical values for forward gears. This side typically does not display D for Drive – it allows the operator to glance down and see the specific gear they are currently using.

BUTTON FUNCTIONS



Reverse gear.



Neutral; the gear selector must be in this position for starting.



Drive, in this position 1st - 6th gears are available and will be selected by the ECM when required. Overdrive gears 5th & 6th will only be engaged when in ROAD MODE.



Gear UP. Press to manually upshift one gear at a time until top gear is selected when the transmission is in Drive. The SELECT display will show which gear range has been selected, and the MONITOR display will show which transmission gear is currently engaged.

NOTE: The transmission will not shift above the gear range selected. When Drive (D) is selected the full range automatic shifting is restored.



Gear DOWN. Press to manually downshift the transmission one gear at a time until 1st gear is selected.

The SELECT display will show which gear range has been selected and the MONITOR display will show which transmission gear is currently engaged.

NOTE: The transmission will not shift above the gear range selected. When Drive (D) is selected the full range automatic shifting is restored.



When the engine is started, the transmission will start in ROAD mode. When the MODE button is pressed, the transmission goes into SPRAY mode and '2 MODE' will be displayed in the MONITOR Display. In SPRAY mode, the transmission limits top gear to 5th for spraying speeds. Pressing the MODE button again cycles back to ROAD MODE. Now 6th gear will be selectable to enable speeds up to the machine's maximum speed of 50 Km/h.



Continued over page

Transmission

PULLING AWAY

The transmission needs to be in NEUTRAL (N) and the operator should have their right foot on the service brake before releasing the park brake.

If DRIVE (D) or REVERSE (R) are pressed while the park brake is still on, no gear will be engaged by the transmission - an audible alarm will sound. Once the desired gear is selected release the foot service brake to start moving.

When in 1st gear, reduced torque is applied until 11 Km/h is reached and then all the engine torque is applied.

NOTE: The transmission must be in neutral before pressing RPM raise and Cruise Control must be off.

NOTE: The transmission will not engage any gear if the engine is over 900 RPM.

TRANSMISSION FAULT WARNING

If the wrench icon is displayed or flashing after startup then there is a fault in the shift by wire system. A qualified technician should inspect the system as soon as possible.



WARNING: Operating the machine with the wrench icon flashing is not recommended. It may indicate a loss of safety back up systems, and the operator should use extra caution when shifting to ensure that the transmission is performing properly.

Troubleshooting

J1939

Loss of the J1939 to/from the shifter is indicated on the Display as  for the 6 Speed Transmission.

The SELECT display works as normal except that DRIVE (D) will only display  on screen. Gear up and gear down button commands are sent on the J1939 link and will not function in this mode. The vehicle transmission will not be able to hold any of the forward gears unless the loss of J1939 occurred while a lower range was currently selected – in this case the selected range will be the max range. Press DRIVE (D) during this condition to enable shifting to all 6 gears, and consult a qualified technician.

RANGE INHIBIT INDICATOR

Certain conditions may cause the Allison transmission control module (TCM) to restrict shifting. The range inhibit indicator alerts the operator that such a condition exists when the SELECT display (the left digit) begins flashing, and the MONITOR Display (the right digit) remains constant. Please consult a qualified technician in this case.

FILTER LIFE MONITOR

The filter life monitor will display REPLACE FILTERS when it detects that the flow through the transmission is being restricted.

Towing & Transporting Sprayer

- A disabled sprayer is best transported on a drop deck trailer. Use chains to secure the sprayer via the tie down attachment point located under the front and rear axles.
- The machine must not be towed unless the engine is running (as the steering and brakes require engine power to operate). Before towing, the front tail shaft should be disconnected, due to the risk of damage to the transmission. While towing do not travel at a speed greater than 10 km/h.
- An operator must steer and brake the sprayer under tow.

Controller - Raven SCS4400 - Standard



The Raven SCS 4400 Auto Section Controller

- Simple operation
- Low-limit function
- Digital boom pressure read-out
- Supports a variety of flow meters and control valves
- Audible alarms
- Self-test function
- Rate bump features

For more information please see your Raven operation manual.

Controller - ISOBUS - Optional

The Raven ISOBUS single product control node is designed to add liquid speed compensated product control capabilities plus 3TS, UltraGlide, DCI and pump rpm information to ISOBUS virtual terminals.

Raven ISOBUS product control node will allow a machine operator to monitor and control a Raven product control system directly from a virtual terminal (VT) screen. A VT screen removes the need for multiple screens as the various components communicate directly with the Virtual terminal.

This is useful when the steering controller has VT capabilities such as the John Deere 2630, Trimble FMX 1000, Case Pro 700 or Ag leader VT displays.

Check with the console supplier to determine if an unlock code is required for additional features such as Auto section control. ISOBUS is an international standard communication system which links tractors and implements together, enabling data to be transferred quickly and simply.

The name ISOBUS is derived from 'CAN-BUS', which is the system by which electronic devices communicate to each other.

The ISOBUS system can be fitted with an optional programmable 6 section switch box. Each section switch can be set up to control multiple boom sections. This box mounts to the VT for easy operation.

A pressure transducer is fitted as standard to provide the operator with the current spray pressure in the cabin. The controller Foot switch for master on/off is fitted next to LHS foot rest. The operation of this can be turned on and off via the switch box.

Before using the ISOBUS system the following calibration values are required to accurately control product application:

- Total Width of Implement
- Number of Sections and Section Widths
- Control Type
- Meter Cal or Spreader Constant and Product Density
- Valve Type and Cal
- Rate Cal

The Raven ISO Bus product node is mounted to the right hand chassis rail under the cabin.

Please see the Raven ISOBUS operators manual for further information on calibration and setup.



Above: ISOBUS fitted with optional Raven virtual terminal (VT) screen and further optional 6 section switch box.

Tank Filling

When filling the sprayer it is necessary to connect to an external water source.

The main tank should always be filled through the quick fill. This line fills through the top of the tank and then through a hose inside the tank so that the water is deposited in the centre of the tank. Water can then be pumped into the system from an external pump, or via a hydraulically driven fill pump mounted on the sprayer (see Chapter 12 'Optional Accessories'). Filling progress can be monitored via an optional fill flow meter (see Chapter 12 'Optional Accessories').

WARNING: Water weighs 1 kg per litre. Conversion factors must be used when spraying liquids that are heavier than water. The total weight of the liquid being sprayed should not exceed the equivalent weight of a full tank of water. Exceeding this weight, can lead to sprayer damage.
ie: Liquid nitrogen has a density of 1.28 kg per litre. Tank size is 8000 L

$$8000 \text{ L} / 1.28 \text{ kg} = 6250 \text{ L}$$

This means that the total volume of liquid Nitrogen allowed in a 8000 L tank is 6250 L.

This rule applies for all tanks sizes. If unsure about the density/weight of the chemicals being applied, contact your agronomist or chemical supplier.

Main Tank Fill Procedures

PUMPING WITH EXTERNAL PUMP

1. Connect the fill hose (not supplied) to the quick fill cam lock coupling.
2. Make sure that the 'main tank fill' handle on the EZ control is in the OFF position so that there can be no flow coming out of the tank if it is not already empty and that other fill functions are OFF.
3. Turn the fresh water pumping system on (make sure the pressure does not exceed 75 psi).
4. Turn 'main tank fill' handle on EZ control to ON. The main tank should now be filling.
5. When the required amount of water has been transferred into the main tank, stop the flow by turning the 'main tank fill' to OFF.

PUMPING WITH OPTIONAL HYDRAULIC FILL PUMP

1. Connect the 3" fill hose (not supplied) to quick fill cam lock coupling under the EZ Control Pod.
2. Turn the 'Main Tank Fill' ball valve ON

NOTE: Do not turn the tank fill ball valve off while the pump is running.



3. With the engine running at low idle, turn the 'Fill Pump' switch ON.

NOTE: Do not turn the fill pump switch ON or OFF with the engine above low idle.



Fill pump switch

RPM raise switch

4. Once the pump is running, turn the 'RPM Raise' switch ON.
5. When the tank has been filled to the desired level, turn the 'RPM Raise' switch to OFF.
6. When the engine has returned to low idle, turn the 'Fill Pump' switch OFF. Close the 'Main Tank Fill' ball valve and remove the water supply from the tank fill fitting.

Continued over page

Tank Filling

EZ Control External Water Delivery Station

The external water delivery station allows several filling functions of the sprayer to be performed simultaneously.

1. With fresh water entering the system as per 'Main Tank Fill' instructions, ensure that all ball valves, including the 'Main tank fill' ball valve, on the external water delivery station are turned to OFF.
2. Turn the desired function ON by selecting the appropriate ball valve as labelled.
3. When the required amount of water has been transferred, turn the appropriate valve to OFF.
4. When all functions have been performed, turn the fresh water pumping system OFF.

Rinse Water Tank Fill

The standard size rinse water tank holds approximately 300 litres, while the G6 (6000 L) machine has a 500 L rinse tank. Make sure this tank always has sufficient water in it in case a chemical accident occurs and rinse water is needed to wash chemical from any contaminated persons, clothing or components.

To fill the rinse water tank from the fresh water supply via the quick-fill and fill station:

1. Start by ensuring that all ball valves on the fill station are turned off.
2. Lift the 'Rinse tank fill' red handle on the EZ control 3-way ball valve to the vertical position. This is the ON position.
3. Connect the fresh water fill hose to the quick-fill coupling.
4. Operate the fresh water pumping system (make sure pressure does not exceed 75 PSI). There should now be flow transferring to the rinse water tank.
5. When the required amount of water has been transferred to the rinse water tank, stop the flow by turning off the external water supply and shut the rinse water tank fill valve by flipping it back down.



Remote Fill Points - 3"

There are two options for the 3" remote fill points. One is located on the front right hand side of the chassis just in front of the front axle. The other is located on the left hand side of the chassis and is mounted to the side of the Pod.

These fill points go straight into the main tank, bypassing the control Pod, in doing so, the tank rinse and or rinse tank filling can not be operated when filling from these points.

The fill times are faster using these points and they give the option to remote fill from a Goldacres BatchMate unit with pre-mixed chemical straight into the main tank.

Right: Remote fill 3" inlet mounted to right hand side Pod.



Left: Remote fill 3" inlet mounted to chassis on left hand side before front axle.

Chemical Induction Hopper

Overview

The Super Flow Chemical Induction Hopper is an alternative method of transferring chemical into the main spray tank. The hopper can be lowered to a more convenient height for adding chemicals. The chemical can either be in liquid form or granular form and once in the hopper the chemical can then be easily transferred into the main spray tank. The hopper facilitates drum rinsing with fresh water and the hopper itself can be rinsed and all rinsate then transferred into the tank.

The hopper transfers the chemical via venturi effect. Water from the main spray tank is pumped under the bottom of the hopper where it passes through a venturi fitting under the hopper. This causes a suction effect and when the bottom of the hopper is open (via the hopper tank valve) the tank contents are drawn into the flow from the pump passing under the hopper and then transferred into the middle of the main spray tank. This eliminates chemical attack resulting from high concentrations of chemical coming into contact with spray components.

NOTE: The level indicator should be used as a guide only.

NOTE: Never let the hopper run empty or suck air, this may cause foaming in the main tank.

Key Features

NUMBER	FUNCTION
1.	Rinse Tap
2.	Tank Rinse Nozzle
3.	Level Indicator 60 L
4.	Drain Tap
5.	Hopper Tank Ball Valve
6.	Drum Rinse Nozzle
7.	Pressure Water Mixing Jet Valve
8.	Hopper breather



Continued over page

Chemical Induction Hopper

Operation

1. Add at least 500 litres of clean water to the main spray tank. Initially there needs to be a sufficient amount of water in the tank in order for the pump delivery to create the venturi effect via the venturi fitting. This will also ensure that agitation takes place when the remaining water is added.
2. Lower the hopper for convenience. (Check that the delivery hose to the hopper is not restricted or kinked).
3. Ensure that the red handle on the spray pump three-way ball valve is pointing towards the main tank sump.
4. Turn the 4-way ball valve to Vortex Induction Hopper.
5. Operate the pump at the speed necessary to generate at least 80 PSI delivery pressure (as displayed on the sprayer pressure gauge). Do not run faster than 540 RPM.

NOTE: The higher the pump delivery pressure, the greater the venturi suction and the quicker the hopper will transfer the chemical. The delivery pressure should not exceed 120 PSI as determined by the pressure relief valve setting.

7. The wash down hose is also useful for ensuring all chemical is clear of the hopper (only available when fresh water coming into the fill station)
8. Put the required amount of chemical into the hopper (liquid or granular). Wear the necessary protective clothing and use the required safety equipment to avoid exposure to chemicals.
9. Open the hopper tank ball valve at the bottom of the hopper by turning the yellow handle up. The chemical should be now transferring to the main spray tank.

10. Rinse all chemical drums and the hopper as per the rinsing instructions.

When finished using the hopper:

- Close the hopper tank ball valve at the bottom of the hopper by turning the yellow handle so that it is horizontal.

- Rotate the 4-way valve from "hopper" to "bypass"
- Ensure that the agitator valve is 'ON'. The sprayer should always be agitating until spraying begins.
- Raise the hopper to its transport position and replace the retaining pin and "R" clip in the mechanism.

Rinsing

RINSING FROM EXTERNAL SOURCE

To rinse the Induction Hopper and chemical drums with fresh water from the external water delivery station:

NOTE: Spray pump must also be operating.

1. Lower the hopper. (Check that the delivery hose to the hopper is not restricted or kinked).
2. Make sure that all valves on the EZ control external water delivery station are 'OFF'.
3. Make sure that the Hopper Rinse valve on the top of the hopper is 'OFF'.
4. Connect the fresh water fill hose to the quick-fill coupling.
5. Operate the fresh water pumping system between 70 and 100 PSI.
6. Turn the Induction Hopper valve on the Pressure delivery station 'ON'.
7. Open the hopper tank valve at the bottom of the hopper by turning the yellow handle 'UP'.
8. Ensure that the hopper drain tap, also located at the bottom of the hopper, remains 'CLOSED'.
9. To rinse a drum, push the drum over the rinsing nozzle located in the top of the hopper.
10. To rinse the hopper, turn the Hopper Rinse valve on the top of the hopper 'ON'. Close this valve when the hopper has been rinsed.

When the hopper is empty:

- Remove any chemical drums that have been rinsed from the hopper.

Continued over page

Chemical Induction Hopper

- Turn the hopper tank valve at the bottom of the hopper 'OFF' by turning the yellow handle so that it is horizontal.
- Turn the Induction hopper valve on the EZ control Pressure Delivery station to 'Bypass'.

Drain the hopper of any remaining liquid using the hopper drain tap at the bottom of the hopper.

RINSING OUT THROUGH DRAIN

The hopper can be rinsed and the rinsate emptied through the hopper drain ball valve rather than transferred into the main spray tank.

To do this:

1. Ensure the fresh water filling supply pump system is operating.
2. Open the hopper rinse valve on the top of the hopper.
3. 'OPEN' the hopper tank ball valve at the bottom of the hopper by turning up the yellow handle so that it is vertical, removing the rinsate from the hopper.
4. Open the hopper drain valve.

CAUTION: Spray pump should be turned off.

NOTE:

- Take proper safety precautions to avoid any contact with rinsate when draining, as it may contain chemical residue.
- Be mindful of where rinsate is deposited as it may contain chemical residue.
- This procedure will not rinse the hose from the bottom of the hopper to the main tank.



*Hopper Drain Tap -
Photo looking up from
underneath the hopper*

Agitation

TO AGITATE WHILE STATIONARY

1. Add 20 percent of the main tank's volume in fresh water to the main tank.
2. Add all chemicals.
3. Add the remaining quantity of water required.
4. Turn the 3 way ball valve to Bypass, and ensure suction handle is on 'Suction Main Tank'.
5. Turn the agitator on.
6. Turn the spray pump on. Check to ensure that the Supermix agitator is working. There should be a visible circulation of water near the back of the tank near the agitator.

7. If the tank has been filled and the spray mixture has been allowed to settle, agitate for as long as it takes the pump to pump the quantity of water in the tank. For example: with 5000 litres in the tank with a 260 L/min pump agitate for $5000/260 = 19$ minutes.

TO AGITATE WHILE SPRAYING

Have the bypass ball valve and agitator ball valves OPEN.

NOTE: The bypass ball valve must be open while spraying.

Spray Application

After completing the filling process, you are now ready to start spraying. While travelling from the fill station to the field, the pump should be running at 400 - 540 rpm with the agitator running in order to ensure that the chemical mix is adequately agitated prior to spraying.

RapidFlow allows an agitated chemical mix to be run through the boom lines prior to spraying, thereby pre-charging them and eliminating waste.

NOTE: The following information is provided as a guide only. It is the responsibility of the operator to assess the conditions in the field where the spray application is taking place

1. Enter the field, unfold boom, and set the boom to desired height above the target and have pump running with bypass ON.
2. Turn on the boom recirculation switch.

NOTE: The lines will require at least 80 L of fluid to fill them.

3. Charge all boom lines with product from the main tank. Switch on for approximately 2 minutes.
4. Switch on the console and set to run in self test mode (while stationary). Information on running in self test mode can be found in the spray controller operators manual supplied.
5. Turn on all boom sections.

6. Have the pump running agitating the tank mix.

7. Switch off all boom sections.

8. When ready to spray, turn off boom recirculation and then turn on the required boom sections.

9. Commence travel on primary swathe and engage boom master switch. The rate controller will now control application based on the calibration information entered by the operator.

10. To avoid overlap it is recommended that individual boom section switches are used to turn on/off sections as needed.

11. When you have completed the spraying task, follow the flushing instructions to ensure that all plumbing is flushed clean.


NOTE: It is important that boom recirculation is turned off before spraying. If it is left on while spraying, the flow meter will read incorrectly leading to the wrong amount of chemical being applied.

RapidFire

Overview

The RapidFire system provides instantaneous, individual nozzle shut off that is controlled by air operated solenoids at each nozzle. This system replaces the boom valves and standard check valves that shut off the boom sections and nozzles. This provides greater flexibility in changing boom section widths and faster shut off at the nozzle.

The RapidFire system reduces the amount of plumbing on the sprayer and allows for the fitting of a boom recirculation system. The ability to have more boom sections also works perfectly in conjunction with autoboom shut off systems.



NO.	FUNCTION
1.	Air Check Nozzle Body
2.	Air Dryer/Oiler
3.	Air Solenoids

Continued over page


RapidFire

Nozzle and Air Check

The air check nozzles allow for instantaneous response at the nozzle tip. The lines can be at spraying pressure and when switched on or off, the nozzle responds quickly with no dribbling, as pressure builds up or subsides.

The air checks close under a spring tension of 140 PSI. This traps the liquid in the spray line at the same pressure that it was being applied. When the booms are turned on, air pressure acts against the 140 PSI springs instantly opening flow to the nozzle allowing the trapped boom line pressure to apply the liquid at the rated pressure and droplet size with a full fan angle.

The air check valve is located on the side of the nozzle, it has 2 O-rings in it. Over time, the O-ring may swell or be damaged. This may result in the nozzle dripping or being slow to shut when it has been turned off. If the nozzle leaks the outer O-ring requires replacement. If the air shut off has poor or delayed response the inner O-ring requires replacement.



To remove the air check from the nozzle, the air supply must be removed. Ensure that all the air pressure is vented from the system. Ensure that all liquid pressure has been removed from the boom lines.

To remove the air hose from the check valve, push down on the release ring on the air fitting and at the same time, pull the hose.


Unscrew the air check valve from the main body. Replace the O-rings that are in the air check valve.

Screw the air check valve back onto the main nozzle body.

When re-fitting the hose, simply push it into the fitting.

On dual or quad nozzle bodies, the body is a fixed unit and the multi spray nozzle body will need to be

removed from the clamp around the pipe. See the parts book for more detail.



Air Dryer and Oiler

The air supply to the RapidFire system has a dryer, oiler and pressure regulator fitted in the circuit.

The dryer removes all the moisture from the air supply and traps it in a clear bowl. This must be drained daily to prevent moisture entering the rapid fire system.

The oil lubricates the air as it passes through to the RapidFire system. In turn, this lubricates the RapidFire seals and O-rings. The oiler must be checked weekly and serviced at approximately 250 hours or when required. The amount of lubricant drawn into the air supply can be increased or decreased depending on requirements.

The pressure regulator is used to set the maximum pressure available to the rapid fire system. This should be set to 80 PSI.

The black knob located above the water trap is used to set the air pressure. To unlock it, lift the black knob. Looking from above, turning the knob clockwise will increase pressure. Turning anti-clockwise will decrease pressure.

To release air from the system for maintenance, turn the knob anti-clockwise until the pressure on the gauge reads zero. Drain the water trap to release any residual pressure.

Once adjustments have been made or maintenance carried out, reset the pressure as above and push the black knob down to lock it in place.

Continued over page

RapidFire



The moisture trap should be checked on a daily basis while the sprayer is in use. It must not be allowed to fill up totally. If it does, moisture will be sent through the lines to the nozzle check valve and this may cause problems with its operation.

To drain the trap, turn the black knob at the bottom of the clear bowl and push it up. Air and moisture will be expelled from the bowl. Keep the knob pressed up until all the moisture has been released. Once finished, release the knob and turn it back until it stops. Ensure correct safety equipment is worn and in place as air will be displaced at high pressure.

The oiler slowly releases oil into the air to keep the check valves, seals & O-rings lubricated.

Fill the oil to within 5 mm of the top of the oil bowl. Use an air tool oil or equivalent.

To ensure the correct flow of oil into the air, the oil flow adjustment screw may need to be adjusted to suit the conditions.

The screw can be adjusted by turning the blue regulator knob shown below. Turning the knob clockwise and in will reduce the amount of oil being supplied to the RapidFire. Turning the screw counter clockwise and out will increase amount of oil. To set the oil flow, wind the knob all the way in, then turn the knob anti-clockwise half a turn. A full bowl of oil should last about 250 hours. The oiler requires regular inspection and topping up every 250 hours or when required.



Moisture trap drain
- Right chamber



Oil flow adjustment screw
- Blue

Continued over page


RapidFire

Solenoid Valves

The solenoid valves are, electrically, turned on and off to control the flow of air to the nozzles.

For troubleshooting purposes or in the event of an electrical problem, the solenoid valve can be manually overridden.

Remove the black plug from the white box in the position above the valve that is to be overridden. Insert a flat head screw driver in through the top of the box and find the screw in the top of the solenoid valve. Push down on the screw driver and turn the screw a 1/4 turn in either direction.




The valve should now be allowing air to flow out to the nozzle and if there is fluid in the lines, it should be coming out of the nozzle.

To shut off the valve, turn the screw driver 1/4 turn in the opposite direction to when it was overridden. The screw in the top of the solenoid is spring loaded, it will pop up when returned to its original position and shut off the flow of air.

On the solenoid bank there are two exhaust ports. These must be kept clean so that the air can expel from these when the RapidFire nozzles are turned off. If these ports are blocked the air can not release from the air checks, through the solenoids to atmosphere and the nozzles will continue to spray.

The ports can become blocked when working in dusty environments. To clean the exhaust ports, remove them from the air solenoid manifold and rinse them in solvent. Blow out with compressed air and refit.




Exhaust port;
one located on
each end of the
manifold.


If a section of the boom will not turn on, it may be because that section has a large air leak, in the supply air to the check valves on the nozzles. To find the air leak, spray soapy water on each of the connections along that section. Replace any component that is leaking air. If the air leak can not be found on the section of the boom line, check to see if the air is leaking out of the air solenoid manifold exhaust port. These should not leak air when the boom sections are turned on. If they do then a solenoid is stuck. To find the stuck solenoid turn all the boom sections OFF. Remove the hoses from the under side of the air solenoid manifold.

Continued over page

RapidFire



If there is air coming out from any of the ports then that is the solenoid that is stuck and it should be replaced.



The air solenoids have two wires going to them, one power and one earth. The wire in pin B of the plug is the earth and pin C is the power. The solenoids operate on 12 volts supplied from the section switches on the console.

RapidFlow

Key Features

RapidFlow is a boom recirculation system. In order to ensure that boom lines are charged and ready to spray, a standard sprayer plumbing system will require the boom lines to be purged with chemical mix prior to spraying. RapidFlow allows an agitated chemical mix to be run through the boom lines prior to spraying - pre-charging them and eliminating waste.

NOTE: This option is not available unless RapidFire is also fitted.

Operation

It is important that boom recirculation is turned off before spraying. If it is left on while spraying, the flow meter will read incorrectly leading to the wrong amount of chemical being applied.

BEFORE SPRAYING (CHARGING THE LINES)

1. Turn off all boom sections on the console.
2. Have the pump running agitating the tank mix.
3. Turn on boom recirculation switch.

NOTE: The lines will require at least 80L of fluid to fill them.



4. When ready to spray turn off boom recirculation and turn on the required boom sections.



AFTER SPRAYING (RINSING)

1. Turn off all boom sections on the console.
2. Turn the pump suction to 'Draw From Flush Tank'
3. Turn pump on.
4. Turn on boom recirculation switch.

NOTE: The boom sections can be pulsed ON/OFF to flush/rinse the tips and nozzle bodies.

5. Turn off boom recirculation switch.
6. Return pump suction to 'Draw From Main Tank'.

[illegible]



Flushing

The following information is provided as a general guide for flushing your sprayer following a spray application.

For more specific information regarding flushing, and decontamination, specific to the products that you are applying, it is recommended that you consult the chemical label or your chemical supplier.

TO USE THE FLUSH WATER TANK TO FLUSH PUMP & BOOM NOZZLES ONLY

This procedure will allow rinse water back into the main spray tank and through the boom recirculation system.

1. Turn spray pump off
2. Press the switch to 'Suction rinse tank' rather than the main product tank. A buzzer will sound in the cabin and at the EZ Control station, until it is switched back to main tank.
3. Set Raven console into manual mode. Ensure that Boom Recirculation is turned 'OFF'.
4. Switch all boom sections to ON
5. Hold increase button for 15-20 secs. This will ensure that fast close valve is fully open to direct all flow to booms (This will eliminate bypass from the booms to main tank).
6. Turn spray pump ON. The pump will now draw water from the flush water tank and direct all flow to the booms.
7. Keep boom switches on until the contents of the flush water tank has been run through the booms.

NOTE: If the pressure gauge increases dramatically, hold decrease to reduce.

TO FLUSH ENTIRE SYSTEM - PUMP, BOOM & TANK

1. Drain the main tank.
2. Connect to external water source to provide fresh water supply.
3. Turn main tank fill tap OFF to direct external water supply to the fill manifold under pressure.
4. Engage tank rinse nozzles with the ball valve on EZ control and allow rinsate to drain out through the main tank drain.

5. Add a quantity of fresh water (a minimum of approximately twice the pumps capacity) to the rinse water tank as per filling instructions.
6. Turn on pump with agitator and bypass open to allow fresh water to circulate.
7. Turn off all taps to allow the pressure relief valve to blow off and purge the 'relief to tank' line.
8. Operate induction equipment (if fitted), with a quantity of fresh water in order to flush venturi system. Lower the induction hopper and open drain valve while the agitation jet is running.
9. Now follow the instructions for boom flushing - keep ball valve drawing from rinse water tank.
10. Turn on boom recirculation switch.

NOTE: The boom sections can be pulsed ON/OFF to flush/rinse the tips and nozzle bodies.

11. Turn off boom recirculation switch.
12. Stop spray pump and close all valves
13. Return pump suction to 'Suction Main Tank'.

Pressure Filter Cleaning

There are 2 in-line pressure filters in the spray pressure line that traps the minute particles that are not collected by the main suction filters.

To drain these filters, open the ball valve located at the bottom of the filter body and let drain. Always remember to stand aside as they may contain some chemical residue.

Allow the chemical in the filter to dribble out into a suitable container to avoid environmental contamination.



Decontamination

Decontamination of your spraying equipment is important when changing chemicals or application methods.

Information specific to your circumstances, the spraying equipment being used and the chemicals being applied should be provided by your agronomist or chemical supplier.

Always wear the recommended personal protective equipment and use caution while working with chemicals.

BASIC DECONTAMINATION

1. Fill the main spray tank with approximately 1000 L of fresh water.
 2. Lower the induction hopper and put the appropriate amount of decontaminating agent into it.
 3. Turn on the agitation jet on the hopper and allow it to fill the hopper to the top. Once full, turn the jet off and leave the hopper to sit for a few minutes. This is to ensure that the decontaminating agent fully neutralises any of the chemicals that were in the hopper.
 4. Use the venturi to induct the contents of the hopper into the main spray tank.
 5. Recirculate the decontaminating agent through the system while the main tank rinse nozzles are running (pressure supplied from the main spray pump e.g. pressure delivery manifold).
 6. Turn off all taps to allow the pressure relief valve to blow off and purge the 'relief to tank' line.
 7. Operate induction equipment (if fitted), with a quantity of fresh water in order to flush venturi system.
 8. Once complete, drain chemical induction hopper delivery hose externally.
- NOTE:** Lower the hopper and open the lid to allow it to drain completely.
9. Turn on Boom Recirculation to flush all boom lines back to main tank.
 10. Once the main tank has emptied, flush the system again using fresh water to ensure the decontaminating agent is removed from the system.
 11. Once the main tank is empty, the hose between the tank and the suction filter also needs to be drained. Close the valve above the Suction Filter.
 12. Remove the filter bowl. As per filter removal instructions.
 13. Return switch to main chemical tank. Stand clear of the filter when turning the valve to main chemical tank as chemical will be coming out. Catch all of the chemical in a suitable container so it can be disposed of in the correct manner.

End of Day

At the end of the spraying day, follow the flushing and decontamination procedure as per previous instructions.

1. Unfold the boom in an area convenient to dispose of residual chemical (an area where chemical can not run-off into above ground or sub surface water courses).
2. Clean all filters.
3. Clean all nozzles.
4. Wash down unit.
5. Drain main tank.
6. Drain the pressure filters.

End of Program

If the sprayer is to be stored for a long period of time without use, there are several tasks that need to be performed.

- Clean the sprayer thoroughly as described under 'End of Day' tasks.
- Carry out a thorough observation to determine if there is any damage to the sprayer.
- Park the sprayer in a position where it will not be affected by frosts, and preferably out of direct sunlight.
- Ensure the main tank and any other tanks fitted are empty.

If necessary, remove consoles from cabin and store in a safe and secure location. Protect hydraulic hoses and electrical connections.

NOTE: Store the sprayer in a suitable location to prevent freezing. If the sprayer is to be left where freezing may occur, cover the pump and flow meter with a material bag and empty pump and flow meter of all water (run the pump dry for 15-20 seconds). It is also suggested that a small quantity of anti freeze be added to the main tank and circulated through the sprayer to minimise the chance of freezing.

Make sure any ice has thawed before using sprayer.

Chapter 9

BOOM

General

All booms present a number of safety hazards due to their operation - the operator should read and fully understand the safety instructions in this manual prior to operation.

Goldacres TriTech booms have been designed and built to ensure many years of trouble free service. Aluminium outer boom sections reduce the overall weight of the boom and aid in providing a superior boom ride and longevity.

CAUTION: Goldacres do not endorse use of this machine for spraying at speeds greater than 20 km/h.

CAUTION: Before adjusting the boom alignment, the hydraulic fold circuit must be free of air. Hydraulic circuits that contain air can make the boom appear that it is too far forward. Adjustment of the boom without bleeding air out of the hydraulic circuit first will result in a boom that quickly reverts to hanging out of alignment to the back.

CAUTION: All chemicals have corrosive properties to some degree. Prevent damage to the machine by always consulting the chemical MSDS or the chemical supplier for advice concerning the corrosive properties of the chemical. It is the responsibility of the operator to carry out preventative and ongoing maintenance to the machine, particularly while applying chemicals with highly corrosive properties. Machine components should be coated with a suitable protectant prior to use, and then washed down, thoroughly, immediately after every

application. Consult the supplier of the substance if you require specific advice about the effectiveness of any particular protectant to prevent premature degradation of machine components.


TriTech booms feature a unique patented boom suspension system.

This system provides suspension in three directions:


PITCH Hydraulic cylinders and accumulators dampen the vertical boom movement encountered over rough ground conditions.

ROLL Shock absorbers help maintain constant boom height over sloping and uneven ground.


YAW Shock absorbers and springs, overcome the erratic whipping movement, which creates undue stress on the boom frame and uneven spray application. (Hydraulic Yaw suspension is an option)



Boom Overview - 36-42 m




TriTech Centre Section & Paralift



Continued over page


Boom Overview - 36-42 m




NO.	FEATURE
1.	Rapidfire Oiler/Dryer
2.	Tilt arm adjuster
3.	Tilt cylinder
4.	Yaw cylinder
5.	Roll shockers
6.	Diagonal delta links
7.	Adjustable delta links
8.	Tilt pin (60mm)
9.	Rapidfire solenoid boxes
10.	Boom roll alignment adjuster
11.	Tail light
12.	Tilt arm wear strips
13.	Hydraulic yaw accumulators
14.	Electric over hydraulic valve block
15.	Hydraulic yaw controls
16.	Flow meter
17.	Norac block mount (option)
18.	Rapidflow valve
19.	Paralift arms

NO.	FEATURE
20.	Lift cylinders
21.	Boom lower limit switch
22.	Bolt on fold cylinder mounting
23.	Boom stopper
24.	Boom wing tip
25.	3D breakaway joints
26.	Fence line jet
27.	Boom aluminium outer
28.	Fold Hinge
29.	Boom steel inner
30.	Adjuster for fold ram
31.	Hydraulic cylinder - for Fold
32.	Boom top chord (RHS)
33.	Boom bottom chord (RHS)
34.	Boom stopper bolt
35.	Fold cylinder
36.	Brace bar
37.	Breakaway bumper


Boom Overview - 48 m



TriTech Centre Section & Paralift



Boom Overview - 48 m



NO.	FEATURE
1.	Boom centre
2.	Paralift rear
3.	Paralift arms
4.	Paralift rams
5.	Tilt rams
6.	First stage fold rams
7.	Centre level ram
8.	Yaw rams
9.	Rapidfire Oiler/Dryer
10.	Boom fold accumulators
11.	Rapidfire solenoid boxes
12.	Flow meter
13.	Diagonal delta links
14.	Boom roll alignment adjuster
15.	Rapidflow valve
16.	Roll shockers
17.	Norac hydraulic block (Optional)

NO.	FEATURE
18.	Hydraulic spool block
19.	Yaw accumulators
20.	Boom lower limit switch
21.	First stage boom
22.	Hydraulic catch - Manual operated
23.	Second stage fold ram
24.	Stopper bolts
25.	Second stage boom
26.	Hydraulic catch - Automatic
27.	Boom protector
28.	Third stage fold ram
29.	Clevis adjustment threads
30.	Third stage boom
31.	Saddle bracket
32.	Boom stopper
33.	Breakaway tip
34.	Boom protector

Boom Features

Centre Section

The TriTech centre section is made up of two components, the Paralift rear and the boom centre section. The two are held together by delta links. These links allow the boom to be suspended in order to provide roll and yaw suspension.

Roll suspension is when the boom pitches up and down at the tips. Yaw suspension is when the boom moves fore and aft at the tips. If the boom did not feature yaw suspension there would be excessive stresses exerted on the booms and centre section when cornering or corrections of line are made. The yaw suspension allows the chassis of the sprayer to move left and right without any movement being transferred to the boom. The Paralift rear will move with the sprayer while the boom centre section will remain static or level as it rotates around the delta links connecting it to the Paralift rear.

Two hydraulic cylinders with individual nitrogen filled accumulators connected to each, centre and dampen the yaw movement.

Hydraulic Raise & Lower

The paralift enables the boom to be raised and lowered to maintain a consistent boom height above the target.

The paralift rear uses two hydraulic cylinders to perform the lift, while also acting as a vertical suspension component. Each hydraulic cylinder has a nitrogen charged accumulator which also assists in improving the boom ride. The boom limit height switch allows the operator to adjust the minimum ride height of the boom. Boom maintenance information can be found in the Chapter 10 'Lubrication & Maintenance'.

The hydraulic lift also enables the boom to be raised prior to folding and then used to lower the boom onto the boom rests.

Hydraulic Fold

The booms have a hydraulic fold feature, allows the boom to be opened and closed from within the cabin.

Hydraulic cylinders with flow dividers are used in the folding operation of the boom. This ensures that both sides of the boom are synchronised and open and close together so that the weight distribution is the same for both sides of the boom.

The outer fold cylinder has an adjustable cushion at the end of the retraction stroke which can be adjusted using the needle valve in the cylinder body.

See Chapter 11 'Troubleshooting' for help with calibrating the boom folding action.

Boom Balance

The boom suspension system causes the boom to adopt the same plane as the spray tanker. If one side is heavier than the other, the boom will tend to hang lower on the heavy side, so both sides need to be balanced for the boom ends to be of the same height.

To achieve this, boom drum weights can be included on the boom and placed strategically so that it compensates and balances the boom. The boom can have more weight added and/or be moved to balance the boom correctly. Before adding any boom weights, it is advised that the boom is adjusted correctly as per the instructions following in this chapter.

Boom Cables (36-42m)

Boom cables are a critical part of the booms and it is important to ensure that boom cables are correctly adjusted prior to operation.

Loose boom cables can cause boom damage by allowing the outer boom section to "break away" too easily. This can shorten the sprayers life by placing unnecessary stresses on the boom, lift and chassis. The cable tension can be checked by inspecting the cable springs. Further information on boom adjustment and alignment can be found in this chapter.

Boom Protection Brackets

Stainless steel boom protectors are fitted on the boom to protect the boom when resting on the boom rests for transport. It is important to ensure that the boom protection brackets are fitted correctly.

Boom End Protector

Boom end protectors are fitted to the breakaway tips to help prevent damage to the boom from ground strike or from hitting an obstruction. They also help to keep the boom from becoming entangled when spraying close to fence lines.

Continued over page

Boom Features

Nozzles

The standard nozzle spacing on Goldacres booms is 500 mm. Nozzles are mounted on brackets that are adjustable for different nozzle types. Nozzles are mounted so that they are protected from strikes should the boom make contact with the ground, obstructions or crop.

As information regarding nozzles is specific to those being used in your application, no specific reference is made to nozzle application rates or types in this operator's manual. Goldacres suggest the use of a current TeeJet or Lechler nozzle selection catalogue for reference to nozzle sizes, outputs, spray patterns and general spraying information. For more technical information on the function of spray nozzles and factors affecting their performance you can also use the TeeJet 'User's guide to spray nozzles'.

The TeeJet & Lechler nozzle selection catalogues and 'User's guide to spray nozzles' are available from your Goldacres dealer, or as a free download from:

TeeJet web site: www.teejet.com

Lechler web site: www.lechler.de

Three Dimensional Breakaway

TriTech booms feature the unique three dimensional breakaway hinge which allows the tip to "break" forward, backward and upward if an obstruction is hit. The 3D breakaway hinge aims to eliminate any further damage to the remainder of the boom should an obstruction be hit.

It is important that the 3D breakaway hinge is properly adjusted when in operation. Just tightening the spring will not help with the function of the breakaway. Instructions on how to properly adjust the breakaway can be found later in this chapter.

Fence Line Jets

Goldacres offer manually and electrically operated fence line jets. The 'fenceline' jet is designed to enable the operator to spray right up to the boundary fence without having the boom too close to the fence.

This should prevent operators from putting the boom into the fence, especially important when the operator is not familiar with the width of the boom. The fenceline jet should be turned off after the end of the first lap and this can be done either manually via a tap or remotely via an optional electric solenoid (controlled in the cabin).

Hydraulic Yaw Suspension

Hydraulic yaw suspension is designed to control the yaw movement of the boom centre section. Two hydraulic cylinders with individual nitrogen filled accumulators connected to each, centre and dampen the yaw movement. The two hydraulic cylinders and accumulators are charged with hydraulic pressure and then closed off to create a separate circuit which acts as the yaw suspension.

The overall yaw travel is limited by rubber bumpers mounted to the Paralift rear. If the boom centre section yaws excessively the centre section will contact these and cushion the travel by collapsing the block. If the block collapses totally the yaw travel will be stopped. If the boom is continually yawed excessively this block will wear out and require replacement.

Hydraulic Boom Wing Tilts

The boom tilt function allows the individual boom sides to be raised independently when in the working position. This serves to provide greater variability of boom height control to compensate for undulating ground conditions. Boom tilts are operated from switches in the cabin.

RapidFire & RapidFlow

The RapidFlow system is complimentary to RapidFire and is fitted at the same time. The RapidFire system provides rapid, individual nozzle shut off that is controlled by air operated solenoids at each nozzle. This system replaces the boom valves and standard check valves that shut off the boom sections and nozzles. This provides greater flexibility in changing boom section widths and faster shut off at the nozzle.

The RapidFire system reduces the amount of plumbing on the sprayer and allows for the fitting of a boom recirculation system. The ability to have more boom sections also works perfectly in conjunction with AccuBoom shut off systems.

In order to ensure that boom lines are charged and ready to spray, a standard sprayer plumbing system will require the boom lines to be purged with chemical mix prior to spraying. RapidFlow allows an agitated chemical mix to be run through the boom lines prior to spraying - pre-charging them and eliminating waste.

Continued over page

Boom Features

Fence Line Jets

Goldacres offer manually and electrically operated fence line jets. The 'fence line' jet is designed to enable the operator to spray right up to the boundary fence without having the boom too close to the fence.

This should prevent operators from putting the boom into the fence, especially important when the boom is relatively new and the operator is not familiar with the width of the boom. The fence line jet should be turned off after the end of the first lap and this can be done either manually via a tap or remotely via an optional electric solenoid (controlled in the cabin).

Boom Options

Three Tier System (3TS)

The Three Tier System (3TS) consists of two complete and totally separate boom lines on the same boom frame. As an example a conventional 30 metre boom has one boom line with 60 nozzle outlets (2 per metre) across its width. A 3TS boom replicates this first line with a second line also consisting of 60 nozzles giving a total of 120 nozzles for both lines.

In simple language, the 3TS gives you the capacity to vary application rates and speeds by switching extra nozzles on and off. The 3TS allows a range of speed changes without the spray quality being compromised – the correct droplet size is maintained.

Importantly you can use the nozzles you want to use - including air induction nozzles. That means higher speed spraying without the limitations of large droplet size.

Typically nozzles on the first line may flow at 015 flow rate and the nozzles on 3TS's second line at 025. When spraying, the first nozzles automatically switch off when they reach full operating pressure allowing the second line nozzles to commence spraying. As speed increases again and the second line nozzles reach their maximum operating pressure, the first line nozzles will switch on again.

Thus, the flow rates of 015, 025 and 040 can be achieved while maintaining the optimum droplet size and spraying pressure. The 3TS delivers everything needed for precision application at variable speeds.

Breakaway Bumper

Ensures that the wing opens instead of the breakaway mechanism. The breakaway bumper also holds the wing straight when in the folded position as long as they are properly adjusted first.

Brace Bar

The brace bar is fitted to the aluminium outer wing. It is designed to hold the vertical weight of the boom and is adjustable.

Boom Height Control - Norac

Boom Height Control systems maintain the boom at a preset height by monitoring field contours and making responsive boom adjustments. Using data from either 3 or 5 ultrasonic sensors, the Boom Height Control systems makes responsive height adjustments allowing booms to automatically follow the contours of the land. Maintaining spray nozzles at the recommended spray tip height allows chemical to be applied using an optimum spray pattern providing even application and reducing drift.

Boom Height Control reduces the need for the operator to move their head back and forth to monitor changes in field terrain, thereby reducing stress and fatigue. This allows the operator to focus on machine operation and safety. Manual operation of a sprayer in uneven field terrain may require reduced operating speeds for continual boom adjustments.

Ultrasonic sensor hardware and software is designed specifically for height control applications. The ultrasonic signals can distinguish the difference between the ground and standing crop or field residue. Boom height is controlled by choosing Soil Mode (senses the soil surface), Crop Mode (senses the top of the crop), or Hybrid Mode (technology that calculates a virtual top of the crop for more accurate control).

Refer to manufacturer's manual(s) for detailed information about this system.


Continued over page

Boom Options

WWW.NORAC.CA

PRECISION DEFINED

Goldacres UC5 Active Wing Roll




Boom Adjustment - 36-42 m

Alignment - Yaw - Inner 36m

1. Open the boom fully into the working position.
2. Continue to press the unfold button or hold the hydraulic remote open to ensure the fold cylinders are opened completely.
3. Look along the inner booms between the fold hinge and the centre to assess the alignment.

All booms must be 50 mm forward of the centre section at the fold hinge. A string line can also be used for measuring the lead of the inner boom (see below).
4. If adjustment is required, loosen the two lock-nuts on the boom fold adjuster bolt at the rear of the boom.
5. To adjust the boom forward, tighten the outer adjuster nut. To adjust the boom rearward, tighten the inner adjuster nut.
6. When the boom is in the required position, tighten both locknuts to hold in place.
7. Follow this process for both inner booms.

NOTE: It is important that both wings are adjusted the same. If one wing is adjusted further forward or back than the other, the boom may not sit level.




Boom Adjustment - 36-42 m

Alignment - Yaw - Inner 42m

1. Open the boom fully into the working position.
2. Continue to press the unfold button or hold the hydraulic remote open to ensure the fold cylinders are opened completely.
3. Look along the inner booms between the fold hinge and the centre to assess the alignment.

All booms must be 50 mm forward of the centre section at the fold hinge. A string line can also be used for measuring the lead of the inner boom (see below).
4. If adjustment is required, loosen the two lock nuts on the boom fold adjuster bolt on the front of the boom. Also loosen the lock nuts on the rear fold adjuster.
5. On the front adjuster, to adjust the boom forward, tighten the outer adjuster nut. To adjust the boom rearward, tighten the inner adjuster nut.
6. When the boom is in the required position tighten both lock nuts to hold in place.
7. When the front lock nuts are in place, tighten the rear fold adjuster lock nuts to hold the required position.
8. Follow this process for both inner booms.

NOTE: It is important that both wings are adjusted the same. If one wing is adjusted further forward or back than the other, the boom may not sit level.



Continued over page


Boom Adjustment - 36-42 m

Alignment - Yaw - Outer

1. When adjustment of the inner booms is complete the outer booms can now be aligned.
2. Ensure the fold hinge breakaway spring tension has been set so there is a **2 mm gap** between the coils.
3. TriTech booms 36-42 m must be 50 mm forward of the inner booms. Use a string line to assist with achieving the correct measurements.
4. To adjust the outer boom to get them 50 mm forward, wind in or out the top boom stopper bolt.
5. Loosen the locking nut behind the fold cylinder clevis. Screw the cylinder rod out until the boom stopper bolt is up hard against the inner boom and the outer boom so it will not flop around.
6. Set the bottom stopper bolt to sit against the boom hinge. If this is not done, excessive twisting load will be exerted on the hinge.
7. Once the position is correct, tighten the lock nut on the stopper bolts and the nut on the hydraulic cylinder clevis.

NOTE: It is advised that all threads are lubricated prior to making adjustments.

NOTE: It is important that both wings are adjusted the same. If one wing is adjusted further forward or back than the other, the boom may not sit level.




Boom Adjustment - 36-42 m

Alignment - Tilt - Unfolded Position


When the boom is in the working position, the inner and outer boom should be level or slightly increasing in height from the centre section to give a consistent and even spray application height. A new boom may be susceptible to stretching or sagging as the components are worn in. Several adjustment may be required in the first 12 months of operation until the boom settles.

INNER BOOMS

- The boom centre section must be level with the chassis before any boom adjustments are made. The centre of the centre section should line up with the centre of the Paralift when look from the rear. This can be done by either shortening or lengthening the centre section adjuster bolt at the top delta links, or by adding weight to the booms.
- The inner booms must be adjusted first so they are the same height as the centre section or slightly increasing in height from the centre section (to allow for boom stretch) .These adjustments are made by lengthening or shortening the tilt adjusters on the tilt cylinder.
- To lengthen or shorten the tilt adjusters, the weight of both the booms will need to be supported.
- When any adjustments are completed. Ensure the lock nuts are tight.



NOTE: Keep distance between wear pad and tilt arm at 0-0.5 mm to prevent tilt arm twisting for prolonged product life. Replace wear strips when necessary.



Continued over page

Boom Adjustment - 36-42 m

OUTER BOOMS


- The height of the outer booms in the working position are adjusted by adding or removing shims at the fold hinge.
- The fold hinge mounts are assembled in manufacturing with 6-7 shims at the upper and lower bearing blocks.
- If the outer boom hangs lower than the inner boom, remove shims from the upper mount until the booms are level. If the outer boom is too high remove shims from the lower bearing block. Re-tension the retaining bolts to 65 Nm when all adjustments are complete.

For 36 m booms:

1 shim added = 20-30 mm change at boom end

For 42 m booms:

1 shim added = 30-40 mm change at boom end



Boom Adjustment - 36-42 m

Alignment - Tilt - Folded Position

When the booms are folded up in the transport position, the full weight of the booms must be supported by the inner boom. The outer aluminium boom may sit on the boom rest rubber but must not support any weight.


INNER BOOMS

- If the boom sits level in the working position but when folded up, one side is lower than the other, there is one adjustment that can be made.
- Shims can be placed at the bottom boom mount of the lowest boom - refer to diagram A. This will lift the boom in the open position.
- If the boom is not level in the working position, the most likely cause is if this is an out of balance boom. Refer to previous boom adjust information.

NOTE: This process should not be required as once they are set in manufacturing, they should not change.

When the booms are folded up in the transport position, the outer boom must saddle onto the inner boom. If this alignment is out the outer boom will not saddle correctly and will not be supported in transport.

The boom support saddle is bolted to the outer boom and when folded, couples to the inner boom.




This saddle must slide onto the inner boom freely to prevent damage to the booms.

NOTE: This process will be required in the first 6 months of operation as the booms stretch and wear in.

OUTER BOOMS

- If the outer boom hangs too low in the folded position shims must be added to the fold hinge pivots. To raise the outer boom, add shims to both the upper and lower pivots. This adjusts the angle of the pivot axis causing the outer boom to fold up higher. By adding shims to both the upper and lower pivots, the outer boom height is not affected in the working position.
- To lower the outer boom in the folded position, remove shims from both the upper and lower pivots.
- 1 x 1 mm shim at the upper and lower pivots equals approximately 15 mm change in height.




Continued over page

Boom Adjustment - 36-42 m

OUTER BOOM FOLDED POSITION GUIDE

- When the outer boom folds up it must saddle firmly against the inner boom.
- Pivot bracket to be touching the stopper plate when boom is folded in bi-fold.
- To keep the boom hard into the saddle, it may be necessary to press and hold the 'Bi-fold IN' switch in the cabin console for 5 seconds.
- If the outer boom misses the saddle on the inner boom, follow the instructions in the previous 'Vertical boom alignment - Folded Position' section.

NOTE: It is advised that all threads are lubricated prior to making adjustments.



Boom Adjustment - 36-42 m

Aluminium Outer Wing



When the booms are fitted at the factory, they are made level or slightly increasing in height from the centre section. Under working conditions the aluminium outer booms will need to be checked at every 50 hour intervals as per the Maintenance Schedule.

If the aluminium outer boom is not level in the working position, then a likely cause of this may be sagging or stretching.


Shims may need to be placed or removed at the fold hinge bearing blocks to get the booms level. Refer to Vertical boom alignment - working position.

If the aluminium top cords around the bolts show any signs of movement, then the bolts will need to be tightened.

Adjustments should be performed with the boom in the lowered working position. Check that the end plate to cords are at 89-90 degrees to each other. If the angle is too large then the wing is sagging. Set the angle correctly using the top bolts and re-tighten to 37 lbft / 50 Nm. The U-bolts should be done up just tightly enough to hold the position set by the upper chord bolts. Overtightening the U-bolts on the diagonal chord will bend and damage the boom.



Above: Cross section of top chord mounting.
Note orientation of spacer inserts.



Boom Adjustment - 36-42 m

Hydraulic Yaw Setup

The hydraulic yaw suspension system uses hydraulic cylinders and nitrogen filled accumulators to dampen and control the back and forth sway (yaw) of the booms.

The hydraulic yaw system is a closed hydraulic circuit. The base of the right hand yaw cylinder is connected via hydraulic hoses to the rod end of the left hand cylinder. A nitrogen charged accumulator (70 bar for 36 m booms) is connected via a t-piece into the cross over hose. The base of the left hand cylinder is connected via hydraulic hose to the rod end of the right hand cylinder. A second nitrogen charged accumulator (70 bar for 36 m booms) is connected via a t-piece into the other cross over hose.

If the boom yaws to the left, the right hand cylinder will try to compress. This will push oil out of the base of the right hand cylinder into the rod end of the left hand cylinder also into the accumulator against the precharge pressure (70 bar for 36 m booms). Because the hydraulic yaw is a closed circuit the oil movement is restricted by the precharge pressure in the accumulator. This precharge pressure is what resists the boom yaw movement and pushes it back to the centered position. If the boom yaws to the right the opposite action occurs.

The circuit precharge needs to be monitored and maintained. Gauges on the centre section display the closed loop hydraulic yaw pressure. This pressure should be maintained at 100 bar.

NOTE: When the hydraulic yaw system is installed or any components are replaced, the closed loop hydraulic circuit needs to be bled of any air. The maximum pressure needs to be set, the system charged and the booms aligned.

BLEEDING YAW CIRCUIT

When the hydraulic yaw system is installed or any components are replaced, the closed loop hydraulic circuit needs to be bled of any air, the maximum pressure set, system charged and the booms aligned.

1. Park the machine on a flat level surface, engage the parking brake and chock the sprayer wheels.
2. Open the boom into the working position and lower to the minimum working height. (Ensure there is ample room in front and behind the boom as it will be required to oscillate.)

3. Isolate the boom lift cylinders by rotating the Paralift cylinder ball valves to the OFF position.
4. Remove the covers from the in-line test point on the accumulators.
5. Connect the bleed hose (supplied in the sprayer kit) to in-line test point on the accumulators.
6. Couple the bleed hose quick connect end to an external hydraulic source, such as a tractor.
7. Using the external hydraulic source, oscillate the boom back and forth ensuring to hold the boom at its extremities for approximately 30 seconds in each direction. Start by activating the hydraulic source in one direction. The boom will oscillate forward and stop when the hydraulic cylinder is fully extended.

Hold the hydraulic supply in position for at least 30 seconds to ensure that the hydraulic cylinder is fully extended. Move the hydraulic source in the opposite direction until the opposite cylinder is fully extended, again hold in position for 30 seconds to ensure the cylinder is fully extended. Repeat this at least 15-20 times to bleed any air from the system.



Continued over page

Boom Adjustment - 36-42 m

- When oscillations are complete move the boom into a perfect centred position as shown below:



- Check that the pressure gauges in the hydraulic yaw circuit are reading below 100 bar.
- Close the hydraulic yaw charge ball valves.
- Disconnect the bleed hose from the tractor or external hydraulic source, and then remove the hose from the in-line test points. Replace the cover on the test point.
- Next, see 'Charging Yaw Circuit'.

CHARGING YAW CIRCUIT

When the hydraulic yaw system is installed, or any components are replaced, the closed loop hydraulic circuit needs to be bled of any air; the maximum pressure set, system charged and the booms aligned.

- Park the machine on a flat level surface, engage the parking brake and chock the sprayer wheels.
- Open the boom into the working position and lower to the minimum working height.
- Isolate the boom left cylinders by rotating the Paralift cylinder valves to the off position.
- Open the hydraulic yaw charge ball valves.
- Activate the boom lift circuit and maintain constant pressure for 30-60 seconds. This will generate maximum hydraulic oil pressure in the sprayer hydraulic circuit.

NOTE: The pressure reducing valve in the circuit limits the main hydraulic pressure to 100 bar entering the hydraulic circuit.



Left: Yaw charge ball valves in the OPEN position.

- After 30-60 seconds release the lift circuit and isolate the hydraulic yaw charge ball valves by rotating them to the OFF position. The pressure gauges in the hydraulic yaw circuit should be reading 100 bar:



Left: Yaw charge ball valves in the CLOSED position.

- Ensure that the boom is sitting level and aligned correctly. If one side of the yaw is sitting forward of the other; OPEN the charge ball valves and push the boom around to centre the boom and cylinders. Once aligned CLOSE the charge ball valves. Check the pressure gauges are still at 100 bar.

Continued over page


Boom Adjustment - 36-42 m

RECENTERING BOOM

1. Park the machine on a flat level surface, engage the parking brake and chock the sprayer wheels.
2. Open the boom into the working position and lower to the minimum working height. Ensure that there is ample clear space in front and behind the boom for it to oscillate in.
3. Isolate the boom lift cylinders by rotating the Paralift cylinder ball valves to the OFF position.



4. Open the hydraulic yaw charge ball valves.



Left: Yaw charge ball valves in the OPEN position.

5. Oscillate the boom by hand to bring the boom and cylinders into the desired center position.



6. The pressure gauges in the hydraulic yaw circuit should be reading 100 bar.

7. Close the hydraulic yaw charge ball valves.



Left: Yaw charge ball valves in the CLOSED position.

Boom Adjustment - 36-42 m

Breakaway - Mid Boom

The back and forth type movement that occurs when the boom is unfolded in the working position is controlled by a breakaway mechanism between the inner and outer boom. It consists of a set of springs, a turnbuckle, a cable, a pivot mechanism on the fold cylinder and a pair of dampers connected to the pivot. The springs are connected to the inner boom and prevent the boom from moving around too freely, but also allow the boom to breakaway when required.

The bi-fold and all other folding cylinders are fed from the main hydraulic pressure system. The bi-fold system uses a flow divider to ensure they both fold evenly.

HYDRAULIC CUSHIONING ADJUSTMENT


An adjustment can be made to the cushioning in the bi-fold cylinders. When the outer boom folds out, the cylinder slows towards the end of its stroke which is pre-set.

When the outer boom folds in for either a bi-fold or a full boom fold, the cylinder slows down as it gets closer to full compression. This is to avoid slapping the inner boom and causing damage.

NOTE: Monitor the outer boom folding to ensure they are not folding in too quickly. Make adjustments where necessary.

Use a 13 mm spanner to undo the lock nut. Wind in the adjustment screw to increase the cushioning and wind it out to decrease the cushioning. Decreasing the cushioning will also increase the speed at the end of the stroke.

The adjuster screw will come to a stop when wound out to the full adjustment. If this is done, there will be NO cushioning when the boom is folded.





WARNING: Working with hydraulics can be dangerous. While operating the boom, all people and objects should be clear of the boom wing fold radius. Nobody should be on or near the centre section, while hydraulic functions are operated.


BREAKAWAY TENSION ADJUSTMENT

The fold hinge between the steel inner and the aluminium outer has a breakaway system incorporated into the folding system. When the boom is fully open and an object hits the aluminium outer, the boom will fold back against the hydraulic cylinder and when the boom passes the object, the springs will bring the hydraulic cylinder back to working position and have the boom straight. To set the spring tension the booms must be open. Ensure the pivot bracket is against the stop, then adjust the turnbuckle so that there is a 2-3 mm gap between each spring coil.

This will ensure that there is always pressure on the hydraulic cylinder when the boom is open.



Boom Adjustment - 48 m



Above: Top view of boom & tilt angle adjustment.

Alignment - Tilt

The boom is divided up into three stages and a breakaway end. These stages need to have their alignment angles adjusted at each pivot area.

BEFORE YOU BEGIN

- Park the machine on a flat level surface, engage the parking brake and chock the sprayer wheels.
- Start with the boom in the working (unfolded) position.

NOTE: It is important that both wings are adjusted the same. If one wing is adjusted further forward or back than the other, the boom may not sit level.

TILT ANGLE ALIGNMENT PROCEDURE:

FIRST STAGE

- The first stage tilt angle is electronically controlled by an adjustable sensor at pivot A.




1. Follow "Before you begin" instructions above and then start the engine and make sure that all persons and objects are clear of the booms.
2. Loosen, but do not remove the screws on the tilt angle sensor (Phillips head screwdriver).
3. Slots in the sensor mounting tabs allow it to swivel when the screws are loosened. Rotate it in the same direction that the first stage needs to adjust in. Aim for an angle 0.2° above the horizontal ground plane.
4. Once the correct alignment has been obtained, re-tighten the screws on the tilt angle sensor (Phillips head screwdriver).
5. Shut down the engine.

Continued over page

Boom Adjustment - 48 m

SECOND STAGE


- The second stage tilt angle is adjusted using the clevis joint threads at pivot B.



- The second stage fold should be adjusted so that it is angled 0.2° higher than the first stage. The alignment will be ideal when the second stage just touches the keeper of the first stage when folding closed.
1. Loosen the locknuts on the upper and lower clevis joint threads ($1 \frac{7}{8}$ " inch spanner).
 2. Winding the top clevis closer to the first stage will cause the second and remaining stages to sit higher in the open position. When folded it will sit lower than before. If angled up too much when open, it will sit below the keeper when folded and not be able to close properly. Some trial and error will be required to check that the boom is vertically aligned correctly in both the open and closed positions.
 3. Once the correct alignment has been obtained, re-tighten the locknuts on the upper and lower clevis joint threads ($1 \frac{7}{8}$ " inch spanner).


THIRD STAGE

- The third stage tilt angle is adjusted using the clevis joint threads at pivot C.



- The third stage fold should be adjusted so that it is angled 0.2° higher than the first stage. The alignment will be ideal when the third stage is closely parallel with the second stage when folded closed.
1. Loosen the locknuts on the upper and lower clevis joint threads ($1 \frac{7}{8}$ " inch spanner).
 2. Winding the top clevis closer to the second stage will cause the third stage and breakaway end to sit higher in the open position. When folded it will sit lower than before. Some trial and error will be required to check that the boom is vertically aligned correctly in both the open and closed positions.
 3. Once the correct alignment has been obtained, re-tighten the locknuts on the upper and lower clevis joint threads ($1 \frac{7}{8}$ " inch spanner).

Boom Adjustment - 48 m



Above: Top view of boom & yaw angle adjustment.

Alignment - Yaw

The boom is divided up into three stages and a breakaway end. These stages need to have their alignment angles adjusted at each pivot area.

BEFORE YOU BEGIN


- Park the machine on a flat level surface, engage the parking brake and chock the sprayer wheels.
- Start with the boom in the working (unfolded) position.

NOTE: It is important that both wings are adjusted the same. If one wing is adjusted further forward or back than the other, the boom may not sit level.


YAW ANGLE ALIGNMENT PROCEDURE:

FIRST STAGE

- The first stage yaw angle is adjusted by adding or removing shim plates from the fold rams mounted on the centre section at pivot A.



1. Loosen and remove the top two bolts, nuts and washers holding the fold ram and dampers together (18 & 19 mm spanner/socket). Loosen the lower two sets but do not remove them; the shim plates will need to rest on them.



Continued over page

Boom Adjustment - 48 m

2. The first stage yaw angle should be adjusted such that it points 50 mm forward of the centre section. A string line can be used as a guide. Alternatively, it may be helpful to observe the boom from underneath as the bottom chords are 50 mm wide all along the stages and provide a visual reference for the offset amount.
3. The two open slots in the shim plates should be facing downward when inserted to sit on the loosened but not fully removed bolts. Insert or remove shims by trial and error until the 50 mm offset has been achieved. Replace and tighten all nuts, bolts and washers (18 & 19 mm spanner/socket).



SECOND STAGE

- The second stage yaw angle is adjusted using the two stopper bolts and catch at pivot B.



1. Loosen the lock nuts on the upper and lower stopper bolts. Back the stoppers off so that they are not touching the second stage (1 1/2" inch spanner).
2. The catch position should be extended or retracted to place the end of the second stage 50 mm in front of the end of the first stage. Loosen the lock nut on the catch on the side to be shortened and tighten the nut on the side to be lengthened (1 1/2" inch spanner).
3. Once the catch is in the desired position, wind out the upper and lower stoppers to touch the second stage. Check that the catch hooks are just barely touching to ensure smooth operation of the mechanism.
4. Re-tighten the lock nuts on the stoppers (1 1/2" inch spanner).

THIRD STAGE

- The third stage yaw angle is adjusted using the stopper bolt on the end of the damper at pivot C.



1. Loosen the lock nut on the stopper: Wind the stopper out to push the third stage forward or wind it in to let it come backwards (1 1/2" inch spanner).
2. Once the position has been adjusted such that the end of the third stage sits 50 mm in front of the end of the second stage, re-tighten the lock nut on the stopper (1 1/2" inch spanner).

Boom Adjustment - 48 m


Hydraulic Yaw Setup

Boom yaw is controlled by a pair of hydraulic rams and accumulators. Oil in these circuits flows through the spool block mounted on the back of the boom centre.

BEFORE YOU BEGIN

- Park the machine on a flat level surface, engage the parking brake and chock the sprayer wheels.
- Start with the boom in the working (unfolded) position.

YAW ANGLE ALIGNMENT PROCEDURE:



1. Wind out (counterclockwise) both the 'Yaw A' and 'Yaw B' valves to open them fully.
2. Move the boom around by hand until it is sitting perpendicular to the chassis of the machine.
3. Wind in (clockwise) both the 'Yaw A' and 'Yaw B' valves to close them fully. The default yaw position is now set.

YAW LINE AIR PURGE PROCEDURE:

- This procedure is typically only necessary when the hydraulic yaw circuit has been opened, such as when replacing a component e.g. hose.
1. Wind out (counterclockwise) the 'Yaw Bleed' valve to open it fully.
 2. Start the engine and then move the boom around by hand for a minute or so to help force air out of the hydraulic yaw circuit.
 3. Wind in (clockwise) the 'Yaw Bleed' valve to close it fully.
 4. Shut down the engine.

YAW LINE PRESSURE SETTING PROCEDURE:

- The hydraulic yaw pressure setting determines the effective stiffness of the yaw damping.
1. Connect a pressure gauge capable of reading up to 3000 PSI or more to the test port.
 2. Follow the "Before you begin" instructions and start the engine.
 3. The hydraulic system will build pressure when a function is activated. Preferably engage 'Stage I Fold' OUT as the boom is already folded out and will not move in a hazardous way.
 4. Once pressure has built up fully, use the pressure reducing valve to set it higher lower as necessary. The target pressure for the 48 metre boom is 1700 PSI. Loosen the lock nut first and then wind it in to increase pressure or wind it out to decrease pressure.



NOTE: If the pressure is too high then wind out (counterclockwise) the 'Yaw Bleed' valve to reduce it in addition to the pressure reducing valve. Then, close the 'Yaw Bleed' valve and check the maximum pressure achieved again. Pressure will not decrease on the gauge if only the pressure reducing valve is wound out.

5. Re-tighten the lock nut on the pressure reducing valve once the pressure is set.
6. Shut down the engine and disconnect the pressure gauge.

Three Dimensional Breakaway - 36-48 m

Initial Setup

1. Open the boom fully into the working position and lower to a good working height.
2. Close the ball valves on the two hydraulic lift cylinders for safety purposes.
3. The lower pivot plates need to be in line with each other (fig. A).
4. If the rose end is removed for any reason, anti seize should be applied to the thread before it is screwed into the boom tip. The rose end should be screwed into the breakaway tip so that it measures 52 mm from the boom tip face plate to the centre of the rose end (fig. B). Apply Loctite 243 thread lock to the grub screw and fasten.
5. The small hole in the sprocket must align with the hole in the side of the pivot plate. This is adjusted by tightening or loosening the turnbuckle (fig. C).
6. The spring tension must be adjusted so there is a 1-2 mm gap between the coils. This applies the ideal amount of resistance when breaking away. The spring tension can be adjusted by tightening or loosening the eye bolt.

TO ADJUST TURNBUCKLE


Pull the boom tip back until the large hole in the sprocket aligns with the hole in the pivot side plate, put a pin through the holes and release the tip.

Make adjustments to turnbuckle. Pull tip back and remove the pin. Release the tip and check alignment of small hole in sprocket with pivot plate. Repeat previous steps until the small hole in the sprocket and hole in the side plate align.

Maintenance

There are several things that need to be done to ensure that the breakaway will be functioning properly.

- There are two main things that are critical to the breakaway functioning correctly. The small hole in the sprocket needs to align with the hole in the side of the pivot plate (see step 5 - Initial Setup) and the spring tension. Check these on a regular basis and adjust as required.
- The spring will stretch over time and will lose tension. A spring is worn and should be replaced when there is no tension on the spring and it doesn't fully retract.
- To ensure the smooth and long lasting operation of the breakaway mechanism, it must be lubricated on a regular basis. The sprocket pivot, chain and lower rose joints should be oiled with a wet lubricant every 8 hours. The upper rose joint should be greased every 8 hours.




Centre Level Adjustment 36-48m


If the centre and the booms tilt excessively when folding, the Centre Level cables may need to be adjusted.

To check if the booms are tilting when folding, have somebody stand behind the sprayer out of the booms reach. Have them take note which direction the booms are tilting too far when folding.

Then unfold and adjust the cables to compensate for the tilt. Then repeat procedure until the booms are level when folding.



Above: Centre level cable adjusters (36-42m Boom)



Above: Centre level cable adjusters (48m Boom)

Chapter 10

LUBRICATION & MAINTENANCE

Recommended Lubricants

- For differing weather conditions consult your Cummins operator's manual to choose the suitable oil grade.
- Ensure that lubricants are stored in a place where the lubricants are protected from contamination (such as dirt and moisture). Always use clean containers when handling lubricants.
- Do not mix lubricants. Proper lubrication may be affected by differences in chemical composition.
- Seek advice from your petroleum dealer on the correct use of lubricants and additives.

SERVICE ITEM	SERVICE SPECIFICATION	CAPACITY (L)
Engine Oil	SAE 15W-40 heavy duty engine oil that meets Cummins standard CES20078 API1 & CI-4	15L
Hydraulic Oil	46W Dedicated hydraulic oil eg: Total Equivis ZS 46	90L
Transmission 3000 Series 6 Speed	Castrol Allison Transynd - TES295	35L approx. (dry)
Transfer Gearbox	Synthetic FE 75W-90	5.2L approx.
Differential Rear Axle	80W90 API GL-5	24L (fill to level hole)
Differential Front Axle	80W90 API GL-5	17L (fill to level hole)
Planetary Hubs - Front	80W90 API GL-5	1.9L (fill to level hole)
General Grease Points	Multi-Purpose Grease	-
Steering Pivot Points	Molybdenum Based Grease	-
Coolant	TEC PG XL Cummins	39L approx.
Diaphragm Spray Pump	SAE 15W40	2.79L for Zeta 300
Air Conditioning	Oil, Sanden SP20	571ml dry
	Gas R134a	2kg
Auto Greaser	EP0	4 L
Rapidfire Oiler	AirTool Oil	50ml

Goldacres are applying G15 anti corrosion spray to all fasteners (bolts, washers and nuts) and zinc plated components at the time of manufacture.

G15 should also be applied to the sprayer pre and post season.

As a guide, application to following areas is recommended but not limited to; Pump mounting bolts, Boom rests, Left hand POD, Mudguard mounting bolts, Induction Hopper bolts & latches, Hydraulic manifold, Boom hinge bolts, Airbag hose fittings and Hydraulic hose crimp fittings etc.

Filters

SERVICE ITEM	PART NO. - GOLDACRES	PART NO. - GENERIC
Hydraulic Return Filter	GA5069056	-
A/C Carbon Filter	GA5066740	P277
Air Cleaner Primary Element	GA5069031	P608666
Air Cleaner Safety Element	GA5069032	P601560
Engine Oil Filters	GA5051755	LF3970
Transmission Oil Filters - Lube & Main	GA3500140	Series 3000 = 29548988 kit
Fuel filter (primary)	GA5051760	FS1242
Fuel filter on engine	GA5051765	FF5612 , FF5421
Fuel Filter in-line	GA5069895	WZ153 (3/8" tails)


Replacement Globes

SERVICE ITEM	PART NO. - GOLDACRES	PART NO. - GENERIC
Headlight - Low Beam	GA3000082	HB3 12V 60w
Headlight - High Beam	GA3000082	HB3 12V 60w

Headlight Adjustment

The headlights on the Super Cruiser use an HB3 globe type globe. To replace the globe, the bonnet will need to be unclipped on both sides and rolled forward. Do not let the bonnet roll forward under its own weight. Lean over the cold engine and unclip the loom from the globe and then unclip the globe from the headlight housing and remove. Replace with new globe and follow the instruction in reverse. Ensure bonnet has been re-clipped before driving.

Headlight alignment can be made by adjusting the three screws located around the headlight body. Make a change and then check to see the movement was in the correct direction.



Wheels

Tyre Changing

- Only an experienced person working with the correct equipment should change the wheels.
- When changing a wheel, ensure that the sprayer is on hard, level ground and the wheels at the opposite end of lifting are chocked.
- Remove the isolator and the key from the ignition.
- Before raising the machine off the ground ensure that the boom is at its fully closed position.
- Where possible empty the spray tank before lifting the machine.
- Place the jack securely under the jacking point and gently raise the machine until the weight has been removed from the wheel.
- Do not support the sprayer using materials that may crumble.
- Do not work under the machine when supported solely by a jack.

NOTE: When the tank is fully loaded each wheel supports a weight up to approximately 4 tonnes. Always ensure that the jack is designed to operate under this pressure.

Tyre Maintenance

- Maintain the correct tyre pressure at all times. Inflation above the recommended pressures may cause damage to the tyres.
- Extreme caution is required during the inflation of tyres. If tyres are inflated at a rapid rate then the tyre rim combination may explode. This can result in serious or fatal injuries.
- When inflating a tyre regularly check the tyre pressure with an inflation gauge.
- Do not weld, heat or modify the rim, as this is likely to weaken the rim.

Be proactive and regularly check the condition of your tyres.

Tyre Pressures

The tyres on the Super Cruiser operate under harsh conditions. High road speeds and high loads can cause tyres to wear prematurely. It is very important that tyres are maintained and operated correctly. Tyre pressures are the most important factor in maintaining the correct load rating of the tyre.

It is advisable to protect the tyres as much as possible to reduce deterioration.

Chemical sprays and insecticides are harmful to the rubber in the tyres and should be washed off after use.


Tyre Pressures must be checked daily to maintain a satisfactory working life.

Also see chart in Chapter 3 'General Information & Specs'.

Wheel Nut Tension

Wheel nuts must be tensioned daily when the machine is new or when the wheel nuts have been removed and refitted.

Once the wheel nuts hold their tension inspection can be lengthened to approximately 50 hours. Wheel nut tension specification on the Super Cruiser front and rear wheels is 350 ft/lb.



Above: Follow this tightening sequence to ensure even wheel nut torque distribution (350 ft/lb).

Suspension

The five point suspension system used on the machine consists of four parallel links, one Panhard rod and two air bags on each axle. The rear axle of the machine is also fitted with an anti roll sway bar.

Parallelogram links hold the axle in place on the chassis. Panhard rods hold the axle centred in the chassis. The parallelogram arms allow the axle to distort or twist forward and backwards when the wheels come in contact with an obstruction such as a pot hole, log or embankment. This oscillation is absorbed by polyurethane bushes in each end of the links. The life time of these bushes is subject to the conditions the machine operates in and the style of operation that it receives. The polyurethane bushes should be checked at regular service intervals as stated in this manual. Air bags mounted on to each side of the axle allow the axle to oscillate.

Polyurethane Bushes

There are two sized polyurethane bushes used in the suspension system on this machine. The first bushes are located in the Para Link and Panhard rods. There are 20 of these bushes used in the machine and they can be purchased from your Goldacres dealer.

The second bushes are located on the sway bar.

Polyurethane bushes wear gradually over time and should be checked for movement during servicing. If there is any play in these bushes they should be replaced.

Parallel Link

Each end of the parallel link is attached to the chassis and differential with polyurethane bushes and 3/4" high tensile bolts. These links hold the axle in place while the bushes allow deflection when the wheels come in contact with an impact such as wash out or embankment. The bolts and bushes should be checked each time that the vehicle is serviced. If the axle is tending to twist or rock the bushes must be replaced.

Shock Absorbers

There are four shock absorbers fitted to the machine, one fitted to each side of the front and rear axle. The shockers dampen the movement of the air bags to prevent recoil. These should be checked for damaged rubbers or oil leaks.

Panhard Rods

The Panhard rods fitted to the machine are designed to prevent any sideways movement of the axles and to hold the axles central to the chassis. These rods are attached to the top of the axle and bottom of the chassis with two polyurethane bushes and 3/4" high tensile bolts. These bolts and bushes should be checked each time that the vehicle is serviced. If the axle is tending to twist or rock the bushes must be replaced.

Sway Bar

The sway bar is attached to the chassis and top of the rear axle with polyurethane bushes. This bar is designed to prevent excessive roll in the vehicle. The bushes should be checked each time that the vehicle is serviced.

Air Bags

The four air bags use compressed air to inflate them. They have ride height valves attached to the chassis and axle. As a load is exerted on the chassis the air bags will compress lowering the ride height valve arm. The ride height valve will then let air into the air bag causing it to inflate. As load is lessened on the axle the air bags will expand raising the arm of the ride height valve. The ride height valve will exhaust letting air flow out of the air bag causing it to deflate until the ride height arm becomes level again.

The air bags have internal rubber bumps that prevent the air bag bottoming out and jarring when the axle contacts large obstacles.

The rear axle has two ride height valves which level the sprayer; the front axle has one ride height valve in the middle of the axle which maintains the required height and allows it to pivot freely.


Air Bag Height Settings

The front air bag height should be set at 340 (+-5) mm. The rear air bag height should be set at 280 (+-5) mm. If this distance is not maintained the angle of the drive shaft changes causing a vibration and possible damage to the drive train.

The front & rear air bag is measured from the inside of the top mount to the bottom of the plastic skirt of the air bag.

Continued over page

Suspension



PROCEDURE TO EVACUATE AIR BAGS FOR TRAILER TRANSPORT



Loosen the drain tap on the air tank and drain the air. Loosen the fitting on the top of the air bag mount and release the air in the air bags. The air bags will lower on to the bump stops. Once the machine is on the bump stops tighten up the air tank valves and the fittings to the air bags. Don't alter or change the height control valve linkages to release the air.

Ride Height Valve Adjustment

The ride height valves are used to adjust the air pressure within the air bags to maintain the correct ride height. There are two ride height valves located on each side of the rear axle and one located in the centre of the front axle.

The ride height can be adjusted by loosening the hose clamp attached to the vertical rod on the end of the ride height valve and then moving the valve arm in the required direction.

When the sprayer has been unused for a period of time, the air bags may deflate, this is normal. They will refill when the machine is started.




Steering

Steering Toe In

Steering toe-in should be set to 0-5 mm. To check this measurement follow these steps:

Park the machine on a flat level surface.

1. Apply the parking brake and remove the keys from the ignition.
2. Measure up from the ground 900 mm on the front of the steer tyre and mark.
3. Repeat for the rear of the steer tyre.
4. Measure between the front of the left and right steer tyres at the mark previously made and record.
5. Measure between the rear of the left and right steer tyres at the mark and record.
6. The front measurement must be 0-5 mm less than the rear measurement.
7. To make an adjustment, loosen the tie rod lock nuts and then loosen or tighten until the toe-in measurement is correct. Re-tighten the lock nuts.



Above: Measurement X should be 0-5 mm less than measurement Y.

Camber

The wheel camber is a factory set parameter and cannot be adjusted. At the time of manufacture the wheel camber is set to $+0.5^\circ$.

Steering Swivel Housing

The front axle has a steering swivel on both side and on the top and bottom of these is a grease point, these should be greased every 100 hours.

Inside the swivel, there is a universal joint and this also needs grease at the same intervals as the steering swivel.

Pneumatic System

The pneumatic system on this machine is used to operate the air bags, control the cabin access ladder, and engage and disengage differential locks and also for the RapidFire spray system.

Air Tank

The air system fitted to this machine incorporates a single air tank located under the transmission on the chassis cross member.

Due to condensation in the tank, it must be drained daily. To drain fluid from this tank, a drain tap has been placed into the bottom of this tank. The tank must be drained on a 10 hour or daily basis.

To drain the air, turn the manual drain tap on tank and allow the condensation and air to escape from the tank.

CAUTION: Beware of high-speed particles leaving the tank. Also be aware that due to the expansion of the air the valve may become very cold.

Compressor

The compressor used on this system is attached to the timing gear case on the rear of the engine. The output of the compressor is connected to the input port on the tank. To regulate the amount of air being generated by the compressor a governor is attached to the side of the compressor. This governor is connected with a sense line back to the tank.

The governor enables the compressor to continue pumping until the required tank pressure is achieved. Once this pressure is reached the governor stops the compressor pumping air. The governor is set to stop the compressor when a pressure of 120 PSI is reached.

Pressure Relief Valve

To prevent the pressure within the air system exceeding acceptable limits, the tank has a pressure relief valve built onto the top of the tank. This valve is set to operate when a pressure of 150 PSI is reached and vents the air to atmosphere.

Pneumatic Cylinder



There is a pneumatic cylinder used on the cabin access ladder. This cylinder gets air flow from the pneumatic block. There is a flow control needle valve on the inlet of the cylinder to control the speed of the ladder when raising and lowering.

To increase or decrease the speed of the ladder going down, the needle valve on the flow control can be screwed in to decrease the speed and screwed out to increase the speed.

NOTE: The speed of the ladder is set at the factory and if adjustments need to be made, ensure that the safety precautions are followed.

Quick Release Air Coupling


Air supply is available out of the air tank to blow out filters and nozzles etc. A Ryco 290 series, super high-flow airline coupling has been placed in the system. This coupling is located in the pneumatic block. Located on the right hand side, inside the chassis rail near the fresh water tank as shown in the image.



Braking System

The braking system for the Super Cruiser is hydraulically driven. The hydraulic pump mounted on the engine supplies oil to the braking circuit and gives priority to the brakes once the accumulators are fully charged. Hydraulic pressure goes from the accumulators to the foot pedal and then to the wet brake system in the front and rear axles.

The hydraulic pressure drives a wedge into the disk body and clutch disks, and on the rear axle when there is no pressure, it acts as a park brake.



There is two brake control cylinders on each axle. On the rear, the brake control cylinders also operate the park brake. The park brake will always be applied when there is no hydraulic pressure going to the park brake chamber in the brake control cylinder.

There is no adjustment for the service brake function, if the braking performance deteriorates and it take more pressure to stop, the clutch disks may need replacing.

Bleeding the Brakes


The braking system is a hydraulic configuration. The front and rear brakes are operated from the main hydraulic pressure system.

To bleed the brakes, ensure that the wheels are chocked front and rear.

Each brake control cylinder and function must then be bled separately.

The method used to bleed the service brakes manually is to:

1. Connect a clear plastic tube to the bleed screw and place the opposite end of the tube into a container.



Bleed screw for Service brakes

Rear brake control cylinder

NOTE: The system should be bled until no more air bubbles appear in the bleed line.

NOTE: It is recommended that during this process the person bleeding the brakes wear suitable eye protection.

2. With an assistant in the cabin, start the engine (ensure no person is under the machine and the transmission is in neutral).
3. In the cabin, depress the brake pedal and hold.
4. Loosen the bleed screw and when there is no air and only a continuous stream of fluid in the clear hose, re-tighten the bleed screw before allowing the pedal to return to its released position.
3. Repeat this procedure for each of the other brake control cylinder assemblies.

Front brake control cylinders



Bleed screw for Service brakes

Continued over page

Braking System

Park Brake


The park brakes are only on the rear axle. The method to bleed the park brake is similar:

1. Connect a clear plastic tube to the bleed screw and place the opposite end of the tube into a container.

NOTE: The system should be bled until no more air bubbles appear in the bleed line.

CAUTION: It is recommended that during this process the person bleeding the brakes wear suitable eye protection.

2. With an assistant in the cabin, start the engine (ensure no person is under the machine and the transmission is in neutral).
3. In the cabin, depress the brake pedal and hold.
4. In the cabin, on the side console, switch the park brake OFF.
5. Loosen the bleed screw and when there is no air and only a continuous stream of fluid in the clear hose, re-tighten the bleed screw before allowing the park brake to be applied.



Bleed screw for
Park brakes


Rear brake control cylinder

6. Repeat this procedure for the other park brake control cylinder assembly.

Park Brake Adjustments

1. With the engine stopped, and the machine on a flat level surface. The wheels chocked.
2. Remove the cover from the brake control cylinder.
3. With a 13 mm spanner, loosen the lock nut until the 16 mm measurement is obtained.

4. With a 6 mm hex key, insert into the bore and wind down until there is strong resistance.
5. Now wind out 2 1/4 turns.
6. Now, wind down the lock nut until the 6 mm measurement is obtained.
7. Replace the cover on the brake control cylinder.



Park Brake Disengage

1. With the engine stopped, and the machine on a flat level surface. The wheels chocked.
2. Remove the cover from the brake control cylinder.
3. With a 13 mm spanner, loosen the lock nut until the 16 mm measurement is obtained.
4. Replace the cover on the brake control cylinder.

This will disengage the park brake for towing the machine, but also leave the machine with no form of braking when the engine is not running.

So the wheels will need to be chocked at all times when the engine is off and the machine is stationary.

Transmission

The Allison 6 speed automatic transmission oil level can be checked by using the dipstick located in left hand side of the transmission, under the cabin.


The oil level must be checked with the engine running. If the oil is cold (less than 70 degrees) the oil level must be in the lower range.

If the oil temperature is warm (above 70 degrees) the oil level must be in the upper range.

The two internal oil filters need to be changed as per the maintenance schedules and the Lubricants and Filters charts for servicing requirements.

Driveline

Fixed drive lines are used to transmit drive between the transmission, transfer gearbox and the differential. These drive lines have greasable universal joints at each end. All the shafts have a telescopic spline which also requires greasing. These drive lines should be inspected for wear and greased at regular service intervals.



Grease nipple

Grease nipple

Differential

The front and rear differential runs in an oil bath sump. The oil level can be checked by removing the level plug on the rear of the differential housing. The oil should be replaced at the first service to remove manufacturing contamination. Oil should be replaced every 500 hours.


Transmission Oil Cooler

The transmission oil cooler is integrated into the radiator.

Refer to the maintenance schedules and the Lubricants and Filters charts for servicing requirements.

Refer to the Allison Transmission operation and codes manual (supplied) for any information on operation or troubleshooting the Allison transmission.

NOTE: The lubricant specifications can be found in Chapter 10 'Lubrication & Maintenance'.



There is a breather located on the top of the differential. This allows the oil to expand and contract without pressurising or creating a vacuum the differential housing. Ensure the cap moves freely.


Front Axle

The front axle needs to be greased as found in Chapter 10 'Lubrication & Maintenance'. The front swivel, top and bottom needs to be greased, and the drive shaft yoke in the centre of the swivel also needs to be greased. The machine may need to be moved or the wheel lifted off the ground and rotated to access the grease nipples.

See images on next page for the greasing points.

Continued over page

Driveline



Planetary Hubs

The planetary hubs in the rear axle are open and part of the rear axle, and get their oil supply when the differential is filled with oil. The oil level can still be checked at each hub, independent to the differential oil level plugs.

When draining the oil from the rear axle, rotate the rear wheels so the drain plugs of the planet hubs are at the bottom, remove the plugs from the centre differential housing and the drain plugs from the planetary hubs. Replace the plugs when all the oil has drained.

Fill the rear differential to the level plugs in the differential housing and the planet hubs.

The front planet hubs need to be filled individually as they are separate from the centre differential. To check the oil in the front planet hubs, the front wheel needs to be rotated so the oil level plug is in the level position.


Remove the plug and see if the oil is level with the plug or just below, if no oil can be seen, more oil needs to be added to bring it back up to level.

To drain the front axle, remove the drain plugs from the centre differential housing. Replace when all the oil has drained.

Fill the front differential to the level plugs in the differential housing.

To drain the front planetary hub, rotate the front wheel so the drain plug is at the bottom. Remove the level plug to help the oil drain from the hub. Replace the plugs when all the oil has drained.

Fill the front planet hubs to the level plugs.




Transfer Case

The transfer case directs drive from the transmission to the front and rear axles. Engaging 4WD lock should only be performed when the machine is stationary.


The transfer case runs in an oil bath sump. The oil level can be checked by removing the oil level plug located on the side of the transfer case.

The oil should be replaced at the first service to remove any manufacturing contamination.


When draining the oil, the machine should be driven for a short time before hand to warm up the oil. This allows it to drain easier. Remove both the drain and fill plugs when draining the oil.



When filling the transfer case, the machine should be parked on level ground. Fill up to the oil level plug. Clean the oil level plug before refitting. See the 'Recommended Lubricants' section of this manual for information on which oil to use.




An air solenoid is located on the right hand side chassis side wall near the flush tank. When 4WD lock is switched on in the cab, the solenoid is activated. This then sends air from the solenoid, down to the shift cylinder on the transfer case. The cylinder is pushed in by the air and 4WD lock is selected.



This solenoid can be manually overridden if required. Locate the solenoid. The override screw is on the bottom. Using a flat head screw driver, push into the screw and turn a 1/4 turn in either direction. Air should now be flowing through the solenoid and 4WD lock should be engaged.

To disengage, turn the screw a 1/4 turn in the opposite direction to when it was overridden.



FRONT of machine

Hydraulics - General


The Super Cruiser sprayer is fitted with two hydraulic systems.

The first is used to operate the steering, hydraulic cylinders on the boom and spray pump.

The second system is used to operate the cooling fan and the brakes.

These systems operate from a common hydraulic reservoir. The reservoir has a sight tube mounted on the side. The oil level must always be visible in top third of the tube. The oil temperature will normally run at 60-80 degrees Celsius.

NOTE: The lubricant specification can be found in Chapter 10 'Lubrication & Maintenance'.



Main Hydraulic Systems

The first pump is a 63 cc variable displacement piston pump. This pressure line gives priority to the steering circuit first. The spray pump uses load sense to ensure the correct pressure for speed control. All other functions require an unloader to stroke up the pump to max pressure and flow (apart from spray pump & UltraGlide).


The second pump is driven from the air compressor drive. This pump operates the cooling fan and the braking system. This system will give priority to the brakes which also includes the accumulators, and when up to pressure and charge, the cooling fan will receive full pressure. Max cooling fan pressure is set to 175 Bar.

The braking accumulators are charged at 90 Bar; if one of the accumulators fail, a check valve will prevent the other accumulator from losing pressure. The pressure goes from the accumulators to the foot pedal, and then to the brakes in the axles.

The park brake hydraulics goes through a pressure reducing valve to ensure the pressure does not exceed 35 Bar. The park brake is actuated (released) with a solenoid valve after the cabin park brake switch is released.


Return Filter

The hydraulic filter is located in the tank in front of the cabin. This filter should be replaced after the first 50 hours of use and then every 500 hours after that. The return filter filters all of the return oil to the reservoir. There is a red indicator located on the top of the filter. If the indicator pops out then the filter must be replaced because it is blocked and causing back pressure through the system. This filter should be checked once the oil has reached operating temperature as cold oil can cause a false reading on the indicator.



Oil Cooler

The oil cooler is located under the rear of the cabin mounted on the chassis. This cooler uses an electric fan and a thermo switch to keep the oil at the optimum temperature. The cooler will switch on when the oil flowing through reaches 55°C. Ensure that the fins on the cooler are kept clear of debris.



Continued over page

Hydraulics - General

Hydraulic Pumps


The double hydraulic pump is attached directly to the engine air compressor. These pumps are positive displacement type pumps and are powered off the engine timing gears.



Above: Hydraulic pumps on left hand side of engine.

- The 22 cc pump is used to supply fluid for the brakes and engine cooling fan.
- The 32 cc pump is used to supply fluid for the spray pump.

After fluid leaves the hydraulic pump it travels through an accumulator charging manifold. It charges the brake accumulators, then the excess oil is supplied to the fan on the radiator.



Above: Hydraulic pump on left hand side of gearbox.

The 63 cc single hydraulic pump is attached directly on the side of the transmission to the transmission PTO. This pump is a variable displacement type pump and is powered off the transmission.

The pump is used to supply fluid for the steering and most hydraulic functions excluding the brakes, engine cooling fan and spray pump.

After fluid leaves the hydraulic pump it travels through a priority valve. This valve prioritises flow to the steering orbital. When the steering system has received sufficient flow, the priority valve begins to enable fluid to travel to the rear hydraulic circuit that controls boom functions. This flow is determined by the load sense line from the steering orbital.

PORT	DESCRIPTION
P	Pressure supply
CF	Supply to steering orbital
EF	Supply to solenoid bank
LS	Feedback from steering orbital

Steering Orbital



The steering orbital is located under the front of the cabin. This supplies oil flow to the steering cylinder when directed by the steering wheel.

PORT	DESCRIPTION
P	Pressure supply
R & L	Supply and return to steering cylinders
LS	Load sense to priority valve
T	Return to reservoir



Hydraulic Fill Pump (Optional)

The fill pump is controlled by the valve block mounted on the left hand side chassis rail under the cabin area.



Continued over page

Hydraulics - General

Hydraulic System Liquid Spray Pump Control Manifold

The liquid spray pump control manifold is located on the top of the hydraulic pump driving the spray pump. It is a pressure flow compensated valve. This means that the oil flow to the product pump can be maintained even if the pressure of the oil is increased or decreased. This allows the product spray pump RPM to remain constant even if engine RPM changes.

Spray Pump Solenoid

The liquid spray pump solenoid is a single acting spring return solenoid and is built into the liquid pump control manifold. When this solenoid is activated, fluid is forced to travel to the needle valve before travelling to the hydraulic drive for the liquid spray pump.


Spray Pump Needle Valve

The liquid spray pump needle valve is built into the liquid spray pump control manifold. This valve enables the speed of the pump drive to be adjusted. Maximum pump speed is factory set at 540 rpm and must not be exceeded.

If the pump still rotates when the pump has been turned off, the 10 bar check valve that is in the tank line from the pump needs replacing.

Setting Spray Pump RPM

1. Park the sprayer on even level ground. Leave the park brake on so the cabin access ladder remains down.
2. Chock all wheels of the sprayer, ensuring it cannot roll while it is being worked on.
3. Allow the hydraulic oil to reach operating temperature.
4. Set engine to around 2000 rpm.
5. Switch spray pump on.
6. Hold the outer adjuster and loosen the locknut behind it.
7. Set the spray pump speed to 540 rpm. Rotate clockwise (wind in) to decrease the speed, rotate anti-clockwise (wind out) to increase the spray pump speed.
8. Hold adjuster and tighten the lock nut.




Above: The speed adjuster is integrated into the priority flow block located in the centre of the chassis, just behind the front axles.

Suction & Delivery Lines

- Use good quality suction hose and fittings that will not collapse or leak air under suction.
- If pumping water from structures other than storage tanks, we recommend the use of an appropriate sized floating filter equipped with a check valve.
- It is essential that the suction line to the pump is the same size as the suction port (3").

A smaller size delivery line can be used but will reduce pump output.

Hydraulics - 36-42m



Electric Over Hydraulic Controls

The boom and fill pump functions are controlled by electric over hydraulics solenoids. These solenoids are energised by functions on the joystick/console in the cabin and switches on the EZ control station.

The boom functions are controlled by the solenoid block mounted at the top of the boom centre section. There is a gauge mounted at the left end of the block for diagnosis. When a hydraulic function is used, the hydraulic pressure will increase during that function.

PORT	DESCRIPTION
P	Pressure supply
T	Return to reservoir
A & B	Bi-fold and tilt cylinder connections
L1 & L2	Lift cylinders & yaw charge circuit

The boom rest and fill pump are controlled by the valve block mounted on the cross member of the chassis under the cabin.

The solenoid valve blocks have various functions.

The directional valve controls oil flow to the desired circuit. Each particular circuit can be identified by the tag on the wires attached to the solenoids.

The double operated check valve blocks oil flow through the solenoid when the solenoid is not energised. This prevents that function leaking down, for example if the right hand side of the boom was tilted up the double operated check valve will stop oil leaking through when the solenoid is de-energised and lower the boom, preventing it moving when the operator is not directing it.

The flow control allows the amount of oil flow to the hydraulic circuit to be varied thus adjusting the speed of that circuit. By turning the flow control adjustment in, clockwise, the flow is reduced thus reducing the speed at which that hydraulic function will operate. By turning the flow control out, counter clockwise, the flow is increased thus increasing the speed of that hydraulic function.

The block has a main pressure relief valve. This valve prevents excessive pressures within the hydraulic system (relief pressure set to 2250 PSI). During normal operation this will prevent any fluid bypassing the system. If a fault develops in the system, this valve will enable fluid to return to the tank, without causing damage to the system.

Continued over page

Hydraulics - 36-42m

Closed Centre - Load Sense System

The unloader solenoid is integrated into the priority flow block located in the centre of the chassis, just behind the front axles. The unloader solenoid can be identified as the cartridge solenoid on top of the block.

The 63 cc single hydraulic pump is a variable displacement type which is attached directly on the side of the transmission to the transmission PTO. The pump is used to supply fluid for the steering and most hydraulic functions excluding the brakes, engine cooling fan and spray pump.


After fluid leaves the hydraulic pump it travels through a priority valve. This valve prioritises flow to the steering orbital. When the steering system has received sufficient flow, the priority valve begins to enable fluid to travel to the rear hydraulic circuit that controls boom functions. This flow is determined by the load sense line from the steering orbital.

When the system performs a function, the gauge on the left hand end of the block should read 2500 PSI. If the reading is lower, contact your local Goldacres dealer for support.

Boom Raise & Lower Solenoids & Cylinders


The raise and lower boom solenoids are separate solenoids. The raise solenoid is a single acting CETOP 3 solenoid. The lower solenoid is a cartridge solenoid that has a one way check in its spool.

When the lift solenoid is energised oil flows from the pressure port in the CETOP 3 manifold through the lower solenoids one way check out to the lift cylinders. The oil flow can be controlled by the flow control spool under the lift CETOP 3 solenoid.



There is a lift lockout solenoid in the circuit, located on the accumulator manifold, at the rear of the machine. This feature is used to eliminate boom bounce when the wings are folded and boom rests are in during transport.

This solenoid can be overridden in the event that it becomes non operational. To do this, locate the red knob on top of it. Wind the knob all the way in. This will allow the flow of hydraulic oil to the lift cylinders.



This is a temporary solution to allow the boom to move up and down. It is recommended to troubleshoot the system to find the fault. If the problem can't be diagnosed, contact your dealer.

NOTE: When lowering the boom the unloader solenoid will not be activated.

Boom Open/Close Solenoid & Cylinders

The boom open/close solenoid is located in the bank of solenoids at the rear of the sprayer. This solenoid is a double acting solenoid.

Four hydraulic cylinders are used to open and close 42 m booms, while two are used on 36 m booms.

Tilt Left/Right Solenoid

The tilt left and tilt right solenoid is located in the bank of solenoids at the rear of the sprayer. This solenoid is a double acting solenoid.

Bi-fold Circuit

The Bi-fold solenoid is located in the bank of solenoids at the rear of the sprayer. This solenoid is a double acting solenoid.

The Bi-fold circuit has 2 double pilot operated check valves (mounted to the bi-fold cylinders) in the system to maintain the pressure in the boom lines when it is folded out in the working position.

Continued over page


Hydraulics - 36-42m



Above: Double pilot operated check valves are mounted to the bi-fold cylinders.

Centre Levelling System

The centre levelling system requires adjustment when the boom is folding closed unevenly. See the tilt adjustment procedure in Chapter 8.



Above: Centre level & cable adjusters.

Hydraulic Yaw

The hydraulic yaw circuit typically only requires attention when changing a component such as a hose or ram that would allow air into the system. See the air bleeding procedure in Chapter 8. Another situation that would require attention is when the yaw suspension seems to firm or too soft and is not controlling the boom movement well. In that case the system pressure should be adjusted. See pressure adjustment procedure in Chapter 8.



Above: Hydraulic yaw circuit pressure gauges & valves.

Hydraulics - 48m

Hydraulic Control Manifold


The 48 metre boom uses a hydraulic control manifold to distribute the various hydraulic functions of the boom.

A single central control spool valve allows oil into the manifold and is operated in concert with poppet valves for any given boom function. The advantage of this system is very low oil leakage compared to a purely spool valve operated system. Therefore any function operated will tend to stay in place until operated again later. This creates a safer and more predictable system for the operator.

The hydraulic system used is a closed centre, load sensing type.

It uses a variable displacement type 63 cc single hydraulic pump which is attached directly on the side of the transmission via the PTO shaft. The pump is used to supply fluid for the steering and most hydraulic functions excluding the brakes, engine cooling fan and spray pump.


After fluid leaves the hydraulic pump it travels through a priority valve. This valve prioritises flow to the steering orbital. When the steering system has received sufficient flow, the priority valve begins to enable fluid to travel to the rear hydraulic circuit that controls boom functions. This flow is determined by the load sense line from the steering orbital.



Above: Hydraulic control manifold (48m Boom)

Paralift Lock Out Solenoid

There is a lift lockout solenoid for the paralift rams located on the accumulator manifold, at the rear of the machine. This feature is used to eliminate boom bounce when the wings are folded during transport. This solenoid can be overridden in the event that it becomes non operational. To do this, locate the red knob on top of it. Wind the knob all the way in. This will allow the flow of hydraulic oil to the lift cylinders.



This is a temporary solution to allow the boom to move up and down. It is recommended to troubleshoot the system to find the fault. If the problem can't be diagnosed, contact your dealer.

Centre Levelling System

The centre levelling system requires adjustment when the boom is folding closed unevenly. See the tilt adjustment procedure in Chapter 8.



Above: Centre level & cable adjusters.


Hydraulic Yaw

The hydraulic yaw circuit typically only requires attention when changing a component such as a hose or ram that would allow air into the system. See the air bleeding procedure in Chapter 8. Another situation that would require attention is when the yaw suspension seems to firm or too soft and is not controlling the boom movement well. In that case the system pressure should be adjusted. Test gauges can be directly connected to the hydraulic control manifold. See the pressure adjustment procedure in Chapter 8.

Hydraulics - 48m

First Stage Fold Rams

The first stage fold rams have dampers attached to the back of them. The dampers are linked to an accumulator located inside the boom centre on the right hand side.




Above: First stage fold rams, dampers & accumulator.


Third Stage Fold Rams

The third stage fold rams play a dual role and also behave as dampers to a limited extent. This is due to the fact that even though the hydraulic control manifold keeps oil flow locked when the fold function is not being operated, there is still some expandability in the hoses. In this way, forward movement of the third stage is damped.

Rearward movement of the third stage is damped by a dedicated cylinder with a stopper bolt on the end for adjustment. This cylinder is connected to a dedicated accumulator mounted on the boom centre which controls the damping. The fold link is also slightly expandable to allow rearward movement of the third stage independently of the fold ram.



Above: Third stage fold linkage.



Above: Third stage fold damper accumulator.

Engine

Opening The Bonnet

The bonnet is fastened down by two latches on either side. Once open, the bonnet is supported by over centre weight.


CAUTION: If the engine has been running, take extra care around hot engine parts such as the exhaust.

CAUTION: When the bonnet is closed, ensure that the latches are tight before driving machine.

Fuel Filters

There are three fuel filters mounted on the left hand side of the engine.

The first filter is an in-line filter that is located behind the fuel tank near the parallel link arms on the left hand side.



The water separator or primary filter is mounted on the front of the left hand chassis rail. This filter is the second point from the fuel tank, it separates any water from the fuel and also filters contaminants.



This filter has a sensor in the base of it which will alarm when excessive amounts of water is detected in the fuel.

This filter should be replaced within the first 50 hours of use and then every 250 hours of engine operation.

The water trap at the base of the cylinder should be drained daily.

The Secondary filter is mounted on the left hand side of the engine. This filter is finer than the primary filter.



NOTE: Filter specifications can be found in the 'Filters' section at the beginning of this chapter.

Engine Oil & Filter

Check the engine oil level daily. The engine oil must be checked with the engine stopped. The engine oil dipstick must be removed from the engine tube, cleaned and then re-dipped to verify the correct engine oil level. The oil level must be between the 'ADD' and 'FULL' marks on the dipstick. If the oil level is below the 'ADD' mark top up the engine with the appropriate fluid. The lubricant specification can be found in the 'Recommended Lubricants' section of this manual.

The engine oil must be drained within the first 50 hours of engine use and then as per the maintenance schedule after that. To drain the engine oil place a container, at least 30 litre capacity, under the remote drain plug, located on the left hand side on the front cross rail in front of the fuel tank, and then remove the plug. The engine oil filler cap can be loosened to allow the oil to drain easier.

Once drained refit the oil drain plug and fill through the rocker cover on the top of the engine or the filler located near the dipstick. The oil can be checked via the dipstick on the left of the engine.

When the engine oil is changed the engine oil filter must be replaced. The engine oil filter is located on the right side of the engine. The filter is a spin on element.

NOTE: Oil and filter specifications can be found in the 'Recommended Lubricants' and 'Filters' sections at the beginning of this chapter.

Continued over page

Engine


Coolant

Super Cruiser radiators are fitted with a header tank. This allows for expansion of the coolant when the engine warms up. The radiator cap allows excess fluid to drain out of the over flow if the coolant expands too much. The coolant level must be visible from the lid of the header tank. The level will be 50 mm below the lid when the engine is cool.

Coolant level must be checked DAILY.

CAUTION: Never remove the radiator cap when the engine is hot.

The header tank is fitted with a level sensor. If the coolant drops below this sensor the engine controller will send an alarm through to the CanTrak console and shut the engine down.



Coolant must be checked at regular service intervals. Refer to maintenance schedule. Test kits are available from Cummins to check this.

The coolant must be replaced every 2000 hours. Quantity and type can be found in Chapter 10 'Lubrication & Maintenance'.

There are ball valves located on the heater hoses at the rear of the engine and also at the header tank. These ball valves can be isolated during hotter periods to allow the air conditioning system to operate more efficiently. When replacing the entire coolant system these ball valves must be opened so that all the air is bled from the coolant lines.



Engine Drive Belt

The engine drive belt is a serpentine belt that has a self tensioner on it. The belt requires inspection at regular service intervals. If the belt begins to slip the belt may require replacement as it can become laminated or slippery. If the tensioner loses its tension it can also cause the belt to slip and must be replaced. The belt should be replaced every 1000 hours.

To replace the engine drive belt insert a ½" drive into the tensioner arm and pull upwards.

Pull the belt off the pulleys and off the fan.

Fit the new belt in reverse, ensure all pulleys are aligned correctly with the belt before releasing the tensioner.


Air Conditioner Belt

The air conditioner compressor belt has a manual adjuster. To tension the belt the compressor mounting bolt and adjuster bolt must be loosened. To tighten the belt, use the lock nuts on the adjuster to pivot the compressor and pull the belt tight. When the belt is correctly tensioned tighten the retaining hardware.

There should be no more than 12 mm deflection in the belt when it is tensioned correctly. The compressor belt should be replaced every 1000 hours.

Engine Air Cleaner

The air cleaner is mounted to the top of the engine on the front right hand side. A vacuum gauge alerts the operator when the air cleaner becomes blocked. It is mounted to the side platform just in front of the windscreen on the left hand side and is visible from the cabin. The gauge will operate in the middle range when in normal working conditions, and in the 'RED' zone when blocked. This indicates that it is time to remove the primary filter and replace it.



Continued over page

Engine

It is recommended to inspect the filters when the machine is new. Inspection of the primary filter should be carried out at service intervals or when the vacuum gauge indicates. NEVER clean the secondary filter; this filter should be replaced if it is contaminated or damaged.

NOTE: Filter specifications can be found in the 'Filters' section at the beginning of this chapter.



Cabin Air Cleaner

A carbon air cleaner is fitted to the right hand side of the cabin. This filter cleans the impurities from the air being drawn into the cabin. The air is drawn in through the carbon filter by a fan and pressurises the cabin to prevent impure air entering the cab from any holes or seal leaks. The filter elements have a foam pre-cleaner covering them; this foam element can be removed and washed in water. The element must be totally dried before refitting. Carbon balls inside the filter capture any impurities in the air that are drawn through it. A colour indicator on the end of the filter identifies when the carbon balls need to be recharged to maintain filtering effectiveness. By removing the element from the housing and inspecting the colour of the carbon balls the service life can be witnessed. When the indicator shows the filter needs to be recharged it must be replaced with a new carbon filter or recharged by a certified agent.

COLOUR GUIDE:

Purple - Active

Brownish Orange - Active


Brownish Red - Requires recharging or replacing

NOTE: Filter specifications can be found in the 'Filters' section at the beginning of this chapter.

Clamp
thread



Air Conditioning System



NO.	COMPONENT
1.	Fan
2.	AC Evaporator
3.	Heater Core
4.	Heater Control Valve
5.	Heater Water Filter

Heating, Ventilation & Air Conditioning Operation

The air conditioning circuit operates by the pressuriser fan drawing clean air into the cabin through the carbon filter. This fan pressurises the cabin with clean air and forces air out any holes or leaking seals in the cabin ensuring no impurities can be drawn into the operator's clean environment.

The blower fan then pulls air through the air conditioning evaporator and heating evaporator and pushes it to the demist and roof vents. If the air conditioning compressor is engaged the air conditioner evaporator will cool the air as it is drawn through it. If the heater thermostat is turned to heat, the air will warm again as it passes through. If the heater is off, the cool air passes through to the vents.

Compressor

The air conditioning compressor is located on the front side of the engine. This compressor is connected to the engine by a v-belt. The compressor is engaged when ever the cabin blower fan switch is energised. The thermostat will cycle the air compressor if the evaporator gets to cold.

Condensor

The air conditioning system condenser is located in front of the engine radiator. The condenser is cooled by air being drawn through from the engine fan. The condenser requires regular cleaning of dust and any debris.

NOTE: Take care not to damage the condenser coils or fins when cleaning the condenser.

Receiver Dryer

The air conditioning receiver dryer is fitted to the right hand chassis rail under the cabin. This component captures any moisture that is circulating in the air condition system. Moisture in the air conditioning system freezes and causes blockages. The component must be replaced any time the air conditioning system is opened or serviced.

Heating System

The heating core is warmed with hot water from the engine. The volume of the water travelling through the system (and therefore the heat supplied) may be adjusted by setting the temperature on the AC head unit. To enable the heating core to be isolated from the engine two taps have been installed. The first tap is located on the right hand side of the engine behind the radiator. The second tap is located at the header tank.

NOTE: If the heating is not working ensure that the isolating taps are on.

Electrical System

Batteries

The electrical system operates on 12 volts. To provide a 12 volt supply with sufficient current, two 12 volt batteries have been used in parallel. This means that like polarity terminals have been joined.

- Before carrying out any repairs to the electrical system turn the battery isolator switch to the 'off' position. The battery isolator is located on the right hand side panel in front of the rinse tank.
- When welding connect the ground terminal directly to the part being welded and ensure that the batteries are disconnected. Disconnect any electronic controls such as the engine controller, transmission controller and the spray controller.
- When welding on the sprayer ensure, If fitted, that all weed seeker controllers are totally removed from the sprayer.

Battery Isolator

The battery isolator switches power flow from the batteries to the sprayer. The switch is a 250 Amp unit. The isolator switch cut all power to the sprayer except for the radio back up power. The isolator switch must be isolated when the sprayer is not in use to prevent battery leakage or power faults. The battery isolator is located on the right hand side panel in front of the rinse tank.


NOTE: The battery isolator is not an Emergency stop. The isolator key should only be removed after more than 30 seconds from stopping the engine, so data can be written and saved to the ECU.



Battery Jumper

If the batteries need jumping, the cables need to be connected directly to the batteries. They are located on the inside chassis rail on the right hand side. When charging the batteries or jump starting another vehicle:

- Switch the engine off.
- Switch off the battery isolator switch.
- Connect the positive jumper lead to the positive battery jumper point.
- Connect the negative jumper lead to the negative battery jumper point.



Electrical Components

The Electrical control panel is located in the side console on the right of the operator's seat. These panels contain fuses and relays to activate the sprayer circuitry. To gain access to the panels the console lining must be removed by releasing the latches on top of the cover and pulling it forwards.

These boxes control various relays, diodes and fuses to operate a number of electrical circuits throughout the sprayer. The layout of the fuse boxes can be seen in the Chapter 4 'Cabin'.

When a fault occurs, the fuses will blow and disconnect the circuit. If a fuse has been blown identify the corresponding device and investigate the cause before reconnecting the new fuse.

The fuses have been placed in the system to protect the system against electrical faults. When a fuse is replaced it is important that the fuse is replaced with another fuse of the same rating.

Maintenance Schedules

See end of this chapter for a list of items that need to be replaced for the first service.

After the first service, replace or inspect the items at the intervals indicated.

Engine

SERVICE ITEM	DAILY (10Hrs)	WEEKLY (50Hrs)	250hrs/ 3 months	500hrs/ 6 months	750hrs/ 9 months	1000hrs/ 1 year
Engine oil level	Inspect	Inspect	Replace	Replace	Replace	Replace
Engine oil filter	Inspect	Inspect	Replace	Replace	Replace	Replace
Fuel filter - engine	Inspect	Inspect	Replace	Replace	Replace	Replace
Fuel filter - (separator filter)	Drain	Drain	Replace	Replace	Replace	Replace
Fuel Filter - (in-line)	Inspect	Inspect	Replace	Replace	Replace	Replace
Fuel level	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect
Antifreeze/Coolant	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect
Fan	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect
Drive belts	Inspect	Inspect	Inspect	Inspect	Inspect	Replace
Cooling system	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect
Mounting bolts and vibromounts	-	Inspect	Inspect	Inspect	Inspect	Inspect
Hoses, lines and clamps	-	Inspect	Inspect	Inspect	Inspect	Inspect
Exhaust system	-	Inspect	Inspect	Inspect	Inspect	Inspect
Air cleaner (Primary filter)	-	Inspect	Inspect	Inspect	Inspect	Replace
Air cleaner (Safety filter)	-	Inspect	-	Inspect	Inspect	Replace
Air intake piping	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect
Crankcase breather tube	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect
Belt tensioner bearing	-	Inspect	Inspect	Inspect	Inspect	Inspect
Belt tension - (450 Nm)	-	Inspect	Inspect	Inspect	Inspect	Inspect
Turbocharger	-	Inspect	Inspect	Inspect	Inspect	Inspect
Air compressor	-	Inspect	Inspect	Inspect	Inspect	Inspect
Harmonic balancer	-	Inspect	Inspect	Inspect	Inspect	Inspect

NOTE: Engine coolant to be replaced at 2000 hours.

NOTE: For more detailed engine maintenance information refer to 'Cummins Operation and Maintenance Manual QSB4.5 and QSB6.7 Engine' supplied with your machine.

Continued over page

Maintenance Schedules

Transmission

SERVICE ITEM	DAILY (10Hrs)	WEEKLY (50Hrs)	250hrs/ 3 months	500hrs/ 6 months	750hrs/ 9 months	1000hrs/ 1 year
Oil	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect
Internal filter	Replace on rebuild					
Lube & Main filter	-	Inspect	Inspect	Replace	Inspect	Replace
Selector linkage	-	Inspect	Inspect	Inspect	Inspect	Inspect
Bolts	-	Inspect	Inspect Tension	Inspect Tension	Inspect Tension	Inspect Tension
Oil lines	-	Inspect	Inspect	Inspect	Inspect	Inspect
Electrical harnesses	-	Inspect	Inspect	Inspect	Inspect	Inspect
Cooling system	-	Inspect	Inspect	Inspect	Inspect	Inspect

NOTE: Transmission oil should be replaced every 6000 hours with TES295 approved oil.

Drive Shafts

SERVICE ITEM	DAILY (10Hrs)	WEEKLY (50Hrs)	250hrs/ 3 months	500hrs/ 6 months	750hrs/ 9 months	1000hrs/ 1 year
Transmission and at Axle Input	-	Inspect	Inspect	Inspect	Inspect	Inspect
Universal Joints	-	Lubricate Inspect	Lubricate Inspect	Lubricate Inspect	Lubricate Inspect	Lubricate Inspect
Slip Splines	-	Lubricate Inspect	Lubricate Inspect	Lubricate Inspect	Lubricate Inspect	Lubricate Inspect

Axles

SERVICE ITEM	DAILY (10Hrs)	WEEKLY (50Hrs)	250hrs/ 3 months	500hrs/ 6 months	750hrs/ 9 months	1000hrs/ 1 year
Differential Oil	-	Inspect	Inspect	Replace	Inspect	Replace
Steering swivel	-	Lubricate Inspect	Lubricate Inspect	Lubricate Inspect	Lubricate Inspect	Inspect Replace
Tie rod ends & ball joints	-	Lubricate Inspect	Lubricate Inspect	Lubricate Inspect	Lubricate Inspect	Lubricate Inspect
Front axle universal joints	-	Lubricate Inspect	Lubricate Inspect	Lubricate Inspect	Lubricate Inspect	Lubricate Inspect
Front planetary hubs - oil level	-	Inspect	Inspect	Replace	Inspect	Replace
Breather	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect
Toe In (1-5mm)	-	-	Measure	Measure	Measure	Measure

Continued over page

Maintenance Schedules

Transfer Gearbox

SERVICE ITEM	DAILY (10Hrs)	WEEKLY (50Hrs)	250hrs/ 3 months	500hrs/ 6 months	750hrs/ 9 months	1000hrs/ 1 year
Oil level	Inspect	Replace	Inspect	Replace	Inspect	Replace
Input output seals	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect
Breather	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect

Hydraulic System

SERVICE ITEM	DAILY (10Hrs)	WEEKLY (50Hrs)	250hrs/ 3 months	500hrs/ 6 months	750hrs/ 9 months	1000hrs/ 1 year
Hydraulic oil	-	Inspect	Sample	Sample	Sample	Replace
Hydraulic oil return filter	-	Inspect	Inspect	Replace	Inspect	Replace
Hydraulic lines and hoses	-	Inspect	Inspect	Inspect	Inspect	Inspect
Hydraulic cylinders	-	Inspect	Inspect	Inspect	Inspect	Inspect
Hydraulic pumps	-	Inspect	Inspect	Inspect	Inspect	Inspect
Hydraulic pump mountings	-	Inspect	Inspect	Inspect	Inspect	Inspect
Hydraulic valves	-	Inspect	Inspect	Inspect	Inspect	Inspect
Hydraulic relief pressures	-	Inspect	Inspect	Inspect	Inspect	Inspect

Pneumatic System

SERVICE ITEM	DAILY (10Hrs)	WEEKLY (50Hrs)	250hrs/ 3 months	500hrs/ 6 months	750hrs/ 9 months	1000hrs/ 1 year
Air tanks	Drain	Drain	Drain	Drain	Drain	Drain
Air lines and fittings	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect

Braking System

SERVICE ITEM	DAILY (10Hrs)	WEEKLY (50Hrs)	250hrs/ 3 months	500hrs/ 6 months	750hrs/ 9 months	1000hrs/ 1 year
Foot brake housing	-	Inspect	Inspect	Inspect	Inspect	Inspect
Hydraulic brake lines/hoses	-	Inspect	Inspect	Inspect	Inspect	Inspect
Seals	-	Inspect	Inspect	Inspect	Inspect	Inspect
Brake operation	Inspect	Inspect	Test & Inspect	Test & Inspect	Test & Inspect	Test & Inspect
Parking brake	-	Inspect	Inspect	Inspect	Inspect	Inspect
Parking brake operation	Inspect	Inspect	Test & Adjust	Test & Adjust	Test & Adjust	Test & Adjust
Parking brake switch	-	Inspect	Inspect	Inspect	Inspect	Inspect

Continued over page

Maintenance Schedules

Suspension System

SERVICE ITEM	DAILY (10Hrs)	WEEKLY (50Hrs)	250hrs/ 3 months	500hrs/ 6 months	750hrs/ 9 months	1000hrs/ 1 year
Polyurethane bushes	-	Inspect	Inspect	Inspect	Inspect	Inspect
Bolts and nuts *	-	Inspect	Tension	Tension	Tension	Tension
Shock absorbers	-	Inspect	Inspect	Inspect	Inspect	Inspect
Ride height valve	-	Inspect	Inspect	Inspect	Inspect	Inspect
Sway Bar Bushes	-	Inspect	Inspect	Inspect	Inspect	Inspect
Torque Rod - Welds	-	Inspect	Inspect	Inspect	Inspect	Inspect

NOTE: Polyurethane bushes, Shock absorbers, Sway bar bushes need to be replaced at 2000 hours.

***NOTE:** Parallel link bolts are to be torqued to 350 ft/lb.

Wheels & Tyres

SERVICE ITEM	DAILY (10Hrs)	WEEKLY (50Hrs)	250hrs/ 3 months	500hrs/ 6 months	750hrs/ 9 months	1000hrs/ 1 year
Rims	-	-	Inspect	Inspect	Inspect	Inspect
Wheel nuts - 350 ft/lb	Tension	Tension	Tension	Tension	Tension	Tension
Tyre pressure	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect
Tyres	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect

Air-conditioning System

SERVICE ITEM	DAILY (10Hrs)	WEEKLY (50Hrs)	250hrs/ 3 months	500hrs/ 6 months	750hrs/ 9 months	1000hrs/ 1 year
Condensor	Clean	Inspect	Inspect	Inspect	Inspect	Inspect
Air conditioner lines	-	-	Inspect	Inspect	Inspect	Inspect
Refrigerant and dryer	-	-	Inspect	Inspect	Inspect	Replace
HVAC box	-	-	Inspect	Inspect	Inspect	Inspect
Carbon filter	-	Inspect	Inspect	Replace	Inspect	Replace
Carbon filter inlet	-	Inspect	Inspect	Inspect	Inspect	Inspect
Compressor drive belt	-	Inspect	Inspect	Adjust	Adjust	Adjust

Continued over page

Maintenance Schedules

Chassis

SERVICE ITEM	DAILY (10Hrs)	WEEKLY (50Hrs)	250hrs/ 3 months	500hrs/ 6 months	750hrs/ 9 months	1000hrs/ 1 year
Ladder switch	-	-	Inspect	Inspect	Inspect	Inspect
Ladder folding mechanism	-	Lubricate	Lubricate	Lubricate	Lubricate	Lubricate
Ladder mounting bolts	-	Tighten	Tighten	Tighten	Tighten	Tighten
Pump mounting bolts	Tighten	Tighten	Tighten	Tighten	Tighten	Tighten
Cab mount bolts and bushes	Tighten	Tighten Inspect	Tighten Inspect	Tighten Inspect	Tighten Inspect	Tighten Inspect
Cabin seals	-	-	Inspect	Inspect	Inspect	Inspect
Cabin interior	Clean	Clean	Clean	Clean	Clean	Clean
Tank retaining strap bolts	Tighten	Tighten	Tighten	Tighten	Tighten	Tighten
Para lift link bushes	Lubricate	Lubricate	Lubricate	Lubricate	Lubricate	Replace
Tank frame mount bolts	-	Tighten	Tighten	Tighten	Tighten	Tighten
Chassis frame	-	-	Inspect	Inspect	Inspect	Inspect
Induction hopper mounting	-	Lubricate	Lubricate	Lubricate	Lubricate	Lubricate
Boom support mounting bolts	-	Tighten	Tighten	Tighten	Tighten	Tighten
Machine exterior	-	Clean	Clean	Clean	Clean	Clean
Windscreen wiper fluid	-	Inspect	Inspect	Inspect	Inspect	Inspect

Electrical System

SERVICE ITEM	DAILY (10Hrs)	WEEKLY (50Hrs)	250hrs/ 3 months	500hrs/ 6 months	750hrs/ 9 months	1000hrs/ 1 year
Battery electrolyte level	-	Inspect	Inspect	Inspect	Inspect	Inspect
Lights	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect
Leads and wires	-	-	Inspect	Inspect	Inspect	Inspect
Earth leads	-	-	Inspect	Inspect	Inspect	Inspect
Wires near moving parts	-	-	Inspect	Inspect	Inspect	Inspect
Boom limit switch	Inspect Adjust	Inspect Adjust	Inspect Adjust	Inspect Adjust	Inspect Adjust	Inspect Adjust
Neutral start switch	-	-	Inspect	Inspect	Inspect	Inspect
Battery terminal	-	-	Clean & Protect	Clean & Protect	Clean & Protect	Clean & Protect

Continued over page

Maintenance Schedules

Spraying Equipment

SERVICE ITEM	DAILY (10Hrs)	WEEKLY (50Hrs)	250hrs/ 3 months	500hrs/ 6 months	750hrs/ 9 months	1000hrs/ 1 year
Sprayer boom	Inspect	Adjust Inspect	Adjust Inspect	Adjust Inspect	Adjust Inspect	Adjust Inspect
Nuts and bolts	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect
Hinge bushes	Lubricate	Lubricate	Lubricate	Lubricate	Lubricate	Lubricate
Tilt bushes	Lubricate	Lubricate	Lubricate	Lubricate	Lubricate	Lubricate
Sprayer calibration	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect
Filters (suction filter; pressure filter; flush filter; compressor air filter)	Inspect	Inspect	Inspect or replace	Inspect or replace	Inspect or replace	Inspect or replace
Nozzles	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect
Pump (pre-spray test)	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect
Pump oil condition and level	Inspect	Inspect	Replace	Replace	Replace	Replace
Pump diaphragms	-	-	-	Replace	-	Replace
Pump seals	-	-	-	Replace	-	Replace
Pump valve O-rings	-	-	-	Replace	-	Replace
Pump valve springs and cages	-	-	-	Replace	-	Replace
Hoses and fittings	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect
Boom secure in boom rests	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect
Sprayer pump and lines	Flush	Flush	Flush	Flush	Flush	Flush
Spray tanks empty	Inspect	Inspect	Inspect	Inspect	Inspect	Inspect
Flow meter	Inspect Drain	Inspect Drain	Inspect Drain	Inspect Drain	Inspect Drain	Inspect Drain
Ball valves	Open & inspect	Open & inspect	Open & inspect	Open & inspect	Open & inspect	Open & inspect

Continued over page

First Service - 50 Hours

ENGINE

SERVICE ITEM	TYPE OF SERVICE	PART NO. - GOLDACRES	PART NO. - GENERIC
Engine oil	Drain & Replace	GA5017913 (200L)	-
Engine oil filter	Replace	GA5051755	LF3970
Fuel filter - Engine	Replace	GA5051765	FF5612, FF5421
Fuel filter - Primary	Replace	GA5051760	FS1242
Fuel filter - In-line	Replace	GA5069895	WZ153 (3/8" tails)

TRANSMISSION & TRANSFER CASE

SERVICE ITEM	TYPE OF SERVICE	PART NO. - GOLDACRES	PART NO. - GENERIC
Transmission oil	Inspect	GA5006959 (20L)	-
		GA5006960 (208L)	-
Lube & Main filter	Inspect	GA3500140	29548988
Transfer case oil	Drain & Replace	GA5072325	-

REAR AXLE

SERVICE ITEM	TYPE OF SERVICE	PART NO. - GOLDACRES	PART NO. - GENERIC
Differential Oil	Drain and Replace	GA5047310 (200L)	-
Planetary Hub Oil	Drain and Replace	GA5047310 (200L)	-

FRONT AXLE

SERVICE ITEM	TYPE OF SERVICE	PART NO. - GOLDACRES	PART NO. - GENERIC
Differential Oil	Drain and Replace	GA5047310 (200L)	-
Planetary Hub Oil	Drain and Replace	GA5047310 (200L)	-
Toe In (1-5 mm)	Measure	-	-

HYDRAULIC OIL TANK

SERVICE ITEM	TYPE OF SERVICE	PART NO. - GOLDACRES	PART NO. - GENERIC
Hydraulic oil return filter	Replace	GA5069056	-
Hydraulic oil	-	GA5017199	-

AIR-CONDITIONING

SERVICE ITEM	TYPE OF SERVICE	PART NO. - GOLDACRES	PART NO. - GENERIC
Compressor drive belt	Check and re-tension	GA5071435	-

Chapter 11

TROUBLESHOOTING

The following troubleshooting information is provided as a reference when your sprayer is not functioning correctly.

To ensure that you receive the best possible service, it is recommended that you exhaust all applicable

troubleshooting solutions shown in this chapter prior to calling your dealer, or Goldacres, for service advice

Parts information and schematics can be found in the parts manual supplied.

Spray Pump

PROBLEM	COMMON CAUSES	COMMON SOLUTION
Pressure and flow rate are too low	Pump	Check suction line for air leaks.
		Suction filter may be blocked.
		Check pump speed. 400 - 540 RPM
		Check oil for colour change. If the oil appears milky, a diaphragm will be damaged and needs to be replaced.
		Check valves in pump.
		Turn the pressure station ball valve to off, if the pressure increases on the pump gauge there is a problem with the control valve.
		Measure the flow per minute coming out of one nozzle and check the nozzle chart for the corresponding flow.
		Check the regulator valve is rotating the full 90 degrees when the boom valves are switched off.
		Check tank sump and suction line blockages.
	Excessive bypass on pressure manifold	Verify console calibration settings.
	Supply to pump is restricted	Check the pressure relief valve setting on pressure manifold.
Pressure and flow rate are too high	Bypass line is restricted or blocked..	Verify console calibration settings. Check for restriction in bypass line. Check pump speed is not too fast. Check if Bypass valve is turned on
The pressure on my gauge is higher than the nozzle flow indicates	Blocked filters of nozzles	Check and clean all pressure and nozzle filters
	Flow loss due to resistance in lines, valves and filters.	Re-calibrate console to allow for pressure loss

Continued over page

Spray Pump

PROBLEM	COMMON CAUSES	COMMON SOLUTION
The flow rate is correct but my pressure is too low or high.	Nozzles	Check nozzle chart for correct nozzle size.
Pressure fluctuation	Air leak on suction side of pump	Check suction pump for air leaks.
	Incorrect pump speed	Adjust pump speed so it is between 400 - 540 rpm
	Faulty pump valves	Replace pump valves
Pump pressure pulsating	Air accumulator pressure is incorrect (if fitted)	Reset the pressure in air accumulator
	Air accumulator diaphragm has a leak (if fitted)	Replace air accumulator diaphragm
	Incorrect pump speed	Adjust pump speed so it is between 400 - 540 rpm
	Air leak on suction side of pump	Check pump suction for air leaks
Pump oil is becoming milky	Cracked diaphragm	Replace all diaphragms
Pump is noisy	Low oil level	Refill or replace oil
	Damaged pump valves	Replace pump valves
	Pump suction line has air leak or is restricted	Clean suction filter and check for leaks in suction lines
Pump housing or mounting cracked.	Extremely cold weather can cause liquid in the pump to freeze	Check for ice in the pump and let defrost if required

Flow Meter & Controller

PROBLEM	COMMON CAUSES	COMMON SOLUTION
Application rate is inaccurate, unstable or zero	Incorrect console calibration	Re-calibrate console
	Inconsistent ground speed reading	Check cabling
	Inconsistent flow meter reading	Replace flow meter
	Faulty control valve	Replace control valve Check using manual increase/decrease flow control
Speed sensor display is inaccurate, unstable or zero	Incorrect speed calibration	Re-calibrate console speed
	Faulty cable	Test cable as per instructions following
Volume display is inaccurate, unstable, zero or not changing	Meter calibration is incorrect	Reset meter calibration
	Flow meter cable pins are corroded	Replace flow meter plugs & pins
	Flow meter is pointing the wrong way	Disconnect flow meter and reinstall in the correct orientation
	Faulty cable	Manually test the cable
Flow meter appears not to be working	Flow meter is seized or blocked	Remove and clean any foreign materials so the turbine spins freely
	Faulty cable	Test cable as per instructions following
	Calibration figure is incorrect	Reset meter calibration
Application rate or pressure will not alter	Faulty control valve	Test valve manually and replace if required
Control valve has failed	Faulty cable Faulty valve	Replace control valve
		Temporary solutions: Remove the motor from the 3 way ball valve and manually adjust the flow by turning the shaft with a spanner
Raven Console not working	No power supply	Check loom connection at the back of the console
		Check connection to battery terminals
		Check the fuse in the back of the console
		With a multi meter; check the voltage potential across pins 1(-) and 16(+) on the 16 pin plug going into the console (Should be at least 12v)

If the flow meter fails to give accurate readings, the following actions should be taken:

- Adjust the spraying pressure by putting the flow control switch into manual and using the increase decrease switch to adjust to the desired pressure as shown on the pressure gauge on the sprayer.
- Drive the sprayer at a constant speed in order to apply the required application volume as determined by the nozzle selection chart.
- The sprayer should then be operated to empty the tank. Once the sprayer is empty of chemical, partially fill the tank with fresh water so that test can be performed in order to correct the problem. Repair or replace the flow meter as soon as possible.

Flow Meter & Controller

Use the following procedures to manually override the boom valves and control valve if the Raven console has failed or is otherwise not able to operate them:

RAPIDFIRE AIR VALVE OVERRIDE

1. Disconnect console from console cable.
2. The air valves located on the centre section. Turn the small screw on the solenoid to turn them on.
3. To start and stop spraying through the nozzles, start and stop the pump.

For more information on overriding the rapid fire solenoids, see 'Rapid Fire' section in Chapter 8 'Operation'.

NOTE: Care should be taken because there is no agitation while the nozzles are not spraying.


CONTROL VALVE OVERRIDE

- Remove electric motor from three way fast close valve, and manually rotate valve until desired spraying pressure is achieved.
- Drive the sprayer at a constant speed in order to apply the required application volume as determined by the nozzle selection chart.

The sprayer should then be able to be operated in order to empty the tank. Once the sprayer is empty of chemical, partially fill the tank with fresh water (no chemical) so that testing can be performed in order to correct the problem. Repair or replace the console as soon as possible.

Testing Raven Flow Meter Cable

1. Change meter Cal number to 1 with the [Meter Cal] key.
2. Press [total volume] key and place boom switches ON.
3. With a jumper wire e.g. paper clip, short between 6 o'clock and 2 o'clock sockets with a "short" then "no short" motion. Each time contact is made the [total volume] should move up in increments of 1 or more.
4. If total volume does not count up, perform test at the next connector closer to the console. If this next test works, the previous section of cable must be faulty and should be replaced.
5. Perform the voltage checks shown below.
6. Change [Meter Cal] number back to previous number.



Voltage Readings

2 o'clock - 6 o'clock (+5V DC)

10 o'clock - 2 o'clock (+5V DC)

Chemical Probe

PROBLEM	COMMON CAUSES	COMMON SOLUTION
Chem probe is not working or is working too slow	Air leak in the vacuum system	Check all hose clamps and fittings are tight
	Lack of pressure to venturi in top of tank	Check there are no kinked hoses and the water pressure is about 100 PSI

ISOLATING POSSIBLE AIR LEAKS

Step 1: Check the operation of the chemical probe. If this will transfer water at a minimum of 30 L/min then this part of the system is okay.

If not check for air leaks at:

- Cam lever fitting at the probe
- Hose fittings
- Venturi – the venturi can suck air (less vacuum) where the black drop-pipe connects to the orange venturi
- The venturi may also suck air where the 'lay flat' hose joins the bottom of the black PVC drop pipe

Step 2: If probe works correctly but envirodrum will not operate, check for air leaks in envirodrum fitting (this must be thoroughly cleaned after each use) and check interior pipes in the envirodrum for air leaks or damage.

In Summary:

First: Check the flow of water into venturi.

Then:

1. Check the probe only.
2. Check probe and envirodrum section.

NOTE: Tests must be done with water because the speed of the transfer is affected by the increased viscosity of the chemical.

Spray Nozzles

PROBLEM	COMMON CAUSES	COMMON SOLUTION
Streaky pattern coming from nozzle	Nozzle tip blockages.	Check for blockages by removing the nozzle, rinsing thoroughly with water and cleaning with compressed air. DO NOT clean by blowing into nozzle with mouth.
	Nozzle worn or damaged.	Visually inspect nozzle for damage or wear; conduct a jug test if necessary.
No spray coming from nozzle	Nozzle tip blockages.	Check for blockages by removing the nozzle, rinsing thoroughly with water and cleaning with compressed air.
	Check valve blockages.	Remove the check valve and clean as required.

TriTech Boom

PROBLEM	COMMON CAUSES	COMMON SOLUTION
Inner and outer wing are not in line with each other when the boom is unfolded	Stopper bolt holding out the boom	Adjust the boom stopper bolt
Booms will not fully fold to the boom rests	Insufficient lubrication	Lubricate all boom pivots
	Fold cylinder mounts have moved	Adjust fold cylinder mounts
Boom unfold unevenly	Air trapped in the hydraulic lines	Unfold booms completely and hold switch for a few seconds. Then, fold booms completely and hold switch for a few seconds. Do this multiple times as necessary to purge any air out of the hydraulic lines.
Outer boom does not line up with the inner wing when unfolded	Incorrect boom adjustment	Fold the boom out and note the position the outer boom is in. Fold the boom in to transport position and note position outer boom is in. Follow the table below to adjust boom so it sits level in the out (work) position and to have the bottom chords sitting parallel in the folded (transport) position
Booms are showing signs of bending components and welds cracking	Folding or unfolding of booms is too fast	Reduce the hydraulic flow to the folding cylinders
	Folding or unfolding of booms while the sprayer is still moving	Do not fold or unfold the boom while the sprayer is still moving
	Tilt operation	Tilt operation should be kept to a minimum. If the tilt operation is too fast, reduce the oil flow

NOTE: By nature, booms fitted with flow dividers don't fold 100% evenly. Hold the boom fold switch for a few seconds after the first boom has folded completely to give the other boom the chance to match the fully folded position.

SHIM ADJUSTMENT

The shim adjustment at the cable drum will affect the position of the outer boom when unfolded and when in the folded position. Use the table below to add or remove shims. The table shows the position of the boom and the adjustment necessary to get them level.

OUTER WING POSITION (OUT)	OUTER WING POSITION (FOLDED)	TOP PIVOT SHIM ADJUSTMENT	BOTTOM PIVOT SHIM ADJUSTMENT
Up	Up	NIL	Remove Shims
Up	Down	Add Shims	NIL
Level	Up	Remove Shims	Remove Shims
Down	Down	NIL	Add Shims
Down	Up	Remove Shims	NIL
Level	Down	Add Shims	Add

Plumbing

PROBLEM	COMMON CAUSES	COMMON SOLUTION
No water at boom	No Tier value entered or is at 0	Enter value greater than 0

Induction Hopper

PROBLEM	COMMON CAUSES	COMMON SOLUTION
Induction hopper is not performing as well as it should	Insufficient flow to venturi in the hopper bottom	Check the pressure supplied to the hopper bottom is around 550 kPa (80 PSI).
	Air leaks on induction system	Check all hoses, clamps, and cam lever fittings are sealed

Brakes

PROBLEM	COMMON CAUSES	COMMON SOLUTION
Brakes are not responding	Leak in brake lines	Inspect all hydraulic lines & repair if necessary
Sprayer is stopping inconsistently	Low hydraulic pressure	Check the level of main hydraulic tank
		Check main hydraulic pressure to ensure there is enough flow
Brakes are squealing	High oil heat in differential	Cool the differential
Park brake not holding	Brake disc wear	Adjust park brake as per 'lubrication & Maintenance' chapter
	Pressure in brake line	Inspect switch and ensure that the hydraulic spool is operating correctly

Hydraulic & Pneumatic

PROBLEM	COMMON CAUSES	COMMON SOLUTION
No hydraulic pressure	Low hydraulic oil level	Check the oil level in the hydraulic reservoir and top up if necessary
	Fill pump is engaged	Switch the hydraulic fill pump off
	Load Sense	Check hydraulic fittings and ensure flow through the system
		Check that standby pressure is at least 15bar
The air bags are not inflating	Low system pressure	The bags will not inflate until the pressure in the system is above 75 PSI, check system pressure
	Compressor not working properly	Check that the compressor is working correctly
Vehicle sits unevenly	Incorrectly adjusted ride height valves	Adjust the ride height valves as per the instructions in the Lubrication and Maintenance chapter

Air Conditioning

PROBLEM	COMMON CAUSES	COMMON SOLUTION
Air conditioning not cooling effectively	Condenser Blocked	Check the condenser for a build up of dirt and plant matter; clean if required.
	Compressor belt loose	Inspect the belt to see if it is tensioned correctly. If belt is showing signs of wear; replace.
	A/C system needs re-gassing	If this is the case, only allow a qualified air conditioning technician to work on the system. R134a refrigerant must not be allowed to escape to the atmosphere.
	Evaporator blocked	Build up of dirt and plant matter; clean if required. Be careful not to damage any of the components.

Chapter 12

OPTIONAL ACCESSORIES

General Information

The following pages provide information on Goldacres optional accessories available on this equipment.

NOTE: These options may not be fitted to your equipment unless ordered.

Chemical Induction Probe

Overview


A simple method of transferring chemical into the sprayer tank is via the chemical probe. The chemical probe enables the chemicals to be transferred with minimal exposure to the operator. The probe is used in conjunction with the Venturi filler (located on the top of the tank) which creates the required suction on the pressure side of the pump.

The viscosity of the chemical being transferred will affect the rate of suction flow and hence the amount of time required to transfer the chemical. Water and air have low viscosities whereas molasses is an example of a highly viscous liquid. The higher the viscosity of the liquid, the longer it takes to transfer

via the chemical probe. If the viscosity of a chemical is such that it takes too long to transfer, dilute the chemical with water, which will reduce the viscosity, and then transfer the solution.

The chemical should be transferred after about 20-50 % of the required water quantity has been added to the sprayer tank. This will ensure that agitation takes place when the remaining water is added.

The end of the probe is not flat so that the probe, when placed flat against the bottom of the container, will not restrict the flow of chemical.



Continued over page

Chemical Induction Probe

Operation

WARNING: It is critical that the chemical probe venturi continues to operate for a minimum of 30 seconds following use. This will ensure that no chemical is left in the line prior to the probe being disconnected.

NOTE: This item is intended for the induction of liquid chemicals only.

11. When finished, rotate the valve to Bypass/Spray mode, keep the agitator valve 'OPEN' and disconnect the probe. Once chemical has been transferred into the main spray tank the sprayer should always be agitating until spraying begins.

CHEMICAL PROBE OPERATION:

1. Add 20 percent of the tank's volume of clean water to the main spray tank. Initially there needs to be a sufficient amount of water in the tank in order for the pump delivery to create the venturi effect via the venturi filler.
2. Ensure that the red handle on the pump 3-way valve is pointing towards the suction hose coming from the main tank sump.
3. Connect probe via cam lever fitting. Close all ball valves and set pressure to 110 PSI.
4. 'OPEN' the venturi and agitator valves.
5. Rotate the valve handle to venturi probe.
6. Operate the pump at the speed necessary to generate at least 100 PSI delivery pressure. Do not run the pump faster than 500 RPM. The higher the pump delivery pressure, the greater the venturi suction and the quicker the probe will transfer the chemical. The delivery pressure should not exceed 120 PSI as determined by the pressure relief valve setting.
7. Place probe in chemical.
8. 'OPEN' the valve on the probe.
9. The chemical should be now transferring to the sprayer tank via the venturi filler.
10. When all of the chemical has been transferred, rinse the chemical container with water and transfer the rinsate to the sprayer tank via the probe. This should ensure that the entire chemical is transferred and that the probe, venturi filler and connecting suction hose are cleaned. Induct clean water to rinse probe vacuum hose.

Chemical Transfer Pump

Overview

The Transfer Pump is used to transfer chemical to the main tank, in place of the venturi chemical probe. Combined with an FM-I 100 flow meter, its an accurate way of measuring chemical being transferred into the main tank.

Pump Specifications:

- Flow rate - Up to 45 L/min
- Head - To 3.0 m
- Pressure - To 1.0 bar

NOTE: Sotera stainless steel rotary vane pumps are designed for maximum practical corrosion protection with a wide range of thin liquids. . However, ensure chemical compatibility between liquids pumped and the pumps wetted parts before using.

NOTE: Do not use the pump to transfer flammable petroleum products.


Operation

CAUTION: Exposure to chemical can cause serious injuries, always wear proper protective clothing and devices when transferring chemical. Refer to and follow chemical manufacturers instructions.

1. Connect chemical probe to cam lock fitting on sprayer.
2. Put other end of probe into the chemical to be transferred.
3. Turn Chemical Induction handle to PUMP.
4. Turn on pump and open valve on chemical probe and valve behind cam lock fitting.
5. Transfer desired amount of chemical. Pull probe out of chemical and let the pump run until all chemical has been sucked from lines.
6. When all of the chemical has been transferred, rinse the chemical container with water and transfer the rinsate to the sprayer tank via the probe. This should ensure that the entire chemical is transferred and that the probe, pump and connecting suction hose are cleaned. Induct clean water to rinse probe vacuum hose.

7. Turn pump off, close both valves and disconnect chemical probe.

NOTE: Do not use the pump with fluids that have a flash point lower than 37 degrees C (100 degrees F).



Above: Sotera chemical transfer pump (GA5072100).

Flow Meter - FM-1100



The FM-1100 Flow Meter is a positive displacement fluid metering unit.

- Accuracy: $\pm 0.5\%$
- Flow Range: 9-136 L/min
- Maximum Pressure: 410 kPa (60 PSI)
- Maximum Total: 9999
- Auto Shut Off: 3 minute
- Auto Wake Up: With Flow

Operation

CAUTION: Exposure to chemical can cause serious injuries, always wear proper protective clothing and devices when transferring chemical. Refer to and follow chemical manufacturers instructions.


The FM-1100 flow meter will start working automatically when flow is detected.

The LCD display will show the following:

- LOW - Low battery indicator
- CUR - Current Total indicator
- CUM - Cumulative total indicator
- GAL - Gallons indicator
- LTR - Litre indicator
- CNT - counts indicator
- CAL - Calibration indicator

The meter displays and stores:

- A resettable CURRENT TOTAL (CUR)
- A non-resettable CUMULATIVE TOTAL (CUM)
- A COUNTS calibration value (CNT)



The FM-1100 Series Flow Meter has three push buttons:
1 MODE or "ON" button 2 INCREASE (up arrow) button 3 DECREASE (down arrow) or "ZERO" button



MODE/
ON



INCREASE



DECREASE/
ZERO

Continued over page

Flow Meter - FM-1100

The MODE button performs the following functions:

1. If the display is off, press MODE button to display current total (CUR).
2. Use MODE button to cycle between CURRENT TOTAL (CUR) and CUMULATIVE TOTAL (CUM).

NOTE: After approximately 30 seconds, display will automatically switch from CUMULATIVE TOTAL (CUM) back to CURRENT TOTAL (CUR).

3. Press and hold MODE button for 3–5 seconds to show Volume Unit Selection. Press INCREASE or DECREASE buttons to cycle through volume units. When desired units are flashing, press MODE button to save selection and return to CURRENT TOTAL (CUR).

Volume Unit Selection choices are: GALLONS (GAL), LITERS (LTR), or COUNTS (CNT).

NOTE: To reset CURRENT TOTAL (CUR) to Zero, press and hold DECREASE button for 2 seconds or more while CURRENT TOTAL (CUR) is displayed.

NOTE: Meter will not enter Volume Unit Selection mode if pump is running.

NOTE: CUMULATIVE TOTAL CANNOT BE RESET - EVEN BY REMOVING THE BATTERY.

- The flow meter display will turn on whenever flow is detected.
- The flow meter and display will turn off after a 3-minute period of button or flow inactivity. Any unsaved changes will not be saved.

Calibration

- Calibration procedures are the same for both the 90° and in-line meters.
- To ensure accuracy, purge all air from pump/meter system before calibrating.

To CALIBRATE (CAL) meter:

1. Press MODE button to turn meter on.
2. Press and hold MODE button for 3–5 seconds to show Volume Unit Selection. Press INCREASE or DECREASE buttons to select desired Volume Units.

3. Press and hold MODE button again for 3–5 seconds to enter Calibration Mode (CAL).
4. CAL and chosen Volume Unit (GAL or LTR) will blink together. Numeric Display will show default values as listed below.

FLASHING INDICATORS	NUMERIC DISPLAY
Calibrate Litres (LTR)	20.00
Calibrate Gallons (GAL)	5.00
Calibrate Counts (CNT)	XXXX

NOTE: XXXX represents the present COUNTS (CNT) value stored in flow meter's memory. To Calibrate using COUNTS (CNT), see next section.

NOTE: To use a calibrated container with a volume other than the default values, press INCREASE or DECREASE buttons to change value shown on Numeric Display.

5. To complete CALIBRATION for GALLONS (GAL) or LITERS (LTR), pump the exact amount shown on Numeric Display.

6. Press MODE button for 3–5 seconds to SAVE the CALIBRATION. Display will show CAL if CALIBRATION was successful.

NOTE: If MODE button is pressed for less than 3 seconds, CALIBRATION will be aborted and display will show Err (Error) to indicate the CALIBRATION was not successful. Display will return to CURRENT TOTAL (CUR) without making any changes.

To CALIBRATE (CAL) meter using COUNTS (CNT) value:

NOTE: No pumping is required to complete CALIBRATION (CAL) for COUNTS (CNT).

1. Press MODE button to turn meter on.
2. Press and hold MODE button for 3–5 seconds to show Volume Unit Selection. Press INCREASE or DECREASE buttons to select COUNTS (CNT).
3. Press and hold MODE button again for 3–5 seconds to enter Calibration Mode (CAL).

Continued over page

Flow Meter - FM-I 100


4. CALIBRATE (CAL) and COUNTS (CNT) indicators will both blink together; Numeric Display will also show a value (XXXX), which represents the present value stored in flow meter's memory.
5. Press INCREASE or DECREASE buttons to change the value shown in Numeric Display to desired value.
6. To complete CALIBRATION for COUNTS (CNT), press MODE button for 3–5 seconds. CALIBRATE (CAL) and COUNTS (CNT) indicators will turn off and display will show CAL if CALIBRATION was successful.

NOTE: If MODE button is pressed for less than 3 seconds, CALIBRATION will be aborted and display will show Err (Error) to indicate the CALIBRATION was not successful. Display will return to CURRENT TOTAL (CUR) without making any changes.

To Display Software Revision Number

1. Press MODE button to turn meter on.
2. Press MODE button again to display CUMULATIVE TOTAL (CUM).
3. While display is showing CUMULATIVE TOTAL (CUM), press and hold DECREASE button to display flow meter's software revision number (e.g. r1.00).



NOTE: CUMULATIVE TOTAL CANNOT BE RESET - EVEN BY REMOVING THE BATTERIES.



Flow Meter & Pump - Troubleshooting

PROBLEM	COMMON SOLUTIONS
Meter display will not turn on:	Check for dead battery.
	Check electronics chamber for moisture.
	Check O-ring seal for damage.
	Check to see that PCB assembly is properly seated.
	Check to see that battery is properly seated / no corrosion.
	Check for damaged magnetic switch/PCB.
Meter shows no flow: (pump runs)	Check low battery indicator.
	Check for damaged magnetic switch/PCB.
	Check magnetic wheel assembly.
	Check nutating chamber for debris.
	Check to see if outlet tube is severely restricted (kinked).
	Check for missing magnet wheel assembly.
Flow low/high/inconsistent:	Check to see if out of product.
	Check for air in system.
	Check for calibration error (Err).
	Check for particulates in fluid.
Meter leaks:	Check for damaged nutating chamber.
	Check for damaged O-ring.
	Check for loose screws.
	Check inlet/outlet fittings for proper seal.
Noisy / rough operation:	Check meter housing for cracks.
	Check nutating chamber for debris.
	Check for loose magnetic wheel assembly.

Hydraulic Fill Pump



Suction & Delivery Lines

- Use good quality suction hose and fittings that will not collapse or leak air under suction
- If pumping water from structures other than storage tanks, we recommend the use of an appropriate sized floating filter equipped with a check valve
- It is essential the suction line to the pump is the same size as the suction port (3") to achieve maximum pump output

A smaller size delivery line can be used but will reduce pump output.

3" Fill Pump - Operation

1. Connect the 3" fill hose (not supplied) to quick fill cam lock coupling under the EZ Control POD.
2. Turn the 'Main Tank Fill' ball valve ON

NOTE: Do not turn the tank fill ball valve off while the pump is running.




3. With the engine running at low idle, turn the 'Fill Pump' switch ON.

NOTE: Do not turn the fill pump switch ON or OFF with the engine above low idle.

4. Once the pump is running, turn the 'RPM Raise' switch ON.
5. When the tank has been filled to the desired level, turn the 'RPM Raise' switch to OFF.
6. When the engine has returned to low idle, turn the 'Fill Pump' switch OFF. Close the 'Main Tank Fill' ball valve and remove the water supply from the tank fill fitting.

Setting Hydraulic Fill Pump RPM

The 3" fill pump speed can be altered by adjusting the screw and lock on the rear of the hydraulic motor. The hydraulic system has been sized so that the fill pump can not be over revved, so the speed control should be wound all the way out.



Fill Flow Meter - 70 Series

Key Features

The Tee Jet monitor and flow meter system can be set up to measure the amount of flow entering the main spray system or it can be set up with a supplementary electronic ball valve that will shut off when a pre determined volume is reached preventing over filling of the sprayer.

When the flow meter system is connected without the ball valve the flow meter is not required to be turned on to fill the tank. However when the electronic ball valve is part of the system the console must be powered on and the target volume must be set to open the ball valve and allow liquid to flow through and fill the tank. If this is not done the ball valve will remain closed, blocking flow to the main tank and dead heading the fill pump.

The console can be programmed to reset to the maximum tank volume every time the filling process is activated. If a lesser amount is required then the maximum volume can be reduced to the required amount. When this amount is reached an alarm will sound. If the system has a ball valve, the valve will shut off stopping flow to the main tank. If the valve is not fitted the [CLR] button can be pressed to silence the alarm.

Operation

Button Functions



Start Up Screen



Continued over page

Fill Flow Meter - 70 Series

Operating Screen




Console Programming

1. Press 'PRO' to turn display screen on. (once turned on, numbers shown on screen may vary to those shown below)



2. The flow meter calibration number must be entered. This number is located on the flow meter ID label.



Continued over page

Fill Flow Meter - 70 Series

3. To do this, press 'PRO' and hold down for 3 seconds. Using the up and down arrows adjust the number so that it matches the flow meter calibration figure (pulses/liter).



4. Press the 'PRO' button once the correct calibration number has been entered. This will take you to the next screen but will also set the calibration figure that was just entered. (To save the flow meter cal figure, the 'Pro' button must be pressed once. Don't press and hold the 'PRO' button to exit from this screen or changes won't be saved. See step 6 for exiting calibration.)
5. When in this screen, the maximum target volume is set. This is used as a quick reset to the tank's maximum volume. Use the up and down arrows to set the required maximum tank volume.



6. Once all calibrations have been entered, press and hold 'PRO' for 3 seconds to go back to the fill screen. (shown below, numbers shown here may vary to what is displayed on your screen)
7. To set the target volume, press 'PRO' once so the target value flashes. Use the arrows to adjust the value. Press 'PRO' when value is reached.



8. Press up and down arrows simultaneously to turn off.

Continued over page

Fill Flow Meter - 70 Series

Flow Meter Operation

1. Press 'PRO' to switch display screen on
2. To begin measuring flow into the sprayer tank, ensure '>L' next to the target volume is flashing. You can now apply flow through the fill system. The actual volume on the bottom line should begin increasing.



Note: If '>L' is not flashing when the TeeJet electric ball valve is fitted, the 'Actual' volume will not count

3. Once the target volume has been reached, an alarm will activate. Stop water flow and press 'CLR' to silence the alarm.
4. To reset the actual volume, press and hold 'CLR'
5. If at any stage the target volume becomes incorrect, press 'CLR' once. This will reset the target volume to the maximum value you programmed in when setting up the console.
6. When the operation is complete, press the up and down arrows simultaneously to turn the console off.

Groeneveld Auto Greaser

Preface

The Groeneveld Automatic Greasing System is cutting edge design encompassing robust components and precision engineering to bring the owner operator not only ease in operation and maintenance but also peace of mind that all moving systems are able to work at their peak.

To this end, Goldacres acknowledges that while we hold a high degree of knowledge in their product, we would always recommend that owners and dealers contact their local Groeneveld dealer for technical advice and assistance. We also advise that you use only genuine Groeneveld parts and lubricants. After all, this system is your investment in your machines serviceability and longevity!

The information following, has been produced by using excerpts from the Groeneveld EG0101 Zero General Manual. Utilising text, tables and diagrams as well as text and photographs supplied by Goldacres.

The following information about the auto greaser system has been approved by Groeneveld.

Introduction

Groeneveld Automatic Greasing Systems ensure the daily maintenance of the moving parts attached to the system. They avoid unnecessary machinery wear and down-time and thus save cost and prevent exasperation.

Groeneveld greasing systems are used by production companies, machinery used in service industries, agriculture, shipping, the offshore industry and the transport industry.

In the following list are the most important advantages:

- Increase of the service intervals, thus less unnecessary down-time;
- Less wear of the lubricated parts because of accurate and constant lubricating;
- Reduced repair and replacement costs;
- Reduced unexpected down-time;
- Fewer production losses.

With a Single line Automatic Greasing System, all attached lubrication points of a vehicle or machine are automatically lubricated at the correct time with the correct dose.

Moreover, optimum grease or lube-oil distribution over the whole lubricating surface is achieved, because the lubrication takes place while the machinery or vehicle is in operation. Every action is automatically carried out by the system. The user needs only to refill the reservoir periodically.

Definitions

NOTE: Is used to notify people of installation, operation or maintenance information that is important but not hazard related.

CAUTION: Instructions that if ignored will cause damage to the system or machine.

WARNING: Instructions that if ignored will cause personal injury or death to the operator or bystanders.

Groeneveld Auto Greaser - Overview I




Figure I. System Overview

Groeneveld Auto Greaser - Overview II




Figure 2. System layout for crop cruiser

Groeneveld Auto Greaser - Components

The COMPONENTS section will give you a basic run down of the components, their location and their purpose. A full operational description of the system is in the OPERATION section. Some settings, tips and words of advice and caution are also listed where applicable at each component's section. Please familiarise yourself with this area thoroughly.

Pump Unit

The Pump Unit is made up of the following parts – the main storage area, the metered reservoir where the next grease dose is held, main piston, follower plate, compressed air inlet, fill point and return / non

return valves. The purpose and operation of these will be explained in the manual.

The filling point is on the left side of the pump unit and should be covered with a protective cap.

Before filling, ensure you read and understand the following note and cautions:

CAUTION: When you take delivery of your sprayer, ensure you check the right hand side of the pump unit and look for a red tag or an over flow hole. If the red tag is still fitted, REMOVE IT now. If it is left in place, the reservoir may fail on refilling due to pressure build up.



Figure 3. Pump Unit



Figure 4. Fill Point



Figure 5. Red tagged bung in place.



Figure 6. Unplugged overflow hole

Continued over page

Groeneveld Auto Greaser - Components

NOTE: The fill point requires a Groeneveld female fill pump adaptor. You can purchase these via your local Groeneveld dealer or contact your Goldacres dealer to order.

CAUTION: Do not overfill the main reservoir. Fill only to about 2 cm from the top. You will see this instruction on the reservoir tank. Over filling will cause the reservoir to fracture.

CAUTION: Use ONLY HP0 or NLGI0 rated grease. It needs to be Lithium based and contain NO Teflon or Graphite as they stick to the meters and eventually jam them. The grease must NOT contain Aluminium or Copper compounds as they are abrasive to the seals and lines.

If you should happen to slightly overfill the reservoir, grease will overflow from the hole on the right of the pump unit as indicated in Figure 6. This will continue for about 3 days until the overflow channel is clear.

Main Air Supply

The air supply that operates the auto greasing system is the red air line running from the pneumatic manifold behind the right hand pod, to the bottom of the pump unit.




Figure 7. Main air supply from manifold




Figure 8. Main air supply at pump unit

Electronic Timer

The electronic timer sets the intervals for operation of the greasing system. This can be set at 30 minute intervals. The timer is located in the main cabin in the main fuse compartment to the right of the operators' seat. The timer is wired into the red covered ignition bus or via the 180A Relay. Power is applied when the ignition key is turned on.



Figure 9. Electronic timer



Figure 10. Electronic timer in main fuse compartment

The timer is protected by a 10A fuse and is the clear orange covered fuse indicated in Figure 10.

CAUTION: The timer should be preset to 90 minutes. This has been tested as the optimum time interval for greasing the main moving parts of your machine. Setting the timer to a longer interval will mean that the components on your sprayer will not be properly lubricated.

While this may seem to be a short time interval, do not forget that the auto greaser applies only small, metered amounts of grease at a time. Keeping that particular area topped up and in optimum condition.

Continued over page

Groeneveld Auto Greaser - Components

Solenoid

The solenoid at the bottom of the grease dispenser opens the valve, allowing air pressure to enter through the compressed air connection and push against the main piston. The inwards airline is pointed out at the bottom of Figure 12.

The solenoid valve between the air tank and the pneumatically operated pump (usually fitted to the pump) is a normally closed, free venting type. The valve is connected electrically by an M24 screw connector.



Figure 11. Solenoid location




Figure 13. Solenoid




Figure 12. Airline IN location

Continued over page

Groeneveld Auto Greaser - Components

Pressure Switch

The pressure switch is easily seen at the front of the unit. This monitors the system pressure during operation. Should pressure drop below a set point (due to brake in a main grease line), the switch will close and sound a low pressure alarm in the cabin.




Figure 14. Pressure switch location

The air pressure supplied to the auto greaser is 110 – 120 PSI (7.6 Bar). The minimum required for effective operation of the auto greaser is 90 PSI (6.1 Bar). Below this, grease pressure will likely be inadequate to effectively protect the components.

The pressure switch operates at 40 PSI (2.7 Bar) grease pressure. Should a main grease line become broken (see next heading on this page), the pressure will drop below 40 PSI and the alarm in the cabin will sound.

A pressure switch is included in the lubrication system (in the main pipe) to provide an alarm for too low a pressure in the system during the lubrication cycle.

This switch closes at a pressure of 40 bar, making a connection to earth. If this does not happen during the lubrication cycle, because insufficient or no grease pressure is generated, an alarm will be given. During the remaining cycle time there will be an intermittent alarm signal. This alarm will be repeated after a preset time if the problem is not corrected.




Figure 15. Pressure switch

An M24 screw connector connects the switch electrically.

For a system with a pneumatically operated pump the pressure switch is fitted to a distribution block. The electrically operated pump is provided with a built-in pressure switch.

Continued over page

Groeneveld Auto Greaser - Components

Return Valve

The return valve indicated in the photograph below allows grease to return to the reservoir from the grease line when pressure is released at the end of the lubrication cycle.



Figure 16. Return valve

NOTE: Removing this blank is not advised. There is a check ball held in under spring tension that will come out at some speed. If this is lost, the return valve and non return valve will not work and the system will pump the grease back to the reservoir. If you believe there is a problem with this part of the system, contact your Groeneveld dealer direct.

WARNING: Removing this blank is not advised. There is a check ball held in under spring tension that will come out at some speed. Eye injury may result from the ball bearing if the blank is removed. If you believe there is a problem with this part of the system, contact your Groeneveld dealer direct.

Second Grease Outlet

A second grease outlet is on the pump unit and shown in the photograph below, in this case it is covered by the brass blank indicated. The main grease line is indicated by the arrow to the right of the blank.

NOTE: If you decide you want to run a second grease outlet line, please contact your Groeneveld dealer directly for technical advice.




Figure 17. Second grease outlet

Continued over page

Groeneveld Auto Greaser - Components

Main Grease Lines

The main grease lines leave the pump unit and terminate at either a bank of metering units or a single metering unit. On your system, a single line leaves the pump unit and to a 'T' joint which branches off to the front and rear of the machine.





Figure 18, 19 & 20. Main Grease Lines

CAUTION: The main lines from the pump unit to the single or banks of metering units are monitored for pressure. Should one of these lines brake or leak, there will be a notable pressure drop in the system and a buzzer will sound in the cabin to alert you. The system will no longer be operating effectively and some or all areas may not be lubricated.

Grease Nipple Lines

The grease nipple lines are the smaller lines that run from the meter units and deliver the metered dose of grease to the grease nipple. These are Black, Red or Blue.

The 3 hose colours can be used if there are 3 different sized metering units in a bank. These make it easier to trace the lines to their terminating points.






Figure 21, 22 & 23.
Grease Nipple Lines



Black is used to denote the lines out of the largest meter unit/s (based on the shims or spacers). Red is used to denote the lines out of the smallest meter unit/s (based on the shims or spacers). Blue is used to denote the lines out of the intermediate meter unit/s (based on the shims or spacers).

CAUTION: These lines do not have their pressure monitored. Should a line after its meter unit be broken, the system will not sound the alarm buzzer. The grease will flow out of the point of least resistance, which is the hole or brake in the hose. It is important to make regular inspections of these lines to ensure they are not damaged. Also inspect the grease point for evidence of lubrication.

Continued over page

Groeneveld Auto Greaser - Components

Meter Distribution Block

The meter unit distribution block is a brass fitting that holds multiple meter units. It has a port to attach the main grease line in and a main grease line out if there are further banks to feed off that line. If there are no further banks, one of the 2 main grease line ports can be closed with a screw in blank. Any unused meter points will be terminated with a blanking plug.

CAUTION: Do not open any of the blanked ports or meter units. This can allow contaminants into the lines and thus be a potential cause of faults or failures.



Figure 24 & 25. Bare meter distribution block





Figure 26 & 27. Fully fitted meter distribution block

Groeneveld Auto Greaser - Pump Unit

1. Reservoir with follower plate
2. Air venting channel
3. Grease channel
4. Return channel to reservoir
5. Main line connection
6. Pressure channel
7. Return valve
8. Non-return valve
9. Compressed air connection
10. Main air piston
11. Spring
12. Filler connector
13. Small grease piston
14. Grease chamber
15. Flapper valve
16. Connection to reservoir




Figure 28. Pump unit exploded view

Pump Unit Operation

The timer counts down the preset interval and then closes the circuit applying power to the solenoid, opening it and allowing air pressure to enter through the bottom of the pump unit.

The air pressure is applied via the compressed air connection (9) the main piston (10) will be forced upwards applying pressure to the lubricant in chamber (14).

The pressure in chamber (14) forces valve (15) against the seat. The connection (16) to the reservoir (1) is closed so the grease does not pump straight back into the reservoir.

The lubricant leaves the chamber (14) via a channel (3) through the non-return valve (8) into the main or primary line. It moves along the main lines under pressure and acts on the plungers in the metering units.

The metering units are brought under full pump pressure passing their metered quantities of lubricant into the lubrication points. As a result of the pressure differential at the return valve (7) the return channel (4) remains closed.

At the end of the complete 3 minute lubrication cycle, the air pressure under the main piston (10) falls, allowing the piston to be pushed downward by the spring (11). At the same time flapper valve (15) is released and, because of the reduced pressure in the chamber (14), lubricant is drawn from the reservoir. This primes the system for the next cycle.

The non-return valve (8) prevents grease from the system piping and metering units from flowing back into the chamber (14).

The pressure in the main pipe opens the return valve (7) via the channel (6). This allows the pressure of the lubricant to flow via the channel (4) to the reservoir.

The metering units, with this pressure drop can now automatically refill themselves. The springs inside the meter units push the plunger back and the reservoir in front of the plunger fills, priming it for the next cycle.

There is NO pressure relief valve for the grease. Once the system has expended all the grease in the meter units, the system hydraulically locks until the end of the cycle time.

Continued over page

Groeneveld Auto Greaser - Pump Unit

Pump Unit Reservoir

The reservoir (2) is made from impact-resistant plastic that can withstand the influences of fluctuating temperatures. The reservoir can hold a quantity of lubricant that in most cases is sufficient for about 4 months, depending on the number of grease points.

The minimum level (5 cm) is marked by a label (3) on the reservoir.

NOTE: There is NO maximum level mark.




Figure 29. Reservoir

In the standard reservoir a follower plate is placed above the level of the lubricant. This plate follows the level of the lubricant; as the level falls the follower plate falls with it under the action of a tension spring. The follower plate prevents the increase of air into the lubricant and any consequent soaping of the lubricant. Funneling of grease as the level falls is also prevented. The follower plate also wipes the reservoir wall clean. This allows the level of the lubricant to be checked easily at a glance.

Groeneveld Auto Greaser - Meter Units

Meter Units

There are 11 metering unit types (1) available for the Single line system, each with a differing metered lubricant quantity. By careful selection of the type of metering unit each lubrication point can be provided with the right quantity of lubricant.

The metering units are fitted in groups on distribution blocks (2); this is a cast brass distribution block to which the primary (main) line (3) is connected. The blocks are available with several ports or outlets to which metering units can be connected. The unused outlets should be blanked-off. The metering units are also made of brass and are, because of their enclosed design, exceptionally suitable for use in dirty and dusty conditions.




Figure 30. Distribution block

CAUTION: Do not open any of the blanked ports or meter units. This can allow contaminants into the lines and thus be a potential cause of faults or failures.

Figure 31 illustrates a new metering unit, one that has not yet been filled with grease. Item (1) in this figure is the spacer, which determines the delivery of the metering unit.

The metering units that are used in your greasing system may differ externally, or even internally, from the one illustrated here. However, the operating principle is always the same.

Meter Unit Setup

The meter units measure the dose of grease to the grease nipple. The metered dose is varied by a number of shims or spacers. If you look closely at your machine, you will see each meter will have 1, 2 or 3 shims. After that, it moves up to a spacer (equivalent to 4 shims). Then 1 spacer with 1, 2 or 3 shims, followed by 2 spacers, then 2 spacers and 1 shim (9 shim spacing).




Figure 31. Meter Unit fitted with spacer

This has been set by the technician when fitted at the factory and has been tested to ensure each component gets the grease it requires. This will allow enough grease to be pushed into the moving parts, lubricating them as well as keeping dirt and abrasives out. If you believe that any points are not getting enough grease, check the lines for damage. If none is evident, contact your dealer or Groeneveld direct and ask about increasing the meter dose for that particular area.

CAUTION: It is not advisable to open the metering units as this allows the entry of dirt, and thus is a potential cause of faults and failures.





Figure 32. Meter components showing shim

Groeneveld Auto Greaser - Meter Unit Operation


Figure 33. Meter unit & Spacer



PHASE A. The pump presses the grease into grease channel (1). The grease pushes plunger (4) past channel (2). The grease now fills chamber (3) and pushes plunger (5) to the right. The stroke length of plunger (5) will determine the amount of grease

that will be pressed through the secondary grease line to the grease point. This stroke length - hence the capacity of chamber (3) - is determined by the number and thickness of the spacers as shown above.


Figure 34. Meter unit in phase A



PHASE B. When the pump stops and as the grease pressure drops, spring (7) (fig. 7.4) will push plunger (4) back to the left, closing off channel (1). O-ring (9) prevents grease from being sucked back from

chamber (6). Plunger (5) is pushed back by spring (10) and presses the grease in chamber (3), via channel (2), to chamber (8).

Figure 35. Meter unit in phase B




Continued over page

Groeneveld Auto Greaser - Meter Unit Operation

PHASE C. During the next lubrication cycle, the same happens as in phase A. Chamber (8) however, is now filled with grease. As plunger (4) moves right under influence of the grease pressure, the grease

in chamber (8) is pressed, via chamber (6) and the secondary grease line, to the grease point. During all this, O-ring (9) is pressed outward to allow the grease to leave chamber (8).

Figure 36. Meter unit in phase C



CAUTION: It is not advisable to open the metering units as this allows the entry of dirt, and thus is a potential cause of faults and failures.

Groeneveld Auto Greaser - Electronic Timer

The greasing system is controlled by an electronic timer. The timer produces, at set time intervals impulses lasting 3 minutes. These impulses energize the solenoid valve in the air supply to start the lubrication cycle. The interval between successive lubrication cycles is adjusted on the electronic timer.

If during a cycle the power supply is switched off, a complete new lubrication cycle will restart when the power supply is again switched on.




Figure 37. Electronic Timer

Adjusting the Timer

Your electronic timer should be set to 90 minutes to ensure your sprayer components are adequately lubricated.

CAUTION: At Goldacres, we strongly advise that you do not increase your timer setting past 90 minutes. This could mean your sprayer grease points are not being sufficiently lubricated.

The interval time between two successive lubrication cycles can be adjusted using the step switch. One of ten time intervals can be selected. The standard version has time intervals increasing by 0.5 h steps (0.5, 1.0, 1.5... 5 h). If the power supply is switched off during a cycle the cycle will be ended. When the power supply is switched on again a complete new cycle will be started.

Timer Alarms

Alarm signals can be generated by the electronic timer in various circumstances.

The standard version uses a built-in buzzer. In other versions another (external) alarm indicator can be fitted, for example a lamp.

The alarm signal is generated in the following situations:

- After reaching 70% of the cycle time (70% of 3 minutes = 2 minutes) the pressure switch should have connected to earth. If this is not the case - because insufficient pressure has been built up - then a continuous alarm signal is generated.
- The electronic timer runs a self-test after the power supply is switched on; if there is a fault condition an intermittent alarm is generated. This can occur if no interval is selected by the step switch.

If the electronic timer sounds an alarm to indicate that the timer or greasing system is not functioning properly, it is strongly advised to examine (or have examined) the greasing system and if necessary to make repairs. If this is left too long, damage can be caused to either the sprayer or the greasing system.

Groeneveld Auto Greaser - Maintenance & Testing

Periodic Maintenance

CAUTION: All maintenance points must be carefully followed. Failure to do so can cause failure of your auto greasing system or your machine to be under lubricated.

The following maintenance is required to ensure a long and reliable lifespan of the auto greasing system:

1. Do not overfill the main reservoir. Fill only to about 2 cm from the top. You will see this instruction on the reservoir tank. Over filling will cause the reservoir to fracture.
2. Check the lubricant levels daily.
3. Use ONLY HP0 or NLGI0 rated grease. It needs to be Lithium based and contain NO Teflon or Graphite as they stick to the meters and eventually jam them. Use NO Aluminium or Copper compounds as they are abrasive to the seals and lines.
4. Your electronic timer should be set to 90 minutes to properly lubricate the connected points on your machine.
5. Inspect grease points daily. If there is no indication of grease at the components, there may be a break in the line between the meter and the grease nipple.
6. Inspect pump unit and airlines / power cables for external damage.
7. Inspect all grease lines weekly for damage. If a brake or puncture occurs between the tank and meter units, there will be a buzzing alarm in the cabin. Your system may not be able to lubricate the machine effectively. However, if a brake occurs between a meter unit and a grease nipple, there will be no alarm. Grease will be lost at the break and the component will not be lubricated.
8. Do not make alterations to your system. Call your local Groeneveld dealer for technical advice.
9. Do not use high pressure or steam cleaners on the pump unit as it may force water into the system.
10. Drain the pneumatic system regularly to prevent water build up. Water entering under the piston

CAN NOT drain away. Eventually this will fill the area under the piston and the amount of lubricant delivered will reduce and eventually cease.

11. Do not forget that the auto grease doesn't cover every grease point on the machine. Ensure you check and grease those parts that are not connected to the auto greaser as per your operators' manual.

Filling

CAUTION: Do not overfill the main reservoir. Fill only to about 2 cm from the top. You will see this instruction on the reservoir tank. Over filling will cause the reservoir to fracture.

CAUTION: Use ONLY HP0 or NLGI0 rated grease. It needs to be Lithium based and contain NO Teflon or Graphite as they stick to the meters and eventually jam them. The grease must NOT contain Aluminium or Copper compounds as they are abrasive to the seals and lines.


When the lubricant in the reservoir has fallen to the minimum level it must be re-filled. Generally a filler pump is used for this purpose. The procedure is as follows:

1. Ensure there grease drain hole on the right of the pump unit is not blocked.
2. With a new filler pump (or filling hose) the hose should first be primed with lubricant. This avoids the pumping of air into the reservoir. For this the ball (1) in the snap-on connector on the filler hose should be depressed while pumping lubricant through the hose until it is filled with the lubricant.
3. Remove the dust cap from the filler connector.
4. Carefully clean the filler connector and the connector on the filler hose.
5. Secure the filler hose to the filler connector.
6. Fill the reservoir to not more than the maximum level (2 cm below the top of the reservoir) or until the follower plate meets its stop. If you slightly overfill, you will see grease flow from the drain hole on the right of the pump unit. This will take about 3 days to complete draining.

Continued over page

Groeneveld Auto Greaser - Maintenance & Testing

7. Replace the dust cap on the filler connector.
8. There is a filter within the filler connector in the reservoir. If pumping is very difficult, the filter could be blocked. In this case, dismantle and clean the filter.



Testing Electronic Timer

STEP SWITCH TEST

This checks the step switch contacts in all positions.

1. Set the step switch to position 'test A'.
2. Activate the electronic timer by switching on the ignition.
3. Press the 'test' button.
4. Wait for the audible alarm signal then release the 'test' button.
5. Within 5 seconds turn the step switch to the required interval time position. Each position produces a number of signals: position 1 gives one signal, position 2 two signals etc.
6. The switch can be set to all positions. Positions 'test A' and 'test B' will not produce an alarm signal.
7. End the test by switching off the ignition.

ACCELERATED CYCLE TEST

This allows you to test a timing cycle without waiting the full set time interval. It sets the time interval at 1/20 of its duration.

1. Set the step switch to position 'test A'.
2. Press and hold the 'test' button.

3. Switch the ignition on while still keeping the 'test' button pressed in.
4. The alarm signal buzzer will now sound. The 'test' button must be pressed as long as the alarm signal continues.
5. Within 5 seconds of the end of the alarm signal turn the step switch to the required position.
6. The electronic timer is now fully operational; the time intervals are now 1/20 of their usual times.
7. End the test by switching off the power supply.

NORMAL SYSTEM TEST

1. Switch the ignition on.
2. Press the 'test' button; a normal lubrication cycle will then follow. The switch can be set in any position except 'test A' or 'test B'.

After this test the electronic timer will work at the interval set.

The 'test B' position is only for use with the test or read-out unit.

Groeneveld Auto Greaser - Warnings Summary

NOTE: Instructions given to the operator to better enhance the system.

CAUTION: Instructions that if ignored will cause damage to the system or machine.

WARNING: Instructions that if ignored will cause personal injury or death to the operator or bystanders.

WARNING: Removing this blank is not advised. There is a check ball held in under spring tension that will come out at some speed. Eye injury may result from the ball bearing if the blank is removed. If you believe there is a problem with this part of the system, contact your Groeneveld dealer direct.

CAUTION: Do not overfill the main reservoir. Fill only to about 2 cm from the top. You will see this instruction on the reservoir tank. Over filling will cause the reservoir to fracture.

CAUTION: When you take delivery of your sprayer, ensure you check the right hand side of the pump unit and look for a red tag or an over flow hole. If the red tag is still fitted, REMOVE IT now. If it is left in place, the reservoir may fail on refilling.

CAUTION: Use ONLY HP0 or NLGI0 rated grease. It needs to be Lithium based and contain NO Teflon or Graphite as they stick to the meters and eventually jam them. The grease must NOT contain Aluminium or Copper compounds as they are abrasive to the seals and lines.

CAUTION: The timer should be preset to 90 minutes. This has been tested as the optimum time interval for greasing the main moving parts of your machine. Setting the timer to a longer interval will mean that the components on your sprayer will not be properly lubricated.

CAUTION: The main lines from the pump unit to the banks of metering units or single metering unit are monitored for pressure. Should one of these lines brake or leak, there will be a notable pressure drop in the system and a buzzer will sound in the cabin to alert you. The system will no longer be operating effectively and some or all areas may not be lubricated.

CAUTION: These lines do not have their pressure monitored. Should a line after its meter unit be broken, the system will not sound the alarm buzzer. The grease will flow out of the point of least resistance, which is the hole or brake in the hose. It is important to make regular inspections of these lines to ensure they are not damaged and the grease point for evidence of lubrication.

CAUTION: Do not open any of the blanked ports on meter distribution blocks or the meter units. This can allow contaminants into the lines and thus be a potential cause of faults or failures.

CAUTION: It is not advisable to open the metering units as this allows the entry of dirt, and thus is a potential cause of faults and failures.

CAUTION: At Goldacres, we strongly advise that you do not increase your timer setting past 90 minutes. This could mean your sprayer grease points are not being adequately lubricated.

CAUTION: All maintenance points must be carefully followed. Failure to do so will can failure of your auto greasing system or your machine to be under lubricated.

NOTE: The fill point requires a Groeneveld female fill pump adaptor. You can purchase these via your local Groeneveld dealer or contact your Goldacres dealer to order.

NOTE: If you decide you want to run a second grease outlet line, please contact your Groeneveld outlet directly on technical advice.

NOTE: Removing this blank is not advised. There is a check ball held in under spring tension that will come out at some speed. If this is lost, the return valve and non return valve will not work and the system will pump the grease back to the reservoir. If you believe there is a problem with this part of the system, contact your Groeneveld dealer direct.

Groeneveld Auto Greaser - Technical Data

Pump Unit

Your sprayer is fitted with model part number 36201 on this table.

	part number			
	36201	35501	37101	43001
reservoir capacity	4 liters	8 liters	4 liters	8 liters
delivery	42 cc / stroke		60 cc / stroke	
ratio	9:1			
grease pressure	72 bar (for an air pressure of 8 bar)			
maximum grease pressure	100 bar			
temperature range	-25 °C to +80 °C (NLGI 0 grease)			
weight	6.3 kg	7.2 kg	7.52 kg	8.42 kg

Electronic Timer

Your sprayer is fitted with part number 0099.01 on this table.

	part number					
	099.01 (12 V)	032.01 (24 V)	676.02 (12V)	675.02 (24V)	678.02 (12V)	677.02 (24V)
cycle time	3 minutes		2 minutes		3 minutes	
cycle intervals	steps of 30 minutes (0.5 - 5 h)		steps of 5 minutes		steps of 30 minutes	
alarm	built-in buzzer		internal relais (16A)		internal relais (16A)	

Pressure Switch

Your sprayer is fitted with part number 184.08 on this table.

	part number
	225.01
type	normally-open
switching pressure	40 bar
connection	2-wire
screw thread	M24

Solenoid

Your sprayer is fitted with part number 184.08 on this table.

	part number	
	184.08 (12 V)	183.08 (24 V)
type	normally-closed with open venting	normally-closed with open venting
operating pressure	maximum 10 bar	maximum 10 bar
power requirement	maximum 8 W	maximum 8 W
screw thread	M24	M24

Meter Units

The metering units as mentioned are altered using combinations of shims and spacers (a spacer being equivalent to 4 shims) to a maximum of 9 shims (2 spacers and 1 shim).

Metering unit nr.	Delivery [cc]
0	0.025
1	0.050
2	0.1
3	0.15
4	0.2
5	0.25
6	0.3
7	0.35
8	0.4
8,5	0.7
9	1.0

Groeneveld Auto Greaser - Troubleshooting

<i>Fault</i>	<i>Cause</i>	<i>Action</i>
1. All points to be lubricated are dry.	a. Pump reservoir is empty. b. Reservoir filled with grease that is too thick and unsuitable for the system. c. Main pipe leaking. d. Electronic timer, PLC or pneumatic impulse counter not set correctly. If there is another cause, please consult your dealer.	a. Fill the reservoir (see section 9). b. Remove and clean the reservoir. Refit and fill the reservoir with the correct grease. Remove the end plugs from the distribution blocks and pump the old grease out of the system. c. Repair the line and bleed the system if a new piece of piping has been fitted. d. Reset the electronic timer, PLC or brake impulse counter.
2. Pump does not work or does not reach working pressure.	a. Pneumatically operated pump: No or too-low air pressure. b. Piston does not rise. If there is another cause, please consult your dealer.	a. Ensure there is an air pressure of 6 to 8 bar. b. Dismantle the cover of the pump casing and clean the piston.
3. One or more lubrication points are dry while the others receive sufficient grease.	a. Break in the secondary piping. b. Inoperative metering unit.	a. Repair or replace the line. b. Remove the metering unit and fit a new unit.
4. A lubrication point receives too much grease.	a. Internal leak in the metering unit.	a. Remove and clean the metering unit or fit a new unit.
5. Pneumatically operated pump: Solenoid valve fails to operate or does not operate correctly.	a. Bad or open electrical connections. b. Solenoid valve internally fouled with water and/or rust from the vehicle air system.	a. Check the electrical circuit and connections to the solenoid valve. Check the valve with direct current bypassing the electronic timer. Watch out for short-circuits! b. Dismantle, clean and refit the valve or fit a new valve. Clean the vehicle air system.
6. Continuous buzzing from the electronic timer.	a. Short circuit.	a. Check wiring and test solenoid.
7. Electronic timer does not operate.	a. Fuse blown.	a. Fit new fuse.
8. Too much grease at all lubrication points.	a. System greasing frequency does not correspond with vehicle operating conditions.	b. Reduce the greasing frequency. Do not be too sparing, it is better to grease too much than too little.
9. Alarm buzzer in electronic timer sounds intermittently.	a. Grease level in the reservoir below the minimum. a. System not reaching working pressure. c. No cycle time interval selected on the electronic timer.	a. Fill the reservoir (see section 9). a. Top up the reservoir with grease and/or repair the main pipe, check the pump pressure with a manometer. c. Set a cycle time interval on the electronic timer.

Groeneveld Auto Greaser - Dealer Contacts

Head Office

268 Proximity Drive
Sunshine West, Vic 3020
Tel: 03 8329 4333
Fax: 03 8329 4334

Perth Branch

8/28 Belmont Avenue
Belmont, WA 6104
Tel: 08 9262 9800
Fax: 08 9477 2688

Adelaide Branch

5 George Street
Wingfield, SA 5013
Tel: 08 8349 6322
Fax: 08 8262 1783

Groeneveld Tasmania

8 Devonport Road
Devonport, TAS 7310
Tel: 03 6423 4256
Fax: 03 6424 9772

Brisbane Branch

1818 Ipswich Road
Rocklea, QLD 4106
Tel: 07 3272 7975
Fax: 07 3272 7534

Groeneveld Central QLD


193-195 Wade Street
Nth Rockhampton, QLD 4701
Tel: 07 4936 4833
Fax: 07 4936 4822

Sydney Branch

1/36 Lidco Street
Arndell Park, NSW 2148
Tel: 02 9831 4933
Fax: 02 9831 4966

Townsville Branch

Unit 10 72-78 Crocodile Crescent
Townsville, QLD 4810
Tel: 07 4774 3056
Fax: 07 4774 3824



GOLDACRES

www.goldacres.com.au