

RAVEN

Installation and Operation Guide



Raven Switch Box
for Use with ISObus Systems

Disclaimer

While every effort has been made to ensure the accuracy of this document, Raven Industries assumes no responsibility for omissions and errors. Nor is any liability assumed for damages resulting from the use of information contained herein.

Raven Industries shall not be responsible or liable for incidental or consequential damages or a loss of anticipated benefits or profits, work stoppage or loss, or impairment of data arising out of the use, or inability to use, this system or any of its components. Raven Industries shall not be held responsible for any modifications or repairs made outside our facilities, nor damages resulting from inadequate maintenance of this system.

As with all wireless and satellite signals, several factors may affect the availability and accuracy of wireless and satellite navigation and correction services (e.g. GPS, GNSS, SBAS, etc.). Therefore, Raven Industries cannot guarantee the accuracy, integrity, continuity, or availability of these services and cannot guarantee the ability to use Raven systems, or products used as components of systems, which rely upon the reception of these signals or availability of these services. Raven Industries accepts no responsibility for the use of any of these signals or services for other than the stated purpose.

Overview

The Raven Switch Box for use with ISOBUS systems is designed to interface with an ISOBUS Virtual Terminal (VT) display and a Raven ISO product control node.



The switch box features:

- Ten section switches for quick boom or implement section control
- A master/override switch for full boom or implement control
- A power LED

Care and Maintenance

Refer to the following items when selecting a mounting location for the Raven Switch Box for use with ISOBUS systems and the VT display.

- The switch box is not weatherproof. Mount the switch box inside of the machine cab or driver compartment within easy reach of the driver or operator.
- The switch box should be mounted in a location where it will not be jarred during normal equipment operation. Keep the console and switch box clear of moving elements within the cab.
- Route all cables to avoid pinching, kinking or damaging the cable and to avoid tripping hazards.

Installation

Refer to the following sections to attach the Raven Switch Box for use with ISOBUS systems and mounting bracket for the specific VT display.

Mounting the Switch Box

John Deere GS 2600/2630 Kit (P/N 117-0171-437)

Note: The mounting bracket is designed to mount the Raven Switch Box for use with ISOBUS systems above the GS 2600/2630 display terminal.

1. Remove the John Deere terminal and display bracket from the vehicle cab using the knob on the back of the mounting arm.



2. Remove the existing wing bolts from the display terminal and remove the mounting bracket (P/N 107-0172-049) from the display.
3. Attach the Raven Switch Box for use with ISOBUS systems (P/N 063-0173-143) to the mounting bracket using two 5/16" screws (P/N 311-0001-007).



Note: The mounting bracket is designed to mount the switch box above the VT display. When looking at the back of the switch box and mounting bracket, the four pin connector and small part number label should be to the left of the mounting bracket flange.

4. Mount the display terminal and switch box together using the existing wing bolts. The switch box bracket should be mounted between the GS 2600/2630 and the existing display mounting bracket.
5. Remount the display with switch box in the vehicle with the mounting knob.

Connection

The Raven Switch Box for use with ISOBUS systems connects to the ISOBUS system using the John Deere switch box cable (P/N 115-0172-011).

To connect the Raven Switch Box for use with ISOBUS systems:

1. Connect the female, 4-pin Deutsch connector on the switch box cable to the male, 4-pin connector on the display cable located near the GS 2600/2630.
2. Connect the 2-pin Deutsch connector on the ISO Switch Box cable to the switched power port on the back of the ISO Switch Box.



3. Connect the male, 4-pin Deutsch connector on the switch box cable to the 4-pin connector on the back of the switch box.

Note: If the switch box is connected as instructed above, the switch box will be powered on or off using keyed power.

Switch Box Operation

The Raven Switch Box for use with ISOBUS systems puts the section control modes right at the operator's finger tips.

Important: Make sure to toggle the master switch to the off position when closing or exiting a job to avoid unintentional product application once the virtual terminal closes application management functions. It is also good practice to shut off section switches when the application system is not being used.

Refer to the following sections for detailed operation of the switch box:



Power LED

This LED indicates the status of power into the Raven Switch Box for use with ISOBUS systems. This LED should be on (solid) during normal operation. If this LED is not lit when the ignition switch is turned on, troubleshoot the ISOBUS system before starting any system operations. Refer to the "Troubleshooting" section on page 5 for troubleshooting information.

Master/Override Switch

Note: The master switch should be toggled off when powering the Raven Switch Box for use with ISOBUS systems. If the master switch is on when the unit is powered on, cycle the master switch off then back on to ensure that boom sections will enable as anticipated during operations.

The master switch toggles all section switches on or off. When the master switch is in the 'ON' position, each section will function according to the corresponding section switch (see the "3-Way Selectable Section Switches" below). Toggle the master switch to the 'OFF' position to turn all boom or implement sections off.

Hold the master switch to the 'OVERRIDE' position to temporarily override any sections controlled by an optional section control system on.

3-Way Selectable Section Switches

Each of the ten section switches may be toggled individually to one of the three following positions:

- ON - manually control the section on. Section control of the section is disabled and will not automatically control this section based on coverage, zone maps or field boundaries.
- ACCU - section control (if activated on VT display), is enabled for the section. The section control features will automatically turn sections on or off based upon previous coverage, zone maps or field boundaries created or active in the job.

Important: When a job is started without a field boundary and all section switches set to ACCU, the VT display may not allow the Raven product controller node to initially enable sections. Toggle the master switch to the OVERRIDE position or momentarily toggle at least one section switch to ON (with master switch in the ON position) then back to the ACCU position to initialize automatic section control functionality in this condition.

Note: To perform section control features, the ISOBUS system will require a Raven ISO product controller node.

- OFF - manually control the section off. This section will remain off regardless of section control features.

Note: Leave the section switch in the off position for any sections not controlled by or configured on the VT display.

Troubleshooting

General Issues

Issue	Possible Cause	Solution
Power LED not lit	No power to switch box	Check CAN Switch Box switched power connection.
		Ensure console or field computer is powered on.
		Check chassis cable power and ground connections.
		Check chassis cable fuses.
Boom valves do not turn on	Faulty power connection	Verify power LED on switch box is lit. If the LED is not lit, check the power connections.
Boom sections do not turn off	Remote section switches in incorrect position	Remote section switches must be in the OFF position to allow the switch box to control sections.

Setup Issues

Issue	Possible Cause	Solution
Previous calibration data lost	Poor CAN connections	Check CAN connections on back of the Raven Switch Box.

Job Issues

Issue	Possible Cause	Solution
Section status displays as inactive	Switch box switches in the off position	Toggle the section and master switches to the on position.
Sections do not enable when starting a job	VT display may not allow automatic section control until the product controller node is activated	If a job is started without a field boundary and all section switches are set to the ACCU position, either: <ul style="list-style-type: none">toggle the master switch to the OVERRIDE position momentarily, ortoggle at least one section switch to the ON position momentarily and return to the ACCU position.

Issue	Possible Cause	Solution
Section status does not turn green (ON) when sections enabled	Master switch must be toggled off at power-up	Cycle the master switch off then back on.
	Sections not properly configured	Verify section setup on the control console or field computer.
	Nodes not programmed properly	Verify all node calibration data is entered.
Product applied to zero rate zones	Bed creep	Adjust hydraulic valve and valve calibration settings to stop bed creep. Refer to the control console or field computer operation manual.
	Wrong valve type installed	A fast close or PWM close valve must be selected to shut off product application in zero rate zones. Refer to field computer or control console manual for more information about selecting valve type.
	Incorrect valve setting	Check valve or PWM settings.
	Section switches toggled on in zero rate zones	Toggle the section switches to the ACCU or OFF positions.
Sections enabled but field computer not recording coverage	Remote section switches left in the ON position	Toggle all remote section switches to the off position. Remote switches will override the section switch status and automatic section control features.

R A V E N

RAVEN INDUSTRIES

Limited Warranty

What Does this Warranty Cover?

This warranty covers all defects in workmanship or materials in your Raven Applied Technology Division product under normal use, maintenance, and service.

How Long is the Coverage Period?

Raven Applied Technology Division products are covered by this warranty for 12 months after the date of purchase. This warranty coverage applies only to the original owner and is nontransferable.

How Can I Get Service?

Bring the defective part and proof of purchase to your Raven dealer. If your dealer agrees with the warranty claim, the dealer will send the part and proof of purchase to their distributor or to Raven Industries for final approval.

What Will Raven Industries Do?

Upon confirmation of the warranty claim, Raven Industries will, at our discretion, repair or replace the defective part and pay for return freight.

What is not Covered by this Warranty?

Raven Industries will not assume any expense or liability for repairs made outside our facilities without written consent. Raven Industries is not responsible for damage to any associated equipment or products and will not be liable for loss of profit or other special damages. The obligation of this warranty is in lieu of all other warranties, expressed or implied, and no person or organization is authorized to assume any liability for Raven Industries.

Damages caused by normal wear and tear, misuse, abuse, neglect, accident, or improper installation and maintenance are not covered by this warranty.

RAVEN

Raven Switch Box
for Use with ISObus Systems
Installation & Operation Guide
(P/N 016-0171-513 Rev A 8/11 E18145)



Raven Industries

Applied Technology Division
P.O. Box 5107
Sioux Falls, SD 57117-5107
www.ravenprecision.com

Toll Free (U.S. and Canada): (800)-243-5435
or Outside the U.S. :1 605-575-0722
Fax: 605-331-0426
www.ravenhelp.com

Notice: This document and the information provided are the property of Raven Industries, Inc. and may only be used as authorized by Raven Industries, Inc. All rights reserved under copyright laws.