

R A V E N

Calibration & Operation Manual



ISO AutoBoom®

Disclaimer

While every effort has been made to ensure the accuracy of this document, Raven Industries assumes no responsibility for omissions and errors. Nor is any liability assumed for damages resulting from the use of information contained herein.

Raven Industries shall not be responsible or liable for incidental or consequential damages or a loss of anticipated benefits or profits, work stoppage or loss, or impairment of data arising out of the use, or inability to use, this system or any of its components. Raven Industries shall not be held responsible for any modifications or repairs made outside our facilities, nor damages resulting from inadequate maintenance of this system.

As with all wireless and satellite signals, several factors may affect the availability and accuracy of wireless and satellite navigation and correction services (e.g. GPS, GNSS, SBAS, etc.). Therefore, Raven Industries cannot guarantee the accuracy, integrity, continuity, or availability of these services and cannot guarantee the ability to use Raven systems, or products used as components of systems, which rely upon the reception of these signals or availability of these services. Raven Industries accepts no responsibility for the use of any of these signals or services for other than the stated purpose.

Chapter 1	<i>Important Safety Information</i>	1
	Hydraulic Safety	2
	Electrical Safety	2
Chapter 2	<i>Introduction</i>	3
	Updates	3
	Pre-Installation	4
	Wiring Connections	5
Chapter 3	<i>PowerGlide Plus</i>	7
	PowerGlide Plus Kit Contents	7
	Install the ISO AutoBoom Wiring	10
	Install the AutoBoom Node	10
	Connect the Harness to the Boom Function Controls	10
	Connect the Boom Sense Functions via Scotch Lock Splice Connectors (If Applicable) ..	11
	Install the Power Leads	12
	Connect the Harness Cable to the Power Cable	12
	Connect the Harness Cable to the Machine	13
	PowerGlide Plus Routine Operation	21
	AutoBoom Icons	21
	Setup Tools	22
	Diagnostic Tools	23
	Alarms	23
	AutoBoom Pre-Calibration Diagnostics	25
	Calibration	26
	Center Rack Control Calibration (If Equipped)	27
	Routine Operation	28
	System Adjustments	30
	Resetting Defaults	31
Chapter 4	<i>UltraGlide</i>	33
	UltraGlide Kit Contents	33
	Install the ISO AutoBoom Wiring	36
	Install the AutoBoom Node	36
	Connect the Harness to the Boom Function Controls	36
	Connect the Boom Sense Functions via Scotch Lock Splice Connectors (If Applicable) ..	37
	Install the Power Leads	38
	Connect the Harness Cable to the Power Cable	38
	Connect the Harness Cable to the Machine	39
	UltraGlide Routine Operation	47
	AutoBoom Icons	47
	Setup Tools	48

Table of Contents

Diagnostic Tools	50
Alarms	51
AutoBoom Pre-Calibration Diagnostics	53
Calibration	54
Slant Control Calibration	56
Center Rack Control Calibration	57
Routine Operation	58
System Adjustments	64
Resetting Defaults	67
Chapter 5 <i>Troubleshooting</i>	69
Node	69
AutoBoom Pre-Calibration Diagnostics	70
AutoBoom Calibration	71
AutoBoom Operation	72
Chapter 6 <i>System Diagrams</i>	75

CHAPTER

1

Important Safety Information

NOTICE

Read this manual and the operation and safety instructions included with your implement and/or controller carefully before installing the AutoBoom™ system.

- Follow all safety information presented within this manual.
- If you require assistance with any portion of the installation or service of your Raven equipment, contact your local Raven dealer for support.
- Follow all safety labels affixed to the AutoBoom system components. Be sure to keep safety labels in good condition and replace any missing or damaged labels. To obtain replacements for missing or damaged safety labels, contact your local Raven dealer.

When operating the machine after installing AutoBoom, observe the following safety measures:

- Be alert and aware of surroundings.
- Do not operate AutoBoom or any agricultural equipment while under the influence of alcohol or an illegal substance.
- Remain in the operator's position or a safe working distance away from the booms at all times when AutoBoom is engaged.
- Disable AutoBoom when exiting from the operator's seat and machine.
- Do not drive the machine with AutoBoom enabled on any public road.
- Determine and remain a safe working distance from other individuals. The operator is responsible for disabling AutoBoom when the safe working distance has diminished.
- Ensure AutoBoom is disabled prior to starting any maintenance work on AutoBoom or the machine.

WARNING

- When starting the machine for the first time after installing AutoBoom, be sure that all persons stand clear in case a hose has not been properly tightened.
- The machine must remain stationary and switched off, with the booms unfolded and supported, during installation or maintenance.

 **CAUTION**

Hydraulic Safety

- Raven Industries recommends that appropriate protective equipment be worn at all times when working on the hydraulic system.
- Never attempt to open or work on a hydraulic system with the equipment running. Care should always be taken when opening a system that has been previously pressurized.
- When disconnecting the hydraulic hoses or purging is required, be aware that the hydraulic fluid may be extremely hot and under high pressure. Caution must be exercised.
- Any work performed on the hydraulic system must be done in accordance with the machine manufacturer's approved maintenance instructions.
- When installing AutoBoom hydraulics or performing diagnostics, maintenance, or routine service, ensure that precautions are taken to prevent any foreign material or contaminants from being introduced into the machine's hydraulic system. Objects or materials that are able to bypass the machine's hydraulic filtration system will reduce performance and possibly damage the AutoBoom hydraulic valve.

Electrical Safety

- Always verify that the power leads are connected to the correct polarity as marked. Reversing the power leads could cause severe damage to the equipment.
- Ensure that the power cable is the last cable to be connected.

CHAPTER

2

Introduction

Congratulations on your purchase of the Raven ISO AutoBoom™ system! The AutoBoom system, used in conjunction with a Virtual Terminal (VT) Display, is designed to provide automated boom height adjustment for agricultural equipment. Using the machine's existing hydraulics, AutoBoom's parallel hydraulic system keeps the machine's hydraulic system open, using only the hydraulic fluid needed to balance the hydraulic cylinders to allow the booms to raise or lower effortlessly.

The instructions in this manual are designed to assist in the proper calibration and operation of the AutoBoom system when used with the VT Display.

Important: *Installation of the AutoBoom system must be completed before calibrating the system. If you have questions regarding the installation of the AutoBoom system, refer to the machine-specific AutoBoom Installation Manual provided with the installation kit. For questions about the field computer/controller, refer to the Installation & Operation Manual provided with the field computer/controller.*

Note: *The VT must be instance 0 to be compatible with Raven ISO products.*

Updates

Updates for equipment installation manuals and software are available on the Raven Industries Applied Technology website at:

www.ravenhelp.com

Sign up for e-mail alerts, and you will automatically be notified when updates for your Raven products are available on the website!

At Raven Industries, we strive to make your experience with our products as rewarding as possible. One way to improve this experience is to provide us with feedback on this manual.

Your feedback will help shape the future of our product documentation and the overall service we provide. We appreciate the opportunity to see ourselves as our customers see us and are eager to gather ideas on how we have been helping or how we can do better.

To serve you best, please send an email with the following information to

techwriting@ravenind.com

-ISO AutoBoom Calibration & Operation Manual

-Manual No. 016-0130-065 Rev. F

-Any comments or feedback (include chapter or page numbers if applicable).

-Let us know how long have you been using this or other Raven products.

We will not share your email or any information you provide with anyone else. Your feedback is valued and extremely important to us.

Thank you for your time.

Pre-Installation

	<p data-bbox="760 1041 1073 1094">⚠ WARNING</p> <p data-bbox="634 1108 1187 1297">Carefully read and follow all safety requirements and precautions contained in this manual and the machine-specific installation manual. Failure to follow safety instructions may lead to equipment damage, personal injury, or death.</p>
---	--

Before any components of the AutoBoom system are installed, activated, or operated, and at the beginning of each season Raven Industries recommends performing the following steps to ensure the machine will function with the AutoBoom system.

1. Ensure the machine's hydraulic filters have been changed and there are no problems with any components of the machine's hydraulic system:
 - Hydraulic pump issues
 - Faulty hydraulic motors
 - Other issues that may leave fine metal deposits in the circuits
2. Operate each of the machine's boom hydraulic functions three times to ensure the machine's valve has fresh oil and any debris has been flushed through the system's hoses, valves, and filters.
 - Tilt
 - Fold
 - Center rack control
 - Tongue extension
 - Any other functions operated by the machine's hydraulic valves

Wiring Connections

	<p>⚠ CAUTION</p> <p>Always connect the power cable as the last step in the wiring process and verify that the power leads are connected with the correct polarity. Reversing power leads can cause severe damage to the equipment.</p>
---	---

For wiring connections made outside the cab, apply dielectric silicone grease (P/N 222-0000-006) generously on both the male and female ends of the connectors. Application of the grease will prevent corrosion to the pins and wires.

The PowerGlide Plus AutoBoom system uses gauge wheels to maintain optimum boom height, while state-of-the-art hydraulics maintain constant hydraulic pressure to the tilt cylinders. PowerGlide Plus systems are typically used in pre-emergence applications.

Note: *Terrain conditions and the machine's hydraulic system dictate the actual speeds that can be achieved during application with an engaged AutoBoom system. Typically, rougher and varied field terrain require slower speeds while AutoBoom is enabled.*

PowerGlide Plus Kit Contents

In addition to the kit components listed below, one of the following harness cables is required for installation of the ISO AutoBoom system:

Machine Description	Part Number
Pull-type sprayer without ISO product control	115-0171-974
	115-0171-988
	115-0171-989
	115-0171-975
	115-0171-990
Pull-type sprayer with Raven or John Deere product control	115-0171-931
	115-0171-932
	115-0171-933
	115-0171-960
	115-0171-961
Sprayer with John Deere product control	115-0171-991

The components in the following tables are required for installation of the ISO AutoBoom system. Locate the type of sprayer the system is being installed on for the list of components applicable to the machine. System drawings for these components are located in Chapter 6, *System Diagrams*.

TABLE 1. Pull-Type Sprayer (P/N 117-0137-037)

Item Description	Part Number	Qty.
Manual - ISO AutoBoom Installation & Operation	016-0130-065	1
Node - ISO AutoBoom CAN Control	063-0130-016	1
Terminator - ISO	063-0172-964	1
Cable - Raven ISO to Passive Terminator	115-0171-963	1
Cable - AutoBoom Node/Valve	115-0230-085	1

TABLE 2. AGCO Self-Propelled RoGator with GTA (P/N 117-0137-039)

Item Description	Part Number	Qty.
Manual - ISO AutoBoom Installation & Operation	016-0130-065	1
Node - ISO AutoBoom CAN Control	063-0130-016	1
Cable - Falcon II RoGator PowerGlide Plus/ UltraGlide ISO CAN Control Node	115-2001-041	1

TABLE 3. John Deere 4630, 4730, 4830 (MY 2008+), 4920, 4930 (P/N 117-0137-038)

Item Description	Part Number	Qty.
Manual - ISO AutoBoom Installation & Operation	016-0130-065	1
Node - ISO AutoBoom CAN Control	063-0130-016	1
Cable - ISO CAN Bus Terminator Adapter	115-0230-024	1
Cable - JD SP Power Harness ISO CAN AutoBoom	115-0230-025	1
Cable - JD SP Valve Connection ISO CAN AutoBoom	115-0230-026	1

TABLE 4. John Deere 4720 and 4830 (2007) (P/N 117-0137-050)

Item Description	Part Number	Qty.
Manual - ISO AutoBoom Installation & Operation	016-0130-065	1
Node - ISO AutoBoom CAN Control	063-0130-016	1
Cable - ISO CAN Bus Terminator Adapter	115-0230-024	1
Cable - JD SP Power Harness ISO CAN AutoBoom	115-0230-025	1
Cable - JD SP Valve Connection ISO CAN AutoBoom	115-0230-053	1

TABLE 5. John Deere 4700 & 4710 with Green Star 2 or Newer (P/N 117-0137-052)

Item Description	Part Number	Qty.
Manual - ISO AutoBoom Installation & Operation	016-0130-065	1
Node - ISO AutoBoom CAN Control	063-0130-016	1
Cable - ISO CAN Bus Terminator Adapter	115-0230-024	1
Cable - JD SP Power Harness ISO CAN AutoBoom	115-0230-025	1
Cable - JD SP Valve Connection ISO CAN AutoBoom	115-0230-044	1



Install the ISO AutoBoom Wiring

Install the AutoBoom Node

FIGURE 1. AutoBoom Node Installed



1. Refer to the machine-specific Raven AutoBoom Installation Manual to mount the AutoBoom node in the appropriate location.

Note: Position the node so that the cable connections face down.

Note: Installation manuals can be found on the Internet at www.ravenhelp.com.

2. Insert the large, rectangular node connectors on the harness cable into the correct ports of the AutoBoom node.
3. Tighten the bolts on the node connectors to secure the connections.

Connect the Harness to the Boom Function Controls

FIGURE 2. AutoBoom Valve




1. Locate the Left Press and Right Press connectors on the AutoBoom harness cable.
2. Route the connectors to the AutoBoom valve.

3. Connect the Left Press connector to Port G1 on the AutoBoom valve.
4. Connect the Right Press connector to Port G4 on the AutoBoom valve.
5. Locate the Left Solenoid and Right Solenoid connectors on the harness cable.
6. Connect the Left Solenoid connector to Port 4A on the AutoBoom valve.
7. Connect the Right Solenoid connector to Port 4B on the AutoBoom valve.
8. Locate the Left Prop and Right Prop connectors on the harness cable.
9. Connect the Left Prop connector to Port 5A on the AutoBoom valve.
10. Connect the Right Prop connector to Port 13A on the AutoBoom valve.
11. Follow the instructions in the machine-specific AutoBoom Installation Manual to connect the boom sense adapter cables to the machine's coils.

Note: *If boom sense adapter cables were not provided in the machine-specific AutoBoom kit, follow the instructions in the following section to connect the boom sense functions to the AutoBoom system.*

Connect the Boom Sense Functions via Scotch Lock Splice Connectors (If Applicable)

FIGURE 3. Machine's Boom Function Coils



1. Locate the machine's boom function coils near the machine's hydraulic valve.
2. Locate the left tilt up coil.
3. Determine which wire feeding into the coil receives the signal from the switches in the cab by pressing the switch and using a test light or multi-meter to detect +12 volts.
4. Locate the Left Solenoid Sense Up connector on the AutoBoom harness cable.
5. Use a 16-18 gauge scotch lock parallel splice connector (P/N 405-2001-079) to connect the left tilt up coil wire to the Left Solenoid Sense Up connector.
6. Locate the left tilt down coil.
7. Determine which wire feeding into the coil receives the signal from the switches in the cab by pressing the switch and using a test light or multi-meter to detect +12 volts.
8. Locate the Left Solenoid Sense Down connector on the AutoBoom harness cable.
9. Use a 16-18 gauge scotch lock parallel splice connector (P/N 405-2001-079) to connect the left tilt down coil wire to the Left Solenoid Sense Down connector.
10. Repeat the steps above to connect the right tilt up and down coils to the Right Solenoid Sense Up and Down connectors on the AutoBoom harness cable.

Install the Power Leads

1. Locate the power cable that has the red and white power leads at one end.
2. Disconnect the machine's connectors from the battery terminals.
3. Install the red power lead on the positive battery terminal and reinstall the machine's battery connector.
4. Install the white power lead on the negative battery terminal and reinstall the machine's battery connector.

Connect the Harness Cable to the Power Cable

Pull-Type Sprayers with Standalone AutoBoom System (No ISO Product Control)

Item Description	Part Number
Cable - 12' ISO Hitch to Raven ECU	115-0171-974
Cable - 36' ISO Hitch to Raven ECU	115-0171-975
Cable - 14' ISO Hitch to Raven ECU	115-0171-988
Cable - 22' ISO Hitch to Raven ECU	115-0171-989
Cable - 45' ISO Hitch to Raven ECU	115-0171-990

Pull-Type Sprayers with Raven ISO Product Control

Item Description	Part Number
Cable - 12' ISO Extension Tee	115-0171-931
Cable - 24' ISO Extension Tee	115-0171-932
Cable - 36' ISO Extension Tee	115-0171-933
Cable - 12" ISO Extension Tee	115-0171-960
Cable - 6' ISO Extension Tee	115-0171-961

1. Connect the harness cable POWER connector to the Power/CAN cable or the ISO Hitch to Raven ECU cable.
2. Route the installed AutoBoom harness cable and the implement's tee cable (if equipped) toward the machine's cab, looping and tying-off any excess cable.
3. **Pull-Type Sprayers with John Deere Product Control Only** - Connect the John Deere to Raven ISO adapter (P/N 115-0171-991) to the ISO implement extension tee cable.

Connect the Harness Cable to the Machine

AGCO Machines

FIGURE 4. AGCO Machine Power Connection



1. Locate and remove the terminator by the right side of the tank in front of the catwalk.
2. Connect the AutoBoom harness cable to the machine's power connector.
3. Install a terminator on the AutoBoom harness cable CAN connector.

John Deere 4630

1. Remove the fuse panel cover in the left-rear corner of the machine.

FIGURE 5. Passive Terminator



Note: The passive terminator has four wires feeding into the connector.

2. Locate and remove the passive terminator.
3. Connect the AutoBoom harness cable CAN connector to the open connection.
4. Install the terminator on the Raven adapter.
5. Install the Raven adapter in the open connection at the back of the machine.

John Deere 4700 and 4710

FIGURE 6. Terminator Location



1. Remove the molding securing the padded roof headliner from the right side of the cab.

FIGURE 7. Terminator Removed from Harness Cable



2. Pull the headliner down to locate the terminator in the corner of the cab.
3. Unbolt and remove the terminator from the machine's harness cable.

FIGURE 8. Post Cover Removed




4. Remove the right corner post cover.

FIGURE 9. Cover Removed



5. Remove the cover under the dash panel.

FIGURE 10. AutoBoom Harness Routed into the Machine's Cab



6. Route the AutoBoom harness cable into the cab via the cut-out on the rear window or by removing the screws from the outside panel below the window.

Note: *The panel will have to be pried out slightly to route the harness cable into the cab.*

FIGURE 11. AutoBoom Harness Cable Connected



7. Route the AutoBoom harness cable under the dash panel and up the corner post.
8. Connect the AutoBoom harness cable to the machine's harness cable.

FIGURE 12. Post Cover Reinstalled Over the AutoBoom Harness Cable



9. Reinstall the headliner moldings and post and dash covers.
10. Install the terminator that was removed from the corner of the cab to the CAN connector on the AutoBoom harness cable.

John Deere 4710 (Model Year 2004), 4720, and 4830 (Model Year 2007)**FIGURE 13. CAN Connection Location**

1. Feed the AutoBoom harness cable through the hole in the top-right corner of the cab.
2. Unplug the machine's harness cable and connect the AutoBoom harness cable to the connection.
3. Install the terminator on the AutoBoom harness cable CAN connector connected to the node.

Note: John Deere model 4720 machines may have the passive terminator under the cab roof, behind the seat (similar to the 4730 model machine on page 18), or behind the instrument panel on the right side of the machine.

FIGURE 14. Power Connected

4. Plug logic power into the John Deere power strip located in the lower-right corner of the cab.

John Deere 4730 and 4830 (Model Year 2008 and Newer)

FIGURE 15. John Deere 4730



1. Remove the access plug at the left rear corner of the cab.
2. Remove the rear cab pad behind the operator's seat.
3. Feed the AutoBoom harness cable through the access plug hole.
4. Remove the terminator from the machine's power connection.
5. Connect the AutoBoom harness cable into the machine's power connection.

FIGURE 16. Terminator Installed



6. Install the previously removed terminator on the AutoBoom harness cable CAN connector connected to the node.

FIGURE 17. Power Connected



7. Plug logic power into the John Deere power strip located in the lower-right corner of the cab.

John Deere 4920 and 4930

FIGURE 18. Terminator Location



1. On the right side of the machine under the spray tank, locate and remove the terminator on the sprayer's harness cable.
2. Connect the machine's harness cable to the AutoBoom harness CAN connector.
3. Install the terminator on the cable connected to the AutoBoom node.

Pull-Type Sprayers with John Deere Rate Control

FIGURE 19. John Deere CAN Connection



1. Locate the John Deere product control ECU by tracing the cable from the ISO connection on the back of the tractor, toward the sprayer.
2. Remove the caps and terminator from the cable connected to the ECU and plug the connections into the John Deere ISO to Raven ISO adapter cable (P/N 115-0171-991).
3. Connect the terminator to the Raven ISO to passive terminator cable (P/N 115-0171-963).
4. Connect the Raven ISO to passive terminator cable to the open end of the implement's ISO extension tee cable.

Pull-Type Sprayer with Standard Rate Control

FIGURE 20. Tractor Connection



1. Plug the tractor hitch to Raven ECU cable into the back of the tractor.
2. Install the Raven ISO to passive terminator cable (P/N 115-0171-963) on the unlabeled end of the tractor hitch to Raven ECU cable.
3. Install the terminator on the remaining end of the Raven ISO to active terminator cable.

PowerGlide Plus Routine Operation

The PowerGlide Plus AutoBoom system uses gauge wheels to maintain optimum boom height, while state-of-the-art hydraulics maintain constant hydraulic pressure to the tilt cylinders. PowerGlide Plus systems are typically used in pre-emergence applications.


Note: *Terrain conditions and the machine's hydraulic system dictate the actual speeds that can be achieved during application with an engaged AutoBoom system. Typically, rougher and varied field terrain require slower speeds while AutoBoom is enabled.*

Note: *The VT must be instance 0 to be compatible with Raven ISO products.*

AutoBoom Icons


Once the AutoBoom node has been installed, the AutoBoom icons will be displayed on the Start-up screen, indicating the AutoBoom node has been detected.

FIGURE 21. Implement Detected



Refer to the icon definitions below when configuring the AutoBoom feature on the ISO terminal.


FIGURE 22. AutoBoom Home Screen



1. When the PowerGlide+ field is checked, the AutoBoom system is in PowerGlide Plus mode.
2. Select the Information icon to access the Node Information screen.
3. The Master Switch icon is used to turn the AutoBoom system off and on.
4. Use the + and - icons to increase or decrease the displayed value.
5. Select the CAL icon to access the Calibration screen.
6. Select the Setup icon to access the setup tools and diagnostics.

Setup Tools

The setup tools allow fine-tuning of minimum boom pressure and center sensor height parameters in the AutoBoom system. To access these tools, select the Setup icon. The following screen will appear:



To adjust any of the ISO AutoBoom setup values, highlight the value and use the + and - icons. To return to the AutoBoom home screen, select the Home icon.

- **Min Pressure %** - Sets a low limit pressure, preventing the boom pressure from falling below a percentage of static pressure and overriding the control when necessary to maintain a low limit of


pressure on each boom. Minimum Pressure% also prevents the booms from resting on the stops for travel-limited booms.

- **PWM Frequency** - Sets the frequency of the PWM signal to the proportional control valve. The default valve value of 60 Hz is recommended with AutoBoom valves with square coils and 250 Hz for valves with round coils.
- **Center Rack Control** - Turns the center rack control on and off. Selecting Center Rack Control ON allows center rack control to be enabled on the field computer/console or the machine's switch. If Center Rack Control OFF is selected, center rack control cannot be used.

Note: Center rack control should only be turned on if the machine is equipped with a center rack sensor and the appropriate cabling that allow center rack control.

Diagnostic Tools


Integrated diagnostic tools allow the status of all AutoBoom inputs and outputs to be viewed on the ISO terminal display. To access the diagnostic tools, select the Diagnostics icon. The following screen will appear:



- **Raise and Lower Buttons** - Indicate the status of the boom switches. When using the machine's manual control functions, the corresponding boom switch will indicate On. These buttons can also be used to troubleshoot wiring or hydraulic issues by using the AutoBoom valve for raise/lower functions and by using the machine's hydraulic valve for center rack functions (if the machine is equipped with center rack control cabling).
- **Pressure, Outer Ht, Mid Ht, Inner Ht, and Center Ht** - Indicate the status of the corresponding sensors.
- **Blocker** - Indicates the status of the double-blocker output. Blocker will indicate On when individual booms are engaged or calibrating.
- **PWM%** - Indicates the duty cycle to the proportional valves. This value will be 0 if the individual booms are disengaged, and will vary in output up to 100 when AutoBoom is engaged and the system is operating.
- **Base PWM%** - Indicates the system's calculated static duty cycle to maintain the set height or pressure. This number will typically change slowly from 0 - 5 points during routine operation.


Alarms

Alarm tones will not sound if the operator is navigating through any of the configuration menus. However, the enable/disable alarms will always sound when appropriate.



- **Low pressure alarms** - When the pressure in the left or right tilt cylinders is low, the low pressure alarm will sound. The alarm is a steady tone, and will stop immediately after pressure is restored to the system.
- **Pressure sensor failure alarms** - The pressure sensor failure alarm occurs immediately when a pressure sensor is not detected. The alarm is a steady tone, and will stop immediately after the sensor is located.

FIGURE 23. Low HC Power



- **Low HC Power** - This alarm occurs when the voltage to the node drops below 12 volts. This alarm is a steady tone, and stops immediately when proper voltage is restored to the node.

FIGURE 24. Incorrect Node Prompt




- **Incorrect Node Prompt** - This prompt appears if an incorrect ECU is connected to the system. Ensure the ISO AutoBoom ECU is installed.
- **Other tones** - When enabling the AutoBoom system in automatic mode via the machine's boom control functions or switches, a single beep will occur. When disabling AutoBoom, a double beep will sound.

AutoBoom Pre-Calibration Diagnostics


While every effort has been made to properly label and document connections for the hydraulic and electrical components of the AutoBoom system, boom function connections may not be identified due to changes in the make and model of the machine. This makes it especially important to trace the hoses from the connection points and verify the electrical connections are correct to ensure proper AutoBoom system operation. In order to verify connections, it is necessary to perform a pre-calibration diagnostic test.

1. Select Setup icon.
2. Select Diagnostics icon. The following screen will appear:



3. Verify that the following components on the ISO terminal screen are displayed correctly and change when raising and lowering the booms via the machine's controls and the AutoBoom manual functions:
 - Pressures
 - Sensor heights
 - Right and left raise/lower functions
 - Center raise/lower functions
 - Fold/unfold functions
 - Manual raise and lower buttons

- Use the right arrow to toggle to the second AutoBoom Diagnostics screen. The following screen will appear




Calibration

After the AutoBoom installation is complete, it is necessary to calibrate the AutoBoom system before use. AutoBoom calibration requires pressure in the machine's cylinders and enough boom travel to allow the system to find the system base duty cycles for operation. Booms must be free to travel 10" up or down without reaching the tops or bottoms of the cylinder stops.

During calibration and operation, it is important to keep the machine running at a sufficient engine RPM so that the hydraulic pump is able to supply a full flow to the hydraulic system.

Note: *If the machine has an open center hydraulic system, or the type of hydraulic system is unknown, all calibration procedures should be performed with the machine operating at the normal operating engine RPM.*

- Touch the AutoBoom icon on the screen to display the AutoBoom main control screen.




- Select **PowerGlide Plus** from the Mode section in the upper-right corner of the screen.
- Verify that AutoBoom is turned on.

- Verify that the booms are unfolded, and lower the center rack so that the wheels are approximately six inches from the ground.


Note: *If the booms do not go over center or are travel-limited, raise the booms so that the tips are approximately ten inches above the horizontal position and lower the center section slightly below the normal spraying height. Verify the wheels are still approximately six inches above the ground.*

- Select **CAL**. The following screen will appear:



- Select **Cal L/R**.

Note: *The calibration process may take several seconds to complete. "Calibrating" will flash, indicating that calibration is in progress. Once the boom calibration is complete, the Cal L/R icon will disappear and the following screen will appear:*



- Select the **Home** icon to return to the AutoBoom main control screen.

Center Rack Control Calibration (If Equipped)

There are many different valve configurations used to control the machine's center rack functions. The AutoBoom system must "learn" which of the machine's solenoids are used to raise and lower the booms. Complete the following steps to calibrate the center rack control feature after the individual booms have been calibrated.

1. Press and hold the center rack raise button on the machine's control panel or joystick for six seconds so that the center rack raises.

Note: *The center rack may reach the upper limit of travel during this time, but continue holding the button until the full six seconds has passed.*

2. Press and hold the center rack lower button on the machine's control panel or joystick for six seconds so that the center rack lowers.

Note: *The center rack may reach the lower limit of travel during this time, but continue holding the button until the full six seconds has passed.*

Routine Operation

Joystick Functions

- When AutoBoom control is on, control of each boom can be enabled or disabled via the ISO terminal or by tapping the sprayer's switch functions (if equipped).


Note: *Pressing the down function for longer than 1/2 a second will switch the function to manual control. The operator must tap the down function to enable Autoboom.*

- A single up-tap on the sprayer's switch functions disables AutoBoom on that boom.
- A single down-tap on the sprayer's switch functions enables AutoBoom on that boom.
- The fast-down feature (double-tap down) is used to quickly lower the booms when the pressure setting is set to a higher setting, which causes the booms to lower slowly. The fast-up feature (double-tap up) is used to slightly raise one boom.
 - On machines with one proportional valve (square coils on the AutoBoom valve), a double-tap up on either boom switch will raise both booms slightly. A double-tap down on either boom switch will lower both booms quickly, and AutoBoom will re-engage to the set pressure setting.
 - On machines with two proportional valves (round coils on the AutoBoom valve), a double-tap up on the inside boom will raise only that boom slightly. A double-tap down will lower the inside boom quickly, and AutoBoom will re-engage to the set pressure setting.

Enabling AutoBoom via the ISO Terminal




1. Touch the AutoBoom icon on the ISO terminal screen.



2. Select **AutoBoom ON** in the upper-right corner of the screen.

Note: The AutoBoom system is now powered on, but is not yet enabled.



3. Select the **Left** and **Right** icons to enable the booms.

Note: The booms can be disabled by deselecting the Left and Right icons, selecting the toggle switch icon in the upper right corner, or by performing a machine tilt up function.

Boom Adjustments When Approaching Headlands

When approaching the headlands to make a turn, the inside gauge wheel must be raised approximately six inches from the ground to prevent it from sliding sideways or backward, causing damage to the gauge wheel assembly. The fast-up feature may be used to raise the inside wheel in this situation.

Center Rack Control (AutoBoom Enabled and Center Rack Control On) - If Equipped

Note: The machine may require the activation of a boom valve and/or master spray switch for the center rack control feature to engage.

Note: Consecutive up-taps or down-taps must be performed within 1.5 seconds of each other.

Note: Return to height and return to transport heights are measurements relative to the crop canopy, not necessarily ground level.

- **Center Down Switch** - A single down-tap will lower the center rack to the desired spray height, enable the center rack, and enable both booms.
- **Center Up Switch** - A single up-tap will disable the center rack and both booms. Two consecutive up-taps will raise the center rack to the desired transport height (if set). Four consecutive up-taps will raise the center rack to the maximum height, turn AutoBoom off, and preserve the new transport height as the maximum height.
 - Set a lower transport height - While the center rack is returning to transport, down-tap once on the center switch when the new transport height is reached.
 - Set the transport height to the maximum height - With the center rack positioned higher than the current transport height and with AutoBoom not currently returning to the transport height, up-tap twice on the center switch to move the center rack to the maximum height.

Center Rack Control (AutoBoom Enabled and Center Rack Control Off) - If Equipped

Note: *The machine may require the activation of a boom valve and/or master spray switch for the center rack control feature to engage.*

Note: *Consecutive up-taps or down-taps must be performed within 1.5 seconds of each other.*

Note: *Return to height and return to transport heights are measurements relative to the crop canopy, not necessarily ground level.*

- **Center Down Switch** - Two consecutive down-taps will lower the center rack to the desired spray height and enable both booms.


Note: *Center rack control will not be enabled since center rack control is off.*

- **Center Up Switch** - Two consecutive up-taps will disable both booms and raise the center rack to the desired transport height. Four consecutive up-taps will raise the center rack to the maximum height and turn AutoBoom off, preserving the new transport position as the maximum height.
 - Set a lower transport height - While the center rack is returning to transport, down-tap once on the center switch when the new transport height is reached.
 - Set the transport height to the maximum height - With the center rack positioned higher than the current transport height and with the AutoBoom not currently returning to the transport height, up-tap twice on the center switch to move the center rack to the maximum height.

System Adjustments

During the calibration process, the AutoBoom system calculates a default Pressure Setting. Normally, the calculated value will be the level at which the machine should operate. However, at times an adjustment to the Pressure Setting may be necessary.

Note: *During routine operation, the gauge wheels should touch down momentarily, raise slightly, then lower back to the target height. Wheels should not continuously ride on the ground.*



1. From the AutoBoom home screen, locate the Left Press Set and Right Press Set icons.
2. Verify that AutoBoom is turned on, then select **Enable Left** or **Enable Right**, or tap the left and right boom down buttons on the joystick.
3. Exit the cab and physically lift the end of each boom up, watching the responsiveness of the booms.


Note: The force required by the operator to lift the boom should never exceed 200 lbs.

4. Adjust the Pressure Setting of each boom as needed to optimize performance by highlighting the pressure set icon and using the + and - icons to adjust the setting.
 - Increasing the Pressure Setting makes the boom lighter and reduces down speed.
 - Decreasing the Pressure Setting makes the boom heavier and increases the down speed.
5. Select **Disable Left** or **Disable Right**, or tap the left and right boom up buttons on the joystick.
6. Select **OK**.


Resetting Defaults

Although it is not normally necessary, there may be circumstances under which it may be necessary to reset the system defaults. Resetting the defaults erases all AutoBoom system settings and adjustments that have been performed. System calibration will be required after the defaults have been reset.


1. Select the CAL icon on the AutoBoom home screen. The following screen will appear:



2. Select the Reset icon. The following screen will appear:



3. Select **Cal L/R** to calibrate. The following screen will appear:



The UltraGlide AutoBoom system uses ultrasonic sensors to measure the boom's height above ground, and state-of-the-art hydraulics to maintain constant hydraulic pressure to the tilt cylinders. The UltraGlide AutoBoom system is ideal for use in pre-emergence and post-emergence applications.

Note: *Terrain conditions and the machine's hydraulic system dictate the actual speeds that can be achieved during application with an engaged AutoBoom system. Typically, rougher and varied field terrain require slower speeds while AutoBoom is engaged.*

UltraGlide Kit Contents

In addition to the kit components listed below, one of the following harness cables is required for installation of the ISO AutoBoom system:

Machine Description	Part Number
Pull-type sprayer without ISO product control	115-0171-974
	115-0171-988
	115-0171-989
	115-0171-975
	115-0171-990
Pull-type sprayer with Raven or John Deere product control	115-0171-931
	115-0171-932
	115-0171-933
	115-0171-960
	115-0171-961
Sprayer with John Deere product control	115-0171-991

The components in the following tables are required for installation of the ISO AutoBoom system. Locate the type of sprayer the system is being installed on for the list of components applicable to the machine.

TABLE 1. Pull-Type Sprayer (P/N 117-0137-041)

Item Description	Part Number	Qty.
Manual - ISO AutoBoom Installation & Operation	016-0130-065	1
Node - ISO AutoBoom CAN Control	063-0130-016	1
Terminator - ISO	063-0172-964	1
Cable - 70' Ultrasonic Sensor Extension	115-0171-527	2
Cable - Raven ISO to Passive Terminator	115-0171-963	1
Cable - AutoBoom Node/Valve	115-0230-085	1

TABLE 2. John Deere 4700/4710 with GS2 or Newer (P/N 117-0137-053)

Item Description	Part Number	Qty.
Manual - ISO AutoBoom Installation & Operation	016-0130-065	1
Node - ISO AutoBoom CAN Control	063-0130-016	1
Cable - 60' Ultrasonic Sensor Extension	115-0230-051	2
Cable - ISO Can Bus Terminator Adapter	115-0230-024	1
Cable - JD SP Power Harness ISO AutoBoom	115-0230-025	1
Cable - JD SP Valve Connection ISO AutoBoom	115-0230-053	1

TABLE 3. AGCO Self-Propelled with GTA (P/N 117-0137-043)

Item Description	Part Number	Qty.
Manual - ISO AutoBoom Installation & Operation	016-0130-065	1
Node - ISO AutoBoom CAN Control	063-0130-016	1

TABLE 3. AGCO Self-Propelled with GTA (P/N 117-0137-043)

Item Description	Part Number	Qty.
Cable - 70' Ultrasonic Sensor Extension	115-0171-527	2
Cable - Falcon II Rogator PowerGlide Plus/ UltraGlide ISO CAN Control Node	115-2001-041	1

TABLE 4. John Deere 4720 and 4830 (2007) (P/N 117-0137-051)

Item Description	Part Number	Qty.
Manual - ISO AutoBoom Installation & Operation	016-0130-065	1
Node - ISO AutoBoom CAN Control	063-0130-016	1
Cable - 40' Ultrasonic Sensor Extension	115-0171-602	2
Cable - ISO Can Bus Terminator Adapter	115-0203-024	1
Cable - JD SP Power Harness ISO CAN AutoBoom	115-0230-025	1
Cable - JD SP Valve Connection ISO CAN AutoBoom	115-0230-044	1

TABLE 5. John Deere 4630, 4730, 4830 (Model Year 2008+), 4920 & 4930 (P/N 117-0137-042)

Item Description	Part Number	Qty.
Manual - ISO AutoBoom Installation & Operation	016-0130-065	1
Node - ISO AutoBoom CAN Control	063-0130-016	1
Cable - 70' Ultrasonic Sensor Extension	115-0171-527	2
Cable - ISO Can Bus Terminator Adapter	115-0203-024	1
Cable - JD SP Power Harness ISO CAN AutoBoom	115-0230-025	1
Cable - JD SP Valve Connection ISO CAN AutoBoom	115-0230-026	1

Install the ISO AutoBoom Wiring

Install the AutoBoom Node

FIGURE 1. AutoBoom Node Installed



1. Refer to the machine-specific Raven AutoBoom Installation Manual to mount the AutoBoom node in the appropriate location.

Note: Position the node so that the cable connections face down.

Note: Installation manuals can be found on the Internet at www.ravenhelp.com.

2. Insert the large, rectangular node connectors on the harness cable into the correct ports of the AutoBoom node.
3. Tighten the bolts on the node connectors to secure the connections.

Connect the Harness to the Boom Function Controls

FIGURE 2. AutoBoom Valve




1. Locate the Left Press and Right Press connectors on the AutoBoom harness cable.
2. Route the connectors to the AutoBoom valve.

3. Connect the Left Press connector to Port G1 on the AutoBoom valve.
4. Connect the Right Press connector to Port G4 on the AutoBoom valve.
5. Locate the Left Solenoid and Right Solenoid connectors on the harness cable.
6. Connect the Left Solenoid connector to Port 4A on the AutoBoom valve.
7. Connect the Right Solenoid connector to Port 4B on the AutoBoom valve.
8. Locate the Left Prop and Right Prop connectors on the harness cable.
9. Connect the Left Prop connector to Port 5A on the AutoBoom valve.
10. Connect the Right Prop connector to Port 13A on the AutoBoom valve.
11. Follow the instructions in the machine-specific AutoBoom Installation Manual to connect the boom sense adapter cables to the machine's coils.

Note: *If boom sense adapter cables were not provided in the machine-specific AutoBoom kit, follow the instructions in the following section to connect the boom sense functions to the AutoBoom system.*

Connect the Boom Sense Functions via Scotch Lock Splice Connectors (If Applicable)

FIGURE 3. Machine's Boom Function Coils



1. Locate the machine's boom function coils near the machine's hydraulic valve.
2. Locate the left tilt up coil.
3. Determine which wire feeding into the coil receives the signal from the switches in the cab by pressing the switch and using a test light or multi-meter to detect +12 volts.
4. Locate the Left Solenoid Sense Up connector on the AutoBoom harness cable.
5. Use a 16-18 gauge scotch lock parallel splice connector (P/N 405-2001-079) to connect the left tilt up coil wire to the Left Solenoid Sense Up connector.
6. Locate the left tilt down coil.
7. Determine which wire feeding into the coil receives the signal from the switches in the cab by pressing the switch and using a test light or multi-meter to detect +12 volts.
8. Locate the Left Solenoid Sense Down connector on the AutoBoom harness cable.
9. Use a 16-18 gauge scotch lock parallel splice connector (P/N 405-2001-079) to connect the left tilt down coil wire to the Left Solenoid Sense Down connector.
10. Repeat the steps above to connect the right tilt up and down coils to the Right Solenoid Sense Up and Down connectors on the AutoBoom harness cable.

Install the Power Leads

1. Locate the power cable that has the red and white power leads at one end.
2. Disconnect the machine's connectors from the battery terminals.
3. Install the red power lead on the positive battery terminal and reinstall the machine's battery connector.
4. Install the white power lead on the negative battery terminal and reinstall the machine's battery connector.

Connect the Harness Cable to the Power Cable

Pull-Type Sprayers with Standalone AutoBoom System (No ISO Product Control)

Item Description	Part Number
Cable - 12' ISO Hitch to Raven ECU	115-0171-974
Cable - 36' ISO Hitch to Raven ECU	115-0171-975
Cable - 14' ISO Hitch to Raven ECU	115-0171-988
Cable - 22' ISO Hitch to Raven ECU	115-0171-989
Cable - 45' ISO Hitch to Raven ECU	115-0171-990

Pull-Type Sprayers with Raven ISO Product Control

Item Description	Part Number
Cable - 12' ISO Extension Tee	115-0171-931
Cable - 24' ISO Extension Tee	115-0171-932
Cable - 36' ISO Extension Tee	115-0171-933
Cable - 12" ISO Extension Tee	115-0171-960
Cable - 6' ISO Extension Tee	115-0171-961

1. Connect the harness cable POWER connector to the Power/CAN cable or the ISO Hitch to Raven ECU cable.
2. Route the installed AutoBoom harness cable and the implement's tee cable (if equipped) toward the machine's cab, looping and tying-off any excess cable.
3. **Pull-Type Sprayers with John Deere Product Control Only** - Connect the John Deere to Raven ISO adapter (P/N 115-0171-991) to the ISO implement extension tee cable.

Connect the Harness Cable to the Machine

AGCO Machines

FIGURE 4. AGCO Machine Power Connection



1. Locate and remove the terminator by the right side of the tank in front of the catwalk.
2. Connect the AutoBoom harness cable to the machine's power connector.
3. Install a terminator on the AutoBoom harness cable CAN connector.

John Deere 4630

1. Remove the fuse panel cover in the left-rear corner of the machine.

FIGURE 5. Passive Terminator



Note: The passive terminator has four wires feeding into the connector.

2. Locate and remove the passive terminator.
3. Connect the AutoBoom harness cable CAN connector to the open connection.
4. Install the terminator on the Raven adapter.
5. Install the Raven adapter in the open connection at the back of the machine.

John Deere 4700 and 4710

FIGURE 6. Terminator Location



1. Remove the molding securing the padded roof headliner from the right side of the cab.

FIGURE 7. Terminator Removed from Harness Cable




2. Pull the headliner down to locate the terminator in the corner of the cab.
3. Unbolt and remove the terminator from the machine's harness cable.

FIGURE 8. Post Cover Removed

4. Remove the right corner post cover.

FIGURE 9. Cover Removed

5. Remove the cover under the dash panel.

FIGURE 10. AutoBoom Harness Routed into the Machine's Cab

6. Route the AutoBoom harness cable into the cab via the cut-out on the rear window or by removing the screws from the outside panel below the window.

Note: *The panel will have to be pried out slightly to route the harness cable into the cab.*

FIGURE 11. AutoBoom Harness Cable Connected



7. Route the AutoBoom harness cable under the dash panel and up the corner post.
8. Connect the AutoBoom harness cable to the machine's harness cable.

FIGURE 12. Post Cover Reinstalled Over the AutoBoom Harness Cable



9. Reinstall the headliner moldings and post and dash covers.
10. Install the terminator that was removed from the corner of the cab to the CAN connector on the AutoBoom harness cable.

John Deere 4710 (Model Year 2004), 4720, and 4830 (Model Year 2007)

FIGURE 13. CAN Connection Location



1. Feed the AutoBoom harness cable through the hole in the top-right corner of the cab.
2. Unplug the machine's harness cable and connect the AutoBoom harness cable to the connection.
3. Install the terminator on the AutoBoom harness cable CAN connector connected to the node.

Note: John Deere model 4720 machines may have the passive terminator under the cab roof, behind the seat (similar to the 4730 model machine on page 44), or behind the instrument panel on the right side of the machine.

FIGURE 14. Power Connected



4. Plug logic power into the John Deere power strip located in the lower-right corner of the cab.

John Deere 4730 and 4830 (Model Year 2008 and Newer)

FIGURE 15. John Deere 4730



1. Remove the access plug at the left rear corner of the cab.
2. Remove the rear cab pad behind the operator's seat.
3. Feed the AutoBoom harness cable through the access plug hole.
4. Remove the terminator from the machine's power connection.
5. Connect the AutoBoom harness cable into the machine's power connection.

FIGURE 16. Terminator Installed



6. Install the previously removed terminator on the AutoBoom harness cable CAN connector connected to the node.

FIGURE 17. Power Connected



7. Plug logic power into the John Deere power strip located in the lower-right corner of the cab.

John Deere 4920 and 4930

FIGURE 18. Terminator Location



1. On the right side of the machine under the spray tank, locate and remove the terminator on the sprayer's harness cable.
2. Connect the machine's harness cable to the AutoBoom harness CAN connector.
3. Install the terminator on the cable connected to the AutoBoom node.

Pull-Type Sprayers with John Deere Rate Control

FIGURE 19. John Deere CAN Connection



1. Locate the John Deere product control ECU by tracing the cable from the ISO connection on the back of the tractor, toward the sprayer.
2. Remove the caps and terminator from the cable connected to the ECU and plug the connections into the John Deere ISO to Raven ISO adapter cable (P/N 115-0171-991).
3. Connect the terminator to the Raven ISO to passive terminator cable (P/N 115-0171-963).
4. Connect the Raven ISO to passive terminator cable to the open end of the implement's ISO extension tee cable.

Pull-Type Sprayer with Standard Rate Control

FIGURE 20. Tractor Connection



1. Plug the tractor hitch to Raven ECU cable into the back of the tractor.
2. Install the Raven ISO to active terminator cable (P/N 115-0171-963) on the unlabeled end of the tractor hitch to Raven ECU cable.
3. Install the terminator on the remaining end of the Raven ISO to active terminator cable.

UltraGlide Routine Operation

The UltraGlide AutoBoom system uses ultrasonic sensors to measure the boom's height above ground, and state-of-the-art hydraulics to maintain constant hydraulic pressure to the tilt cylinders. The UltraGlide AutoBoom system is ideal for use in pre-emergence and post-emergence applications.


Note: Terrain conditions and the machine's hydraulic system dictate the actual speeds that can be achieved during application with an engaged AutoBoom system. Typically, rougher and varied field terrain require slower speeds while AutoBoom is enabled.

Note: The VT must be instance 0 to be compatible with Raven ISO products.

AutoBoom Icons


Once the AutoBoom node has been installed, the AutoBoom icons will be displayed on the Start-up screen, indicating the AutoBoom node has been detected.

FIGURE 21. Implement Detected



Refer to the icon definitions below when configuring the AutoBoom feature on the ISO terminal.


FIGURE 22. AutoBoom Home Screen



1. When the UltraGlide field is checked, the AutoBoom system is in UltraGlide mode.
2. Select the Information icon to access the Node Information screen.
3. The Master Switch icon is used to turn the AutoBoom system off and on.
4. Use the + and - icons to increase or decrease the displayed value.
5. Select the CAL icon to access the Calibration screen.
6. Select the Setup icon to access the setup tools and diagnostics.

Setup Tools

The setup tools allow fine-tuning of stability control, minimum boom pressure, and sensor height offset parameters in the AutoBoom system. To access these tools, select the Setup icon. The following screen will appear:



To adjust any of the ISO AutoBoom setup values, highlight the value and use the + and - icons. To return to the AutoBoom home screen, select the Home icon.

- **Height Offsets (Outer, Inner, and Center)** - Allows sensor heights to be adjusted according to the sensor mounting location. Enter a positive value if the sensors are mounted above the sprayer tips, and a negative value if the sensors are mounted below. Refer to the Sensor Height Offsets section on page 64 for more information.
- **Stability Factor** - Allows fine-tuning of the rigidity of the machine's center rack. The default value of 20 is recommended for machines with a rigid center rack. A value of 5 - 14 is recommended for machines with center racks that float freely. Adjust this value as needed to prevent boom oscillation.
 - Stability settings of 0 disable the stability control completely, making the left and right booms completely independent of each other. When above target, the control of both booms is accelerated to increase the down speed. This setting is useful for machines that have a rigid center rack.
 - Stability settings of 1 - 99 will adjust the stability of the center section. Lower numbers cause the opposing boom that is not being controlled to counteract the movement of the controlled boom by raising to balance or stabilize the center section and to prevent undesired rotation or movement. While lower numbers allow the booms to react at the same rate and time, low settings may prevent the booms from lowering. Higher stability settings allow the booms to react independently from each other, but may cause the center section to oscillate, diminishing performance.
- **Min Pressure %** - Sets a low limit pressure, preventing the boom pressure from falling below a percentage of static pressure, overriding the control when necessary to maintain a low limit of pressure on each boom. Minimum Pressure % also prevents the booms from resting on the stops for travel-limited booms.

- **PWM Frequency** - Sets the frequency of the PWM signal to the proportional control valve. The default valve value of 60 Hz is recommended with AutoBoom valves with square coils and 250 Hz for valves with round coils.
- **Slant PWM Freq** - Sets the frequency of the PWM signal to the XT proportional control valve. The default value is 250 Hz.
- **Outer Sensors (UltraGlide Only)** - Allows the operator to disable outer boom sensors if the machine is equipped with optional inside boom sensors. This feature is useful when the outer boom tips are folded in, and only the inside boom sensors are needed for control.

Note: The system must be re-calibrated if the outer sensors option is disabled, then re-enabled.

- **Center Rack Control** - Turns the center rack control on and off. Selecting Center Rack Control ON allows center rack control to be enabled on the field computer/console or the machine's switch. If Center Rack Control OFF is selected, center rack control cannot be used.

Note: Center rack control should only be turned on if the machine is equipped with a center rack sensor and the appropriate cabling that allow center rack control.

- **Slant** - Turns the slant feature on and off. The Slant PWM frequency will remain set at 250 whether slant is turned on or off.


FIGURE 23. Machine Selection Database Screen



- **Machine Selection Database** - Applicable to AutoBoom software versions 5.01.00 and greater. The machine selection database contains a list of machines that, when selected, automatically populates the ideal settings for that specific machine. If the specific machine is not listed, choose the profile that best fits the machine:
 - Standard0 - Generic profile suitable for most machines.
 - Standard100 - Generic profile for machines with heavy booms that require more pressure to lift the booms quickly. Select this profile if the static pressure required to hold the booms level is 1800 psi or greater.
 - Standard200 - Generic profile for machines with lighter booms that require less pressure to lower the booms at a faster rate. Select this profile if the static pressure required to hold the booms level is 900 psi or lower.


Diagnostic Tools

Integrated diagnostic tools allow the status of all AutoBoom inputs and outputs to be viewed on the ISO terminal display. To access the diagnostic tools, select the Diagnostics icon. The following screen will appear:



- **Raise and Lower Buttons** - Indicate the status of the boom switches. When using the machine's manual control functions, the corresponding boom switch will indicate On. These buttons can also be used to troubleshoot wiring or hydraulic issues by using the AutoBoom valve for raise/lower functions and by using the machine's hydraulic valve for center rack functions (if the machine is equipped with center rack control cabling).
- **Pressure, Outer Ht, Mid Ht, Inner Ht, and Center Ht** - Indicate the status of the corresponding sensors.
- **Roll Rate** - Displays the rate of roll measured by the rotary sensor. The roll rate is displayed as degrees per second.
- **Blocker** - Indicates the status of the double-blocker output. Blocker will indicate On when individual booms are engaged or calibrating.
- **PWM%** - Indicates the duty cycle to the proportional valves. This value will be 0 if the individual booms are disengaged, and will vary in output up to 100 when AutoBoom is engaged and the system is operating.
- **Base PWM%** - Indicates the system's calculated static duty cycle to maintain the set height or pressure. This number will typically change slowly from 0 - 5 points during routine operation.
- **Slant PWM%** - Indicates the duty cycle of the slant control proportional valves. This value will be 0 if the slant control is not enabled, and can vary in output up to 100 when slant control is engaged and operating. A minimum value will be maintained when the slant control system is enabled, and move slightly when the boom is re-centering.



To access page two of the Diagnostic tools, select the right arrow button. The following screen will appear:




- **Stats** - Reflects the boom performance. This value is for Raven use only.
- **Slnt PWM%** - Allows the operator to see the duty cycle value of the slant control proportional valves while rotating the boom with the Manual Slant Control icons.
- **Roll Rate** - Allows the operator to see the roll rate value when using the Manual Slant Control icons.
- **Deg** - Allows the operator to see the degrees of rotation while operating the manual slant control.
- **Manual Slant Control Icons** - Used to manually rotate the boom clockwise or counterclockwise relative to the machine's chassis and can be used to troubleshoot wiring or hydraulic issues.

Alarms


Alarm tones will not sound if the operator is navigating through any of the configuration menus. However, the enable/disable alarms will always sound when appropriate.




- **Low pressure alarms** - When the pressure in the left or right tilt cylinders is low, the low pressure alarm will sound. The alarm is a steady tone, and will stop immediately after pressure is restored to the system.
- **Pressure sensor failure alarms** - The pressure sensor failure alarm occurs immediately when a pressure sensor is not detected. The alarm is a steady tone, and will stop immediately after the sensor is located.



- **Ultrasonic sensor - too low alarm** - This alarm occurs if the ultrasonic sensor is closer than ten inches to the ground for 1/2 a second.




- **Ultrasonic sensor - too high alarm** - This alarm occurs when the ultrasonic sensor is higher than 65 inches from the ground for five seconds.



- **Ultrasonic sensor - failure alarm** - This alarm occurs immediately when an ultrasonic sensor is not detected. The alarm is a steady tone, and will stop immediately after the sensor is located.

FIGURE 24. Low HC Power



- **Low HC Power** - This alarm occurs when the voltage to the node drops below 12 volts. This alarm is a steady tone, and stops immediately when proper voltage is restored to the node.

FIGURE 25. Incorrect Node Prompt





- **Incorrect Node Prompt** - This prompt appears if an incorrect ECU is connected to the system. Ensure the ISO AutoBoom ECU is installed.
- **Other tones** - When enabling the AutoBoom system in automatic mode via the machine's boom control functions or switches, a single beep will occur. When disabling AutoBoom, a double beep will sound.

AutoBoom Pre-Calibration Diagnostics

While every effort has been made to properly label and document connections for the hydraulic and electrical components of the AutoBoom system, boom function connections may not be identified due to changes in the make and model of the machine. This makes it especially important to trace the hoses from the connection points and verify the electrical connections are correct to ensure proper AutoBoom system operation. In order to verify connections, it is necessary to perform a pre-calibration diagnostic test.

1. Select Setup icon.
2. Select Diagnostics icon. The following screen will appear:



3. Verify that the following components on the ISO terminal screen are displayed correctly and change when raising and lowering the booms via the machine's controls and the AutoBoom manual functions:
 - Pressures
 - Sensor heights

- Right and left raise/lower functions
- Center raise/lower functions
- Fold/unfold functions
- Manual raise and lower buttons

Calibration

After the AutoBoom installation is complete, it is necessary to calibrate the AutoBoom system before use. AutoBoom calibration requires pressure in the machine's cylinders and enough boom travel to allow the system to find the system base duty cycles for operation. Booms must be free to travel 10" up or down without reaching the tops or bottoms of the cylinder stops.


During calibration and operation, it is important to keep the machine running at a sufficient engine RPM so that the hydraulic pump is able to supply a full flow to the hydraulic system.

Note: *If the machine has an open center hydraulic system, or the type of hydraulic system is unknown, all calibration procedures should be performed with the machine operating at the normal operating engine RPM.*

Important: *Be sure that the area is clear of people and obstructions before beginning the calibration process.*

1. Move the machine to a flat area.
2. Verify that AutoBoom is turned on.
3. Verify that the booms are unfolded, and lower the center rack.

Note: *If the booms do not go over center or are travel limited, raise the booms so that the boom tips are approximately ten inches above the horizontal position and lower the center section to approximately 20 inches.*



4. Using a tape measure, measure the distance from the bottom of the sensor to the spray nozzle tip.
5. Access the AutoBoom Setup screen.
6. Adjust the vertical sensor height offset settings in the ISO terminal to sensor position as measured in step 4.
 - Positive offsets indicate the sensor surface is located above the nearest spray tips.
 - Negative offsets indicate the sensor surface is located below the nearest spray tips.


- Inner, outer, and center offsets are not required to be the same across the width of the machine, but they must be correctly measured relative to the spray tips.

Note: If the machine is equipped with a center sensor, the center rack height can be verified through the main menu or diagnostics screen in AutoBoom section of the ISO terminal.

7. Raise the boom tips to approximately the target height.


Note: The default target height is 30 inches. Verify that the booms are not fully raised to the boom stops. If gauge wheels are installed, the setting must be adjusted to 40 - 45 inches to prevent the wheels from touching the ground during the system calibration.

8. Touch the Home icon on the screen to display the AutoBoom home screen.




9. Select **UltraGlide** from the Mode section in the upper-left corner of the screen and turn AutoBoom on in the upper-right corner.

10. Select **CAL**. The following screen will appear:



11. Select the left boom calibration icon to begin the calibration of the left boom.

Note: The left boom will raise and then lower. This is a normal part of the calibration process. During the calibration process, the following screen will be displayed:




12. Repeat steps 9 - 10 above to calibrate the right boom. Once the right boom calibration process is complete, the following screen will appear:




13. Select the **Home** icon.

Slant Control Calibration




1. Verify the Slant Control feature is turned on in the Setup screen.

2. Select the CAL icon on the Home screen.



3. Enter the number of the direction arrow on the node that is pointing forward.
4. Select the right arrow icon to access the Calibration screen.



5. Select the Slant Calibration icon on the Calibration screen.

Note: The boom tips may raise automatically to allow for full rotation of the center section. Pressure in one slant cylinder will increase until the center section begins to rotate slightly. The center section will then rotate fully clockwise then counterclockwise to calibrate the center rotation sensor position.

Note: The center rotation sensor may be re-centered by recalibrating the slant control or by manual adjustment of the centering bolt while the center section is confirmed to be in the center position.

Center Rack Control Calibration

There are many different valve configurations used to control the machine's center rack functions. The AutoBoom system must "learn" which of the machine's solenoids are used to raise and lower the booms. Complete the following steps to calibrate the center rack control feature after the individual booms have been calibrated.

1. Press and hold the center rack raise button on the machine's control panel or joystick for six seconds so that the center rack raises.

Note: The center rack may reach the upper limit of travel during this time, but continue holding the button until the full six seconds has passed.

2. Press and hold the center rack lower button on the machine's control panel or joystick for six seconds so that the center rack lowers.

Note: The center rack may reach the lower limit of travel during this time, but continue holding the button until the full six seconds has passed.

Routine Operation

Joystick Functions

- When AutoBoom control is on, control of each boom can be enabled or disabled via the ISO terminal or by tapping the sprayer's switch functions (if equipped).



Note: Pressing the down function for longer than 1/2 a second will switch the function to manual control. The operator must tap the down function to enable Autoboom.

- A single up-tap on the sprayer's switch functions disables AutoBoom on that boom.
- A single down-tap on the sprayer's switch functions enables AutoBoom on that boom.

Enabling AutoBoom via the VT Display




1. Touch **AutoBoom** icon on the VT display screen.



2. Select **On** in the upper-right corner of the screen.

Note: The AutoBoom system is now powered on, but is not yet enabled.



3. Select the **Left** and **Right** icons to enable the booms.

Note: The booms can be disabled by deselecting the Left and Right icons, selecting the toggle switch icon in the upper right corner, or by performing a machine tilt up function.

Boom Adjustments When Approaching Headlands (If Equipped with Gauge Wheels)

When approaching the headlands to make a turn, the inner gauge wheel must be raised approximately six inches from the ground to prevent it from sliding sideways or backward, causing damage to the inner gauge wheel assembly.

Center Rack Control (AutoBoom Enabled and Center Rack Control On)

Note: The machine may require the activation of a boom valve and/or master spray switch for the center rack control feature to engage.

Note: Consecutive up-taps or down-taps must be performed within 1.5 seconds of each other.

Note: Return to height and return to transport heights are measurements relative to the crop canopy, not necessarily ground level.

- **Center Down Switch** - A single down-tap will lower the center rack to the desired spray height, enable the center rack, and enable both booms.
- **Center Up Switch** - A single up-tap will disable the center rack and both booms. Two consecutive up-taps will raise the center rack to the desired transport height. Four consecutive up-taps will raise the center rack to the maximum height, turn AutoBoom off, and preserve the new transport height as the maximum height.
 - Set a lower transport height - While the center rack is returning to transport, down-tap once on the center switch when the new transport height is reached.
 - Set the transport height to the maximum height - With the center rack positioned higher than the current transport height and with AutoBoom not currently returning to the transport height, up-tap twice on the center switch to move the center rack to the maximum height.

Center Rack Control (AutoBoom Enabled and Center Rack Control Off)

Note: The machine may require the activation of a boom valve and/or master spray switch for the center rack control feature to engage.

Note: Consecutive up-taps or down-taps must be performed within 1.5 seconds of each other.

Note: Return to height and return to transport heights are measurements relative to the crop canopy, not necessarily ground level.

- **Center Down Switch** - Two consecutive down-taps will lower the center rack to the desired spray height and enable both booms.

Note: Center rack control will not be enabled since center rack control is off.

- **Center Up Switch** - Two consecutive up-taps will disable both booms and raise the center rack to the desired transport height. Four consecutive up-taps will raise the center rack to the maximum height and turn AutoBoom off, preserving the new transport position as the maximum height.
 - Set a lower transport height - While the center rack is returning to transport, down-tap once on the center switch when the new transport height is reached.
 - Set the transport height to the maximum height - With the center rack positioned higher than the current transport height and with the AutoBoom not currently returning to the transport height, up-tap twice on the center switch to move the center rack to the maximum height.

Operating the UltraGlide AutoBoom System in PowerGlide Plus Mode (Square Coils on the AutoBoom Valve)

The UltraGlide AutoBoom system is also capable of operating in the PowerGlide Plus mode. In addition to the AutoBoom valve modification listed below, a gauge wheel kit is required for the system to operate in the PowerGlide Plus mode. For available kits and ordering information, contact your local Raven dealer

Complete the following steps to convert the UltraGlide AutoBoom valve to the PowerGlide Plus Mode.

FIGURE 26. Needle Valves on the UltraGlide AutoBoom Valve




1. Locate the needle valves in Ports RT and LF on the AutoBoom valve.
2. Loosen the jam nuts on the needle valves.
3. Use an Allen wrench to turn the set screws counter-clockwise until they won't move any further.

- Tighten the jam nuts.

Note: When converting the AutoBoom system back to UltraGlide, the needle valves must be screwed all the way back in (clockwise).

FIGURE 27. ISO Terminal Programmed to Run in PowerGlide Plus Mode



- Program the ISO terminal to run in PowerGlide Plus mode.

Note: When converting the AutoBoom system back to UltraGlide, the ISO terminal display must show the UltraGlide mode selected.

Operating the UltraGlide AutoBoom System in PowerGlide Plus Mode (Round Coils on the AutoBoom Valve)

Before populating the hydraulic fittings on the AutoBoom valve, it is necessary to remove orifice fittings from the valve in the PowerGlide Plus system. Failure to remove these fittings from the valve will restrict the down speed of the booms when the system is enabled.

FIGURE 28. Port 3A and 3B Location



- Locate Ports 3A and 3B on the AutoBoom valve.

FIGURE 29. Coil Removed from the AutoBoom Valve



2. Remove the coils from the solenoids near Ports 3A and 3B to gain easy access to those ports.

FIGURE 30. Port Plugs Removed from the AutoBoom Valve



3. Use an Allen wrench to remove the plugs from Ports 3A and 3B.

FIGURE 31. Orifice Fitting Removed from the AutoBoom Valve



4. Remove the orifice fittings from Ports 3A and 3B.

Important: Tip the AutoBoom valve on its side and use the Allen wrench to remove the orifice from the cavity, taking care not to let the fitting fall into the valve.

FIGURE 32. Port Plug Reinstalled on the AutoBoom Valve



5. Use the Allen wrench to reinstall the port plugs on Ports 3A and 3B of the AutoBoom valve.


FIGURE 33. Coil Reinstalled on the AutoBoom Valve



6. Reinstall the coils on the solenoids of the AutoBoom valve.

Note: When converting the AutoBoom system back to UltraGlide, the orifice fittings must be reinstalled.

FIGURE 34. ISO Terminal Programmed to Run in PowerGlide Plus Mode




7. Program the VT display to run in PowerGlide Plus mode.

Note: When converting the AutoBoom system back to UltraGlide, the VT display must show the UltraGlide mode selected.

System Adjustments

Note: AutoBoom must be enabled after both booms have been calibrated in order to make system adjustments.




Ultrasonic Sensor Height Offsets

Ultrasonic sensor height offset adjustments are used to compensate for the difference between the height of the sensor surface and the height of the spray tip. The offset height is calculated by measuring the distance from the bottom of the sensor to the height of the crop, measuring the distance between the spray tip to the

height of the crop, and then subtracting the spray tip distance from the sensor distance. Refer to the diagram below to determine whether the offset value should be positive or negative.

Note: The maximum offset height value is 20 inches.

Note: Ultrasonic sensors will react to the first object that reflects an echo, whether it is the ground or the crop. For row-crop situations, it may be beneficial to adjust the sensor positions to directly over a row, or add additional boom sensors.



- Touch **+** in the Sensor Height section to increase the value representing the distance between the sensor and the ground.
- Touch **-** in the Sensor Height section to decrease the value representing the distance between the sensor and the ground.

Note: On machines with travel-limited booms, center sensor height offsets may need to be entered as less than the measured value from the sensor to the ground to ensure the boom cylinders have sufficient pressure during operation.

Sensitivity

1. Place one hand at ground level below one boom sensor and raise it slowly (about one foot per second) to within 12 inches of the sensor surface.

Note: The boom should react immediately and raise at approximately the same speed as your hand.

2. Adjust the Sensitivity setting as needed to make the boom more or less reactive to hand motions.

Note: The default setting is 15. If the Sensitivity is too high, the boom will appear unstable and jittery, reacting to slight changes in target height or crop movement. The typical Sensitivity setting that

works best for most machines is 13 - 17. During routine operation, AutoBoom should be unresponsive to changes in height of 2" - 3", but should react quickly to changes of 5" or more.

For row-crop situations, or when crop conditions are sparse and not fully covering the ground, it may be beneficial to decrease the sensitivity so the boom is less reactive to sudden changes in crop height, and less likely to cause sudden movements that diminish performance.

Speed

The Speed setting controls how fast the boom will move away from an obstacle, and how much the boom overshoots the target height. The Speed setting should be set so that the boom motion is smooth and the machine does not oscillate. Adjust the Speed setting as needed so that boom raise rates match hand movement rates, but so that the booms don't overreact and become unstable.

1. Place one hand at ground level below one boom sensor and raise it quickly (about 2 feet per second) to within 12 inches of the sensor surface.

Note: *The boom should react immediately and adjust at a raise speed matching the hand movement, overshooting the new target height by one foot or less.*

2. Adjust the Speed setting as needed.

Note: *The default setting is 25. The Speed setting should be set so that the boom motion is smooth and the machine does not oscillate. The typical Speed setting that works best for most machines is 22 - 27, but can be much higher depending on the static pressures of the boom, boom geometry, and the Sensitivity settings.*

Stability

1. Place one hand at ground level below one boom sensor and raise it quickly (about two feet per second) to within 12 inches of the sensor surface, while observing the movement of the opposite boom.

Note: *The opposite boom should raise slightly (usually no more than six inches) simultaneously.*

2. Adjust the Stability setting to minimize movement of the opposite boom.

Note: *Lower the Stability value to make the opposite boom more rigid, but keep the number high enough to allow for natural movement of the boom without affecting the chassis roll.*

Min Press %

Note: *On machines with travel-limited booms, operate the AutoBoom system with center rack control enabled, or with the center sensor at or slightly below the target height to prevent the booms from continuously entering the Min Press % mode. This mode is for boom emergency protection only, and AutoBoom system should not be run in this mode during routine operation.*

1. Raise the center rack section to the target height, so that the booms and center rack are horizontal.
2. Enable the AutoBoom system.
3. Locate the Min Press % setting in the AutoBoom control menus.

Note: *The default setting is 65.*

4. Increase the Min Press % value to approximately 80.
5. Place one hand at ground level below one boom sensor and raise it slowly (about one foot per second) to within 12 inches of the sensor surface, or until the boom travels up approximately three feet higher than the original target.

- Pull hand away, and verify that the booms lower slowly after a slight delay.

Note: *If the booms do not lower, decrease the Min Press % setting value by one and repeat the steps above. Continue performing the Min Press % test until the booms begin to lower.*

Slant Gain

Allows fine-tuning of the allowable rotation of the center section suspension. Higher Slant Gain values cause the slant control to react more aggressively when chassis roll is sensed by the node and can cause the boom to be excessively rigid, possibly causing damage to the center rack. Lower Slant Gain values cause the slant control to be less aggressive and can cause the system to be unreactive, not controlling the suspension based on the chassis roll.


- Take the machine to the field and observe the rotation of the center section suspension with the AutoBoom system on and left, right, and slant enabled.
- Adjust the Slant Gain setting to cause the slant control to be more or less reactive.

Note: *The default setting is 10.*


Resetting Defaults

Although it is not normally necessary, there may be circumstances under which it may be necessary to reset the system defaults. Resetting the defaults erases all AutoBoom system settings and adjustments that have been performed. System calibration will be required after the defaults have been reset.

- Touch **CAL** on the ISO terminal screen. The following screen will be displayed:



- Select the reset icon. The following screen will appear:




3. Select the left boom calibration icon to recalibrate the left boom.
4. Select the right boom calibration icon to recalibrate the right boom.
5. If equipped with center rack control, use the machine's joystick functions to raise and lower the center rack for six seconds in each direction.

Node

The AutoBoom CAN control node features several green light-emitting diodes (LEDs) which may be used to diagnose issues within the AutoBoom system.

Note: *If the LEDs are not displayed as outlined in the figure below or are all on continuously, check the CAN connections and the control cable connections on the node. If the issue persists, contact your local Raven dealer for additional technical support.*

FIGURE 1. AutoBoom CAN Control Node LEDs



AutoBoom Pre-Calibration Diagnostics

Problem	Possible Cause	Corrective Action
AutoBoom icon does not appear on the VT display.	The AutoBoom node is not being detected.	Check the electrical connections to the node including the power and CAN communication circuits.
	Power circuits are not properly connected.	<ul style="list-style-type: none"> • Check power circuits. • Verify high current, logic, and CAN power systems are connected to the battery and switched properly.
	Malfunctioning/improperly connected CAN system.	<ul style="list-style-type: none"> • Verify the CAN system is installed correctly. • Verify terminators, cables, and connections are functioning.
Pressures/heights are not being displayed in the correct units of measure.	System startup performed incorrectly.	Turn the power to the CAN system off, then on.
	Units of measure programmed incorrectly.	Reprogram the VT display to display the correct units of measure.
Pressures for the left and right boom are not displayed on the correct side.	The left and right pressure transducer connections are reversed.	Reverse the left and right transducer connections.
	The left and right hose connections are reversed.	Reverse the left and right cylinder connections on the AutoBoom valve.
Ultrasonic sensor heights are displaying incorrect locations.	The left and right ultrasonic sensor connections are reversed.	Reverse the left and right outer sensor connections on the AutoBoom harness cable.
	The outer sensors are connected to the inner sensor connectors.	Disconnect the sensors from the AutoBoom harness cable and connect the outer sensor connectors to the sensors.
Left, right and center raise/lower functions are not sensed correctly when the machine's functions are used.	The boom sense cables/connections are connected to the incorrect machine coils.	Check the connections to the machine's coils and trace the wiring to ensure the connections are made to the correct coils.
Center section will not raise/lower manually with the machine's functions.	The center rack boom sense cables are not connected to the correct center sense/control function.	Check the connections to the machine's coils and trace the wiring to ensure the connections are made to the correct coils.

AutoBoom Calibration

Problem	Possible Cause	Corrective Action
Booms do not move during calibration.	The proportional/blocker connections are reversed or improperly connected.	Check the connections on the AutoBoom valve to ensure the harness cable connections are connected to the correct ports.
	The hydraulic connections are improperly connected.	Check the hydraulic connections.
	Booms are resting on their stops or the cylinders are fully extended.	Raise the booms and lower the center rack to ensure pressure is sufficient in the booms for calibration.
	The pressure transducer or connection is faulty.	Check the transducer connections to the AutoBoom harness cable.
	There is insufficient high current power.	Check the power and ground connections at the battery and AutoBoom node.
The booms fully raise during calibration and do not lower.	The inner and outer sensor connections are reversed.	Check the inner and outer sensor connections and reverse them if necessary.
	The ultrasonic sensors are giving poor readings.	<ul style="list-style-type: none"> • Check the cabling to the sensors. • Verify the sensor surface is clean. • Verify no obstructions or boom components are interfering with sensor readings.
	The hydraulic connections are improperly connected.	<ul style="list-style-type: none"> • Check the hydraulic connections. • Reverse the direction of the hydraulic lever on pull-type sprayers.
	The electrical connections to the AutoBoom valve are reversed.	Check the connections to the proportional and blocker valves and reverse if necessary.
	The Speed setting is too high.	Decrease the Speed setting.
	The Sensitivity setting is too high.	Decrease the Sensitivity setting.
	The hydraulic flow is too high (pull-type sprayers only).	Decrease the hydraulic flow on the AutoBoom circuit remote. The flow should be 3 - 5 gpm or 20 - 30%.



Problem	Possible Cause	Corrective Action
The booms fall to the ground during calibration	The proportional valve connections are reversed on the AutoBoom valve.	Check the connections on the AutoBoom valve to ensure the harness cable connections are connected to the correct ports.
	The hydraulic connections are improperly connected.	<ul style="list-style-type: none"> • Check the hydraulic connections. • Reverse the direction of the hydraulic lever on pull-type sprayers.
	Malfunctioning proportional valve.	Turn the set screws in on the proportional valve to verify the booms raise during calibration. <ul style="list-style-type: none"> • If the booms raise, troubleshoot the electrical system and/or AutoBoom node. • If the booms do not raise, troubleshoot the hydraulic system and/or AutoBoom node.
	The hydraulics are not activated (pull-type sprayers only).	<ul style="list-style-type: none"> • Verify the hydraulics are activated. • Ensure hydraulic flow going to the AutoBoom valve.
Booms over-react or oscillate during calibration.	There are objects beneath the sensors causing faulty readings.	Attempt to calibrate the system over open ground or consistent crop canopy.
	The inner and outer sensor connections are reversed.	Check the inner and outer sensor connections and reverse if necessary.
	Faulty ultrasonic sensor readings.	Check the sensors and cabling and replace if necessary.
	The Speed setting is set too high.	Decrease the Speed setting.
	The Sensitivity setting is too high.	Decrease the Sensitivity setting.
	The hydraulic flow is too high (pull-type sprayers only).	Decrease the hydraulic flow to the AutoBoom circuit remote.

AutoBoom Operation

Problem	Possible Causes	Corrective Action
The booms will not enable with the down-tap of the machine's functions.	The boom sense adapter cables are damaged or not connected.	<ul style="list-style-type: none"> • Check the cabling. • Use the Diagnostics menu to determine the proper wiring setup.
	There is inadequate voltage to the system.	Use a multi-meter to verify +12V is provided to the machine's coils when the function is activated.
	The AutoBoom system is not calibrated.	Calibrate the AutoBoom system.
	The AutoBoom harness cable is damaged.	Inspect the cable for damage and repair or replace as needed.
	The AutoBoom node is faulty.	Replace the AutoBoom node.

Problem	Possible Causes	Corrective Action
The pressure alarm is always on.	The pressure alarm setting in the PowerGlide Plus mode is set too low.	Increase the pressure alarm setting.
	The pressure and tank hoses are reversed.	Check the hoses and reverse if necessary.
	The pressure transducer is faulty.	<ul style="list-style-type: none"> • Inspect the transducer and verify the pressure reading on the Diagnostic screen. • Replace the pressure transducer if necessary.
	The pressure transducers are not connected to the AutoBoom harness cable.	Connect the pressure transducers to the AutoBoom harness cable.
	The AutoBoom harness cable is damaged.	Inspect the cable for damage and repair or replace as needed.
	Booms are resting on their stops or the cylinders are fully extended.	Raise the booms, lower the center section, and re-engage AutoBoom.
Objects under one boom makes the opposite side react.	The left and right sensor connections are reversed.	Check the left and right sensor connections and reverse them if necessary.
	The proportional valve connections are reversed or one side is not connected.	Check the connections on the AutoBoom valve to ensure the harness cable connections are connected to the correct ports.
	The Stability setting is too low.	Increase the Stability setting incrementally until the opposite side barely raises.
	The proportional valve is faulty.	<ul style="list-style-type: none"> • Inspect the proportional valve. • Clean and/or replace if necessary.
The booms oscillate or overreact when the machine is stationary.	The Sensitivity setting is too high.	Decrease the Sensitivity setting by one increment until the boom oscillation stops.
	The wind is affecting the sensor readings.	Decrease the Sensitivity setting by one increment until the boom oscillation stops.
	The Speed setting is too high.	Decrease the Speed setting by one increment until the boom oscillation stops.
	The center section is unstable.	Decrease the Stability setting to balance the movement of the booms on both sides of the center section.
	Sporadic ultrasonic sensor readings.	Inspect the sensor cabling for damage and repair or replace as needed.



Problem	Possible Causes	Corrective Action
The booms raise but will not lower or lower too slowly during operation.	The incorrect PWM frequency was entered.	Verify the PWM frequency setting in the Raven console/field computer. (60 Hz for square coil valves, 250 Hz for round coil valves).
	The Speed setting is too low	Increase the Speed setting.
	The Minimum Pressure % setting is too high.	Decrease the minimum pressure % setting by one increment until the booms lower at the desired rate.
	The set pressure is too high (PowerGlide Plus only).	Decrease the set pressure by 10 until the booms lower at the desired rate.
	The inner and outer sensor connections are reversed.	Check the inner and outer sensor connections and reverse them if necessary.
	Faulty ultrasonic sensor readings.	Check the sensors and cabling and replace if necessary.
	The orifices or circuit restrictions are restricting the return flow from the tilt cylinders.	Inspect the AutoBoom hydraulics and remove orifices or restrictions in the circuit if necessary.
The booms are slow to raise or are unresponsive to height changes.	The Speed setting is too low.	Increase the Speed setting.
	The Sensitivity setting is too low.	Increase the Sensitivity setting.
	Excessive ground speed.	Decrease the ground speed.
	The incorrect sensor height offsets were entered.	Verify the proper height offset and adjust the settings as needed. Refer to the appropriate chapter in this manual for the Raven controller/field computer being used to determine the height offset settings calculation.
	The orifices or circuit restrictions are restricting the return flow from the tilt cylinders.	Inspect the AutoBoom hydraulics and remove orifices or restrictions in the circuit if necessary.
Booms raise but will not lower when starting the machine or engaging the hydraulics (pull-type sprayers) with AutoBoom engaged.	The PWM base is too high.	Engage the AutoBoom hydraulics and allow the PWM base to decrease and the booms to lower automatically.
	The system is out of calibration.	Re-calibrate the AutoBoom system.
Unable to switch from PowerGlide Plus mode to UltraGlide.	The ultrasonic sensors are not detected.	<ul style="list-style-type: none"> • Connect ultrasonic sensors • Check cabling to sensors and node and repair or replace if necessary.
	The ultrasonic sensors are connected to inner sensor connectors on a non-dual sensor system.	Connect ultrasonic sensors to the outer sensor connectors.
	The UltraGlide node is not connected to the CAN bus.	Verify the node is connected to the CAN bus.


CHAPTER

6


System Diagrams

This section contains system diagrams for machine-specific ISO AutoBoom machine configurations. Identify the appropriate schematic for the type of machine on which the ISO AutoBoom system is being installed.


ISO AUTOBOOM WITHOUT ISO PRODUCT CONTROL




ISO AUTOBOOM FOR AGCO ROGATOR



ISO AUTOBOOM FOR JOHN DEERE SELF PROPELLED SPRAYERS



RAVEN ISO AUTOBOOM WITH JOHN DEERE PRODUCT CONTROL



E

Electrical Safety 2

H

Hydraulic Safety 2

I

Important Safety Information 1

Electrical Safety 2

Hydraulic Safety 2

Introduction 3

Pre-Installation 4

Updates 3

Wiring Connections 5

K

Kit Contents

PowerGlide Plus 7

UltraGlide 33

P

PowerGlide Plus

Installing the ISO AutoBoom Wiring 10

Connecting the Boom Sense Functions via Scotch Lock Splice Connectors (If Applicable) 11

Connecting the Harness Cable to the Machine 13

Connecting the Harness Cable to the Power Cable 12

Connecting the Harness to the Boom Function Controls 10

Installing the AutoBoom Node 10

Installing the Power Leads 12

Kit Contents 7

Routine Operation 21

Alarms 23

AutoBoom Icons 21

AutoBoom Pre-Calibration Diagnostics 25

Boom Adjustments When Approaching Headlands 29

Calibration 26

Center Rack Control 29

Center Rack Control Calibration (If Equipped) 27

Diagnostic Tools 23

Enabling AutoBoom via the ISO Terminal 28

Joystick Functions 28

Resetting Defaults 31

Routine Operation 28

Setup Tools 22

System Adjustments 30

U

UltraGlide

Installing the ISO AutoBoom Wiring 36

Connecting the Boom Sense Functions via Scotch Lock Splice Connectors (If Applicable) 37

Connecting the Harness Cable to the Machine 39

Connecting the Harness Cable to the Power Cable 38

Connecting the Harness to the Boom Function Controls 36

Installing the AutoBoom Node 36

Installing the Power Leads 38

Kit Contents 33

Routine Operation 47

Alarms 51
AutoBoom Icons 47
AutoBoom Pre-Calibration Diagnostics 53
Boom Adjustments When Approaching Headlands 59
Calibration 54
Center Rack Control 59
Center Rack Control Calibration 57
Diagnostic Tools 50
Enabling AutoBoom via the Viper Pro 58
Joystick Functions 58
Operating in PowerGlide Plus Mode) 60
Resetting Defaults 67
Routine Operation 58
Setup Tools 48
Slant Control Calibration 56
System Adjustments 64

Slant Gain 67

Min Press % 66
Sensitivity 65
Speed 66
Stability 66
Ultrasonic Sensor Height Offsets 64

RAVEN

Limited Warranty

What Does this Warranty Cover?

This warranty covers all defects in workmanship or materials in your Raven Applied Technology Division product under normal use, maintenance, and service when used for intended purpose.

How Long is the Coverage Period?

Raven Applied Technology products are covered by this warranty for 12 months from the date of retail sale. In no case will the Limited Warranty period exceed 24 months from the date the product was issued by Raven Industries Applied Technology Division. This warranty coverage applies only to the original owner and is non-transferable.

How Can I Get Service?

Bring the defective part and proof of purchase to your Raven dealer. If the dealer approves the warranty claim, the dealer will process the claim and send it to Raven Industries for final approval. The freight cost to Raven Industries will be the customer's responsibility. The Return Materials Authorization (RMA) number must appear on the box and all documentation (including proof of purchase) must be included inside the box to be sent to Raven Industries.

What Will Raven Industries Do?

Upon confirmation of the warranty claim, Raven Industries will (at our discretion) repair or replace the defective product and pay for the standard return freight, regardless of the inbound shipping method. Expedited freight is available at the customer's expense.

What is not Covered by this Warranty?

Raven Industries will not assume any expense or liability for repairs made outside our facilities without written consent. Raven Industries is not responsible for damage to any associated equipment or products and will not be liable for loss of profit, labor, or other damages. The obligation of this warranty is in lieu of all other warranties, expressed or implied, and no person or organization is authorized to assume any liability for Raven Industries.

Damages caused by normal wear and tear, misuse, abuse, neglect, accident, or improper installation and maintenance are not covered by this warranty.



Extended Warranty

What Does this Warranty Cover?

This warranty covers all defects in workmanship or materials in your Raven Applied Technology Division product under normal use, maintenance, and service when used for intended purpose.

Do I Need to Register My Product to Qualify for the Extended Warranty?

Yes. Products/systems must be registered within 30 days of retail sale to receive coverage under the Extended Warranty. If the component does not have a serial tag, the kit it came in must be registered instead.

Where Can I Register My Product for the Extended Warranty?

To register, go online to www.ravenhelp.com and select Product Registration.

How Long is the Extended Warranty Coverage Period?

Raven Applied Technology products that have been registered online are covered for an additional 12 months beyond the Limited Warranty for a total coverage period of 24 months from the date of retail sale. In no case will the Extended Warranty period exceed 36 months from the date the product was issued by Raven Industries Applied Technology Division. This Extended Warranty coverage applies only to the original owner and is non-transferable.

How Can I Get Service?

Bring the defective part and proof of purchase to your Raven dealer. If the dealer approves the warranty claim, the dealer will process the claim and send it to Raven Industries for final approval. The freight cost to Raven Industries will be the customer's responsibility. The Return Materials Authorization (RMA) number must appear on the box and all documentation (including proof of purchase) must be included inside the box to be sent to Raven Industries. In addition, the words "Extended Warranty" must appear on the box and all documentation if the failure is between 12 and 24 months from the retail sale.

What Will Raven Industries Do?

Upon confirmation of the product's registration for the Extended Warranty and the claim itself, Raven Industries will (at our discretion) repair or replace the defective product and pay for the standard return freight, regardless of the inbound shipping method. Expedited freight is available at the customer's expense.

What is Not Covered by the Extended Warranty?

Raven Industries will not assume any expense or liability for repairs made outside our facilities without written consent. Raven Industries is not responsible for damage to any associated equipment or products and will not be liable for loss of profit, labor, or other damages. Cables, hoses, software enhancements, and remanufactured items are not covered by this Extended Warranty. The obligation of this warranty is in lieu of all other warranties, expressed or implied, and no person or organization is authorized to assume any liability for Raven Industries.

Damages caused by normal wear and tear, misuse, abuse, neglect, accident, or improper installation and maintenance are not covered by this warranty.

ISO AutoBoom®
Calibration & Operation Manual
(P/N 016-0130-065 Rev F 06/14 E23261)

RAVEN



Raven Industries
Applied Technology Division
P.O. Box 5107
Sioux Falls, SD 57117-5107
www.ravenprecision.com

Toll Free (U.S. and Canada): (800)-243-5435
or Outside the U.S. :1 605-575-0722
Fax: 605-331-0426
www.ravenhelp.com

Notice: This document and the information provided are the property of Raven Industries, Inc. and may only be used as authorized by Raven Industries, Inc. All rights reserved under copyright laws.

©Raven Industries, Inc. 2008, 2009, 2011, 2012, 2014